

101-1115-3740-200-25P

TM 5-3740-200-25P

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

RETURN TO GOV. CORP. 1967

**ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT,
AND DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST
SPRAYER, INSECTICIDE,
SKID MOUNTED: GASOLINE DRIVEN;
40 GAL PER HOUR; FOG (CURTIS
AUTOMOTIVE DEVICES MODEL CFR-40000)
FSN 3740-790-6188**

This copy is a reprint which includes current
pages from Changes 2 and 3.

HEADQUARTERS, DEPARTMENT OF THE ARMY

APRIL 1967

Changes In force C 2

***TM 5-3740-200-25P
C 2**

Change }
No. 2 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D. C., 3 January 1972

**Organizational, Direct and General Support and Depot Maintenance
Repair Parts and Special Tools List
SPRAYER, INSECTICIDE, SKID MOUNTED; GASOLINE DRIVEN;
40 GAL. PER HOUR; FOG (CURTIS AUTOMOTIVE DEVICES MODEL
CFR-40000) FSN 3740-790-6188**

Current as of 26 October 1971

TM 5-3740-200-25P, 10 April 1967, is changed as follows:

Page xi, paragraph 7; change FMC 01510, MIEHLE-DEXTER supercharger division of Christianson Machine Co., Inc. to FMC 03951, MIEHLE and GOSS AND DEXTER.

8. Report of Equipment Publication Improvements.

The reporting of errors, omissions, and recommendations for improving this publications by

the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commanding General, U.S. Army Mobility Equipment Command, ATTN: AMSME-MP, 4300 Goodfellow Boulevard, St. Louis, Mo. 63120.

All changes, additions, or deletions of Federal stock numbers, or manufacturers part number within this change should be appropriately reflected in the index.

Page xiii, in line 2, Group 55, FSN 3740-542-3717, column 3 (01510) change to read (03951).

*This change supersedes C1, 21 October 1968.

[illegible]

Page	Line	Action	1			2	3	4	5	6	7			8	9	10	
			Source maintenance and recoverability code								30-day DS/GS maint. allowance	1 yr alw per 100 equip cntry planing pur. poses	Depot maint alw per 100 equip			Illustrations	
			Source	Maintenance	Recoverability												Figure No.
11	0630	Ch col 3	X2	O		5310-584-5005 5305-068-0502 5310-527-3289	GROUP 18 — BODY, CAB, HOOD AND HULL 1801 — BODY, CAB, HOOD CANOPY A CANOPY ASSEMBLY (97403) 13200E5402 DECK PLATE (97403) 13200E5417 FLANGE, MUFFLER (97403) 13200E5427 NUT, PLAIN, HEXAGON: *** SCREW, MACHINE: *** WASHER, LOCK: *** PANEL, FRONT (97403) 13200E5413 GROMMET, FRONT PANEL (97403) 13200E5413-5 RETAINER, FRONT PANEL (97403) 13200E5413-6 STUD, FRONT PANEL (97403) 13200E5413-4 PANEL, REAR (97403) 13200E5415 GROMMET, REAR PANEL (97403) 13200E5415-5 RETAINER, REAR PANEL (97403) 13200E5415-6 STUD, REAR PANEL (97403) 13200E5415-4 STRAP, HOLD DOWN: *** (97403) 13200E5423 1808 — STRAPS STRAP, HOLD DOWN: *** (97403) 13200E5422										
	0631	Ch col 3	X2	O													
	0632	Ch col 3	X2	O													
	0633	Ch col 3															
	0634	Ch col 3															
	0635	Ch col 3															
	0636	Ch col 3	X2	O													
	0637	Ch col 3	X2	O													
	0638	Ch col 3	X2	O													
	0639	Ch col 3	X2	O													
	0640	Ch col 3	X2	O													
0641	Ch col 3	X2	O														
0642	Ch col 3	X2	O														
0643	Ch col 3	X2	O														
0646	Ch col 3	X2	O														
0653	Ch col 3	X2	O														

[illegible]

Page	Line	Action	1			2	3	4	5	6	7			8	9	10		
			Source mainte- nance and recoverability code								30-day DS/GS maint. allowance					1 yr alw per 100 equip cntgy plan- ing pur- poses	Depot maint alw per 100 equip	Illustrations
			Source	Mainte- nance	Recovera- bility						1-20	21-50	51-100					
12	0679	Ch col 3	X2	O			PLATE, NAME: *** (03951) 6459											
	0681	Ch col 3		O			RIVET, SOLID: *** (97403) 13200E5399-40											
	0682	Ch col 3	X2	O			SCREW DRIVE: *** (03951) 1120											
	0682	Ch col 3	X1				FLOAT, OUT (82254) CFR 40469											
13	0689	Ch col 3	X1				STOP, FLOAT (82254) 304A193											
	0700	Ch col 3	X1				TUBE, METER (82254) CFR 40468											
	0701	Ch col 3	X2			6685-855-7226	GAGE, PRESSURE: *** (97403) 13200E5399-7											
	0710	Ch col 2		O		5310-012-0614	NUT, PLAIN, HEXAGON: ***											
	0713	Ch col 3	M	O			(96906) MS35650-102 TUBE: ***											
	0714	Ch col 3	M	O		3740-971-1419	(97403) 13200E5399-24 TUBE: ***											
	0715	Ch col 3	X2	O			(97403) 13200E5399-23 VALVE, NEEDLE: ***											
	0717	Ch col 3		O		5310-595-7235	(97403) 13200E5399-2 WASHER, LOCK: ***											
							(96906) MS35333-20 GROUP 55 — PUMPS											
	0726	Ch col 2		O		5310-543-2628	5500 — PUMP ASSEMBLY NUT, PLAIN HEXAGON: ***											
0731	Ch col 3	X2	O			(96906) MS35690-602 SHIM: *** (97403) 13200E5431												

Page	Line	Action	1			2	3	4	5	6	7			8	9	10	
			Source mainte- nance and recoverability code		Recovera- bility						30-day DS/GS maint. allowance		1 yr alw per 100 equip enrgy plan- ing pur- poses			Depot maint alw per 100 equip	Illustrations
			Source	Mainte- nance							1-20	21-80					
16	0881	Ch col 3	X2	O			ELBOW, HOSE: *** (97403) 13200E5399-19										
	0882	Ch col 3	X2	O			ELBOW, HOSE: *** (97403) 13200E5399-19										
	0887	Ch col 3	X2	O			ELBOW, PIPE TO TUBE: *** (97403) 13200E5341-7										
	0889	Ch col 3	X2	O			HOSE: *** (97403) 13200E5399-32										
	0890	Ch col 3	M	O			HOSE: *** (97403) 13200E5399-31										
17	1002	Ch col 3	X	O			NIPPLE, PIPE: *** (97403) 13200E5399-13										
	1005	Ch col 1a	P	O			STRAINER ASSEMBLY, HOSE (82254) CFR 40587										
	1019	Ch col 3	X2	O			TEE, PIPE: *** (97403) 13200E5399-31										
	1020	Ch col 3	X2	O			TEE, PIPE: *** (97403) 13200E5341-3										
	1021	Ch col 3	X2	O			TEE, PIPE TO TUBE: *** (97403) 13200E5341-9										
18	1022	Ch col 3	X2	O			TUBE ASSEMBLY: *** (97403) 13200E5341-1										
	1023	Ch col 3	M	O			TUBE ASSEMBLY: *** (97403) 13200E5341-8										
	1024	Ch col 1A & 3 Add col 2	M	O		4720-994-1522	TUBE FLUID: *** (97403) 13200E5399-27										
	1025	Ch col 3	X2	O			TUBE FLUID: *** (97403) 13200E5399-26										
	1026	Ch col 3	X2	O		4720-995-1522	TUBE, TEFLON: *** (97403) 13200E5399-25										
	1027	Add Col 2 Ch col 3	M	O			TUBE, VINYL: *** (97403) 13200E5399-23										
	1028	Ch col 3	X2	O			UNION, HALF: *** (97403) 13200E5399-11										

Page	Line	Action	1			2	3	4	5	6	7			8	9	10			
			Source maintenance and recoverability code		Recoverability						30-day DS/GS maint. allowance					1 yr alw per 100 equip engecy planing pur- poses	Depot maint alw per 100 equip	Illustrations	
			Source	Maintenance							1-20	21-50	51-100					Figure No.	Item or symbol No.
23	1196	Ch col 3	X2	O		GROUP 57 — SPRAY EQUIPMENT COMPONENTS 5704—SPRAY DUCTS AND MANIFOLDS MANIFOLD SPRAY ASSEMBLY (97403) 13200E5341 CLAMP, DRUM (97403) 13200E5358 ELBOW LONG (97403) 13200E5350 ELBOW SHORT (97403) 13200E5353 END CAP NOZZLE HEAD NOZZLE ASSEMBLY SCREW TOGGLE: *** (97403) 13200E5359 GROUP 57—SPRAY EQUIPMENT COMPONENTS 5704—SPRAY DUCTS AND MANIFOLDS END CAP: NOZZLE HEAD MANIFOLD SPRAY ASSEMBLY (97403) 13200E5341 CLAMP, DRUM (97403) 13200E5358 ELBOW, LONG (81336) 13200E5350 ELBOW, SHORT (81336) 13200E5353 SCREW, TOGGLE: *** (81336) 13200E5359													
	1197	Ch col 3	X2	O															
	1198	Ch col 3	X2	O															
	1199	Ch col 3	X2	O															
	1200	Delete all	X2																
	1201	Delete all	X2																
	1202	Ch col 3	X2	O															
27	1357	Delete all col	X2																
	1358	Delete all col	X2																
	1353	Ch col 3	X2	O															
	1354	Ch col 3	X2	O															
	1355	Ch col 3	X2	O															
	1356	Ch col 3	X2	O															
	1359	Ch col 3	X2	O															

Page	Line	Action	1			2	3	4	5	6	7		8	9	10	
			Source	Mainte- nance	Source mainte- nance and recoverability code						30-day DS/GS maint. allowance	1 yr alw per 100 equip ctgcy plan- ing pur- poses			Figure No.	Item or symbol No.
35	1677 thru 1682	Delete all col					GROUP 57 — SPRAY EQUIPMENT COMPONENTS 5704 — SPRAY DUCTS AND MANIFOLDS				1-20 21-50 51-100					
38	1820 thru 1834	Delete all col					GROUP 76 — FIRE FIGHTING EQUIPMENT COMPONENTS 7603 — FIRE EXTINGUISHER NUT, PLAIN, HEXAGON: *** (96906) MS35690-405 PART VII GROUP 01 — ENGINE 0101 — CRANKCASE, BLOCK, CYLINDER HEAD EXTENSION, OIL DRAIN (82254) CFR 40974 GROUP 57 — SPRAY EQUIPMENT COMPONENTS 5704 — SPRAY DUCTS AND MANIFOLDS									
39	1838	Add col 2	X2	0		5310-584-5005										
40	1849	Ch col 3	X2	0												
42	1973 thru 1987	Delete all col														

Page	Line	Action	1			2	3	4	5	6	7			8	9	10			
			Source maintenance and recoverability code								30-day DS/GS maint. allowance					1 yr alw per 100 equip enrgy plan- ing pur- poses	Depot maint alw per 100 equip	Illustrations	
			Source	Mainte- nance	Recovera- bility						Unit of issue	Qty per unit pack	Qty inc in unit					1-20	21-50
44	0030	Add col 1a, 7c, 8 ch col 2	P	O		5306-225-8504	SECTION IV — REPAIR PARTS FOR DS, GS AND DEPOT MAINTENANCE PART I GROUP 01 — ENGINE ASSEMBLY BOLT, MACHINE: ***						6						
	0038	Add col 1a, 7c, 8 Ch col 2	P	O		5315-753-3893	PIN, SPRING: *** (66289) PA332						2						
	0042	Add col 1a, 3	P	O		5305-068-0502	SCREW, CAP, HEXAGON HEAD: *** (66289) XD6						2						
45	0068	Add col 1a, 7c, 8	P	O		5315-952-3107	0102 — CRANKSHAFT KEY, MACHINE: ***						2						
	0082	Ch col 3	X2	O			SHEAVE, CRANKSHAFT: *** (97403) 13200E5435							6					
46	0104	Ch col 7c, 8, 9	P	H		5340-374-9707	0104 — PISTONS, CONNECTING RODS RING, RETAINING: *** (96906) MS13962-1						2	12	20				
	0253	Add col 1a ch col 7c, 8, 9	P	O		5305-068-0502	GROUP 03 — FUEL SYSTEM 0302 — FUEL PUMPS SCREW, CAP, HEXAGON HEAD: ***						2	6	10				
51	0275	Ch col 3, 8, 9	P	O		4710-872-1781	0306 — TANKS, LINES, FITTINGS LINE, FUEL PLASTIC: *** (97403) 13200E5428-1							6	*				

Page	Line	Action	1 Source maintenance and recoverability code			2 Federal stock No.	3 Description	4 Unit of issue	5 Qty inc in unit pack	6 Qty inc in unit	7 30-day DS GS maint. allowance			8 1 yr alw per 100 equip cntry plan-ling pur-poses	9 Depot maint alw per 100 equip	10 Illustrations	
			Source	Maintenance	Recoverability						1-20	21-50	51-100			Figure No.	Item or symbol No.
54	0358	Ch col 3	M	O		5310-543-2628	GROUP 04 — EXHAUST SYSTEM										
							0401 — MUFFLER AND PIPES										
							PIPE, EXHAUST (97403) 13200E5434										
59	0592	Ch col 2		O		5310-543-2628	GROUP 06 — ELECTRICAL SYSTEM										
							0612 — BATTERIES, STORAGE										
							NUT, PLAIN, HEXAGON: ***										
60	0626	Ch col 3	X2	F		5310-543-2628	GROUP 15 — FRAME ASSEMBLY										
							FASTENER: ***										
							(97403) 13200E5370-20										
60	0630	Ch col 3	X2	O		5310-543-2628	GROUP 18 — BODY, CAB, HOOD AND HULL										
							1801 — BODY, CAB, HOOD										
							CANOPY ASSEMBLY										
	0631	Ch col 3	X2	O			(97403) 13200E5402										
	0632	Ch col 3	X2	O			DECK PLATE										
	0636	Ch col 3	X2	O			(97403) 13200E5417										
	0637	Ch col 3	X2	O			FLANGE, MUFFLER										
	0638	Ch col 3	X2	O			(97403) 13200E5427										
	0639	Ch col 3	X2	O			PANEL, FRONT										
	0640	Ch col 3	X2	O			(97403) 13200E5413										
	0641	Ch col 3	X2	O			GROMMET, FRONT PANEL										
							(97403) 13200E5413-5										
							RETAINER, FRONT PANEL										
							(97403) 13200E5413-6										
							STUD, FRONT PANEL										
							(97403) 13200E5413-4										
							PANEL, REAR										
							(97403) 13200E5415										
							GROMMET, REAR PANEL										
							(97403) 13200E5415-5										

Page	Line	Action	1			2	3	4	5	7		8	9	10	
			Source	Maintenance	Recovery					30-day DS/GS maint. allowance	1-20	21-50	51-100	Figure No.	Item or symbol No.
60	0642	Ch col 3	X2	O			RETAINER, REAR PANEL (97403) 13200E5415-6								
	0643	Ch col 3	X2	O			STUD, REAR PANEL (97403) 13200E5415-4								
	0646	Ch col 3	X2	O			STRAP, HOLD DOWN: *** (97403) 13200E5423								
	0647	Ch col 3	X2	O			STRAP, HOLD DOWN: *** (97403) 13200E5424								
	0648	Ch col 3	X2	O			STRAP, HOLD DOWN: *** (97403) 13200E5425-1								
61							1808—STRAPS								
	0653	Ch col 3	X2	O			STRAP, HOLD DOWN: *** (97403) 13200E5422								
	0654	Ch col 3	X2	O			STRAP, HOLD DOWN: *** (97403) 13200E5424								
	0655	Ch col 3	X2	O			STRAP, HOLD DOWN: *** (97403) 13200E5425-1								
							GROUP 22—BODY CHASSIS OR HULL AND ACCESSORY ITEMS								
	0651	Ch col 3	X2	O			2201—CANVAS ITEMS CURTAIN ASSEMBLY								
	0659	Ch col 3	M	O		9820-771-1513	(97403) 13200E5421 SHIM: ***								
	0660	Ch col 3	M	O		3740-971-1418	(97403) 13200E4520-2 STRIP, CURTAIN:								
	0667	Ch col 3	X2	O			(97403) 13200E5419 2210 — DATA PLATES LABEL SET, IDENTIFICATION								
	0668	Ch col 3	X2	O			(97403) 13200E5402 PLATE, IDENTIFICATION: ***								
	0669	Ch col 3	X2	O			(97403) 13200E5399-38 PLATE, IDENTIFICATION: ***								
							(97403) 13200E5399-35								

Page	Line	Action	1			2	3	4	5	6	7			8	9	10	
			Source maintenance and recoverability code								30-day DS/GS maint. allowance					Illustrations	
			Source	Maintenance	Recoverability						1-20	21-50	51-100			Figure No.	Item or symbol No.
62	0672	Ch col 3	X2	O			PLATE, IDENTIFICATION: *** (97403) 13200E5399-39										
	0673	Ch col 3	X2	O			PLATE, IDENTIFICATION: *** (97403) 13200E5399-37										
	0674	Ch col 3	X2	O			PLATE, IDENTIFICATION: *** (97403) 13200E5399-36										
	0675	Ch col 3	X2	O			PLATE, IDENTIFICATION: *** (97403) 13200E5399-34										
	0679	Ch col 3	X2	O			PLATE, NAME: *** (03951) 6459										
	0681	Ch col 3				5320-117-7106	RIVET, SOLID: *** (97403) 13200E5399-40										
	0682	Ch col 3	X2	O			SCREW DRIVE: *** (00951) 1120										
							GROUP 47—GAGES (NON-ELECTRICAL) WEIGHING AND MEASURING DEVICES 4702—GAGES, LINES AND FITTINGS FLOAT OUT 82254 CFR40469 STOP, FLOAT (22375) 304A193 TUBE, METER (82254) CFR 40468 GAGE, PRESSURE: *** (97403) 13200E5399-7 NUT, PLAIN, HEXAGON: *** (96906) MS35650-102 TUBE: *** (97403) 13200E5399-24										
63	0692	Ch col 3	X1														
	0699	Ch col 3	X1														
	0700	Ch col 3	X1														
	0701	Ch col 3	X2	O		6685-855-7226											
	0710	Ch col 2		O		5310-012-0614											
	0713	Ch col 3	M	O													

[illegible]

Page	Line	Action	1			2	3	4	5	6	7			8	9	10		
			Source maintenance and recoverability code								30-day DS/GS maint. allowance	Qty inc in unit	Qty inc in unit pack			1 yr altw per 100 equip enclgy plan- ing pur- poses	Depot maint altw per 100 equip	Illustrations
			Source	Maintenance	Recoverability													
65	0075	Ch col 3	X1				COVER, GEAR END: *** (03951) 11701											
	0776	Ch col 3	X2	M			DOWEL, GEAR: *** (03951) 6036											
	0777	Ch col 3	X2	O			FITTING, LUBRICATING: *** (03951) 90265											
	0778	Ch col 3	X2	O			FITTING, RELIEF (03951) 90102											
	0779	Ch col 3	X2	F			GASKET: *** (03951) 11705											
	0780	Ch col 3	X2	F			GASKET: *** (03951) 11322											
	0781	Ch col 3	P	O		3740-542-3717	GASKET: *** (03951) 7932											
	0782	Ch col 3	X2	H			GEAR ASSEMBLY: *** (03951) 60169											
	0783	Ch col 3	X1				HOUSING: *** (03951) 11512											
	0784	Ch col 3	X2	H			KEY, GEAR: *** (03951) 11150											
	0786	Ch col 3				5310-012-0279	NUT, PLAIN, HEXAGON: *** (03951) 5871											
	0789	Ch col 3	X1				PLATE, FREE END: *** (03951) 11429R											
	0790	Ch col 3	X1				PLATE: *** (03951) 11772R											
	0791	Ch col 3	X2	F			PLATE LOCK (03951) 11739											
	0792	Ch col 3	X2	H			PLATE, LOCK: *** (03951) 6038											
	0793	Ch col 3	X2	H			PLATE, LOCK: *** (03951) 40325											
	0794	Ch col 3	X2	O			PLATE, NAME: *** (03951) 6459											

Page	Line	Action	1			2	3	4	5	6	7			8	9	10			
			Source maintenance and recoverability code								30-day DS/GS maint. allowance					1-yr allow per 100 equip category planning purposes	Depot maint allow per 100 equip	Illustrations	
			Source	Maintenance	Recoverability						1-20	21-50	51-100					Figure No.	Item or symbol No.
66	0831	Ch col 3	X2	O			FLANGE: *** (97403) 13200E5355												
	0832	Ch col 3	X2	O			GUARD ASSEMBLY, BELT (97403) 13200E0109												
	0836	Ch col 3	X2	O			MANIFOLD ASSEMBLY, INTAKE (97403) 13200E5363												
67	0856	Ch col 3	X2	O			5707 — INSTRUMENT PANEL BRACKET, PANEL (97403) 13200E5412												
	0858	Ch col 3	X2	O			PANEL ASSEMBLY, INSTRUMENT (97403) 13200E5399												
	0859	Ch col 3	X2	O			LABEL SET, IDENTIFICATION (97403) 13200E5402												
	0869	Ch col 3				4730-277-7899	5708 — TANKS, VALVES, LINES, HOSES, FITTINGS and LIQUID STRAINER BUSHING, PIPE: *** (97403) 13200E5499-16												
	0872	Ch col 3				4730-278-2538	CLAMP, HOSE: *** (97403) 13200E5399-29												
	0874	Ch col 3	X2	O		4820-845-1096	COCK, DRAIN: *** (97403) 13200E5430-4												
	0875	Ch col 3	X2	O			CONNECTOR, HOSE, PIPE: *** (97403) 13200E5399-12												
	0876	Ch col 3	X2	O			CONNECTOR, HOSE, PIPE: *** (97403) 13200E5399-20												
	0877	Ch col 3	X2	O			CONNECTOR, HOSE, PIPE: *** (97403) 13200E5399-20												

Page	Line	Action	1			2	3	4	5	6	7		8	9	10		
			Source maintenance and recoverability code								30-day DS/GS maint. allowance				Illustrations		
			Source	Maintenance	Recoverability						1-20	21-50			51-100	Figure No.	Item or symbol No.
69	1027	Ch col 3	M	O			TUBE, VINYL.*** (97403) 13200E5399-23										
	1028	Ch col 3	X2	O			UNION, HALF: *** (97403) 13200E5399-11										
	1029	Ch col 3	X2	O			UNION, HALF: *** (97403) 13200E5399-11										
	1030	Ch col 3	X2	O			VALVE, NEEDLE: *** (97403) 13200E5399-17										
	1033	Ch col 3	X2	O			VALVE, THREE WAY: *** (97403) 13200E5399-5										
70							GROUP 95—GENERAL USE STANDARDIZED PARTS 9501—BULK MATERIAL PIPE, STEEL: *** (97403) 13200E5434	4710-162-0991									
	1042	Ch col 3	P	O			PLASTIC TUBING: *** (97403) 13200E5399-24	4710-809-8149									
	1043	Ch col 3	P	O			RUBBER SHEET, SOLID: (97403) 13200E5420-1	5330-505-6611									
	1044	Ch col 3	P	O			STEEL STRIP, CARBON, HOT ROLLED: *** (97403) 13200E5419	9515-554-0893									
	1045	Ch col 3	P	O			GROUP 99—PARTS PECULIAR 9901—MULTI-LISTED PARTS CONNECTOR, HOSE, PIPE: *** (97403) 13200E5399-20										
	1053	Ch col 3	X2	O			ELBOW, HOSE:*** (97403) 13200E5399-19										
	1054	Ch col 3	X2	O			RECEPTACLE (97403) CFR40421										
	1056	Ch col 3	X2	F													

80

Page	Line	Action	1			2	3	4	5	6	7			8	9	10	
			Source maintenance and recoverability code								30-day DS/GS maint. allowance					Illustrations	
			Source	Maintenance	Recoverability						1-20	21-50	51-100				Figure No.
80	1354	Ch col 3	X2	O			CLAMP, DRUM (97403) 13200E5358										
	1355	Ch col 3	X2	O			ELBOW, LONG (97403) 13200E5350										
	1356	Ch col 3	X2	O			(97403) 13200E5353 END CAP										
	1357	Ch col 3	X2	O			(97403) 13200E5347 NOZZLE HEAD										
	1358	Ch col 3	X2	O			(97403) 13200E5342 SCREW, TOGGLE:***										
	1359	Ch col 3	X2	O			(97403) 13200E5359 PART IV GROUP 01—ENGINE 0102—CRANKSHAFT. SCREW, SELF LOCKING: ***										
82	1385	Add col 1a, chg col 2, 7c, 8, 9	P	H		5305-360-8335							2	7	4		
							(66289) PB169A GROUP 57—SPRAY EQUIPMENT COMPONENTS 5704 —SPRAY DUCTS AND MANIFOLDS MANIFOLD SPRAY AS- SEMBLY (97403) 13200E5341 CLAMP, DRUM (97403) 13200E5358 ELBOW, LONG (97403) 13200E5350 ELBOW, SHORT (97403) 13200E5353 END; CAP (97403) 13200E5347 NOZZLE HEAD (97403) 13200E5342										
86	1511	Add col 1c, chg col 3	X2	O	R												
	1512	Ch col 3	X2	O													
	1513	Ch col 3	X2	O													
	1514	Ch col 3	X2	O													
	1515	Ch col 3	X2	O													
	1516	Ch col 3	X2	O													

Page	Line	Action	1			2	3	4	5	6	7			8	9	10	
			Source maintenance and recoverability code								30-day DS/GS maint. allowance					Illustrations	Item or symbol No.
			Source	Maintenance	Recoverability						1-20	21-50	51-100				
101	1980	Ch col 1B	X2	F			BODY: *** (82254) CFR 41535-1 CLAMP ASSEMBLY: *** (82254) CFB55020 COVER: *** (82254) CFR41535-5 GASKET, LONG: *** (82254) CFA41537 GASKET, SHORT: *** (82254) CFA41538 NOZZLE HEAD ASSEMBLY: *** (82254) CFR41536 SCREW, MACHINE: *** (82254) CFA41100 WASHER, LOCK: *** (96906) MS35333-25										
	1981	Ch col 1B	X2	F													
	1982	Ch col 1B	X2	F													
	1983	Ch col 1B	P	F		5330-956-4306											
	1984	Ch col 1B	P	F		5330-925-0455											
	1985	Ch col 1B	X2	F													
	1986	Ch col 1B	X2	F													
	1987	Ch col 1B	X2	F													
							All changes, additions or deletions of Federal Stock Numbers or Manufacturers part numbers should be appropriately reflected in the parts listing and index of the manual.										

By Order of the Secretary of the Army:

W. C. WESTMORELAND,
General, United States Army,
Chief of Staff.

Official:

VERNE L. BOWERS,
Major General, United States Army,
The Adjutant General.

Distribution:

To be distributed in accordance with DA Form 12-25A (qty rqr Block No. 150), Organizational maintenance requirements for Insect and Pest Control.

Changes in force: C 2 and C 3

TM 5-3740-200-25P
C 3

Change }
No. 3 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 20 November 1972

**Organizational, Direct and General Support, and Depot
Maintenance Repair Parts and Special Tools List**

**SPRAYER, INSECTICIDE, SKID MOUNTED:
GASOLINE DRIVEN; 40 GAL PER HOUR; FOG
(CURTIS AUTOMOTIVE DEVICES MODEL CFR-40000)
FSN 3740-790-6188**

Current as of 1 November 1972

TM 5-3740-200-25P, 10 April 1967 is changed as follows:

[illegible]

By Order of the Secretary of the Army:

CREIGHTON W. ABRAMS
General, United States Army
Chief of Staff

Official:

VERNE L. BOWERS
Major General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-25A, (qty rqr block No. 150) Organizational maintenance requirements for Insect and Pest Control.

TECHNICAL MANUAL

No. 5-3740-200-25P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 10 April 1967

**Organizational, Direct And General Support, And Depot
Maintenance Reports Parts and Special Tools List**

SPRAYER, INSECTICIDE, SKID MOUNTED:

GASOLINE DRIVEN; 40 GAL PER HOUR;

FOG (CURTIS AUTOMOTIVE DEVICES MODEL CFR-40000)

FSN 3740-790-6188

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1	ix
General	2	ix
Explanation of columns	3	ix
Instructions for locating repair parts	4	xi
Abbreviations	5	xi
Special information	6	xi
Index of Federal Supply Codes	7	xi
Reporting of equipment publication improvements	8	xi
SECTION II. PRESCRIBED LOAD ALLOWANCE		
SECTION III. REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE		
Part I.		
Group 01. Engine		
0100 Engine assembly		1
0101 Crankcase, block, cylinder head		1
0102 Crankshaft		1
0103 Flywheel assembly		1
0105 Valves, camshafts and timing system		2
0106 Engine lubrication system		2
0107 Engine starting system		2
0108 Manifolds		2
03. Fuel System		
0301 Carburetor		3
0302 Fuel pumps		3
0304 Air cleaner		3
0306 Tanks, lines, fittings		4
0308 Engine speed governor and controls		5
0311 Engine starting aids		5
0312 Throttle or choke controls		5
04. Exhaust System		
0401 Muffler and pipes		6
05. Cooling System		
0502 Deflectors, shrouds		6
06. Electrical System		
0601 Generator		7
0602 Generator regulator		7

*This manual supersedes TM 5-3740-200-25P, 1 December 1961, including C1, 13 May 1963.

	Page
0603 Starting motor	7
0606 Engine safety controls	8
0607 Instrument or engine control panel	9
0612 Batteries, storage	9
0615 Radio interference suppression	10
18. Body, Cab, Hood and Hull	11
1801 Body, cab, hood	11
1808 Straps	11
22. Body, Chassis or Hull, and Accessory Items	11
2201 Canvas items	12
2210 Data plates	12
47. Gages (Non-Electrical), Weighing and Measuring Devices	12
4702 Gages, lines and fittings	12
55. Pumps	13
5500 Pump assembly	14
5505 Suction or discharge system	14
5507 Pump drive	14
57. Spray Equipment	14
5703 Air blower assembly	15
5707 Instrument panel	18
5708 Tanks, valves, lines, hoses, fittings, and liquid strainer	18
95. General Use Standardized Parts	15
9501 Bulk material	15
99. Parts Peculiar	19
9901 Multi-listed parts	19
 Part II.	
Group 01. Engine	20
0102 Crankshaft	20
0106 Engine lubrication system	20
03. Fuel System	20
0309 Fuel filters	20
06. Electrical System	21
0605 Ignition components	21
22. Body, Chassis or Hull and Accessory Items	23
2210 Data plates	23
57. Spray Equipment Components	23
5703 Air blower assembly	23
5704 Spray ducts and manifolds	23
95. General Use Standardized Parts	23
9501 Bulk material	23
 Part III.	
Group 01. Engine	24
0100 Engine assembly	24
0102 Crankshaft	24
0106 Engine lubrication system	24
03. Fuel System	24
0306 Tanks, lines, fittings	25
0309 Fuel filters	25
04. Exhaust System	25
0401 Muffler and pipes	25
06. Electrical System	25
0605 Ignition components	25
22. Body Chassis or Hull, and Accessory Items	26
2210 Data plates	26
57. Spray Equipment Components	26
5703 Air blower assembly	27
5704 Spray ducts and manifolds	27
5708 Tanks, valves, lines, hoses, fittings, and liquid strainers	27
95. General Use Standardized Parts	27
9501 Bulk material	27

Part IV.

Group 01.	Engine	
	0102 Crankshaft	28
	0106 Engine lubrication system	28
03.	Fuel System	
	0309 Fuel filters	28
06.	Electrical System	
	0605 Ignition components	29
22.	Body Chassis or Hull and Accessory Items	
	2210 Data plates	30
57.	Spray Equipment Components	
	5703 Air blower assembly	31
	5704 Spray ducts and manifolds	31
76.	Fire Fighting Equipment Components	
	7603 Fire extinguishers	31
95.	General Use Standardized Parts	
	9501 Bulk material	31

Part V.

Group 01.	Engine	
	0100 Engine assembly	32
	0102 Crankshaft	32
	0106 Engine lubrication system	32
03.	Fuel System	
	0306 Tanks, lines, fittings	32
	0309 Fuel filters	33
04.	Exhaust System	
	0401 Muffler and pipes	33
06.	Electrical System	
	0605 Ignition components	33
22.	Body Chassis or Hull and Accessory Items	
	2210 Data plates	34
57.	Spray Equipment Components	
	5703 Air blower assembly	34
	5704 Spray ducts and manifolds	34
	5708 Tanks, valves, lines hoses, fittings and liquid strainers	35

Part VI.

Group 01.	Engine	
	0101 Crankcase, block, cylinder head	36
	0102 Crankshaft	36
	0106 Engine lubrication system	36
03.	Fuel System	
	0309 Fuel filters	36
06.	Electrical System	
	0605 Ignition components	37
22.	Body Chassis or Hull and Accessory Items	
	2210 Data plates	38
57.	Spray Equipment Components	
	5703 Air blower assembly	38
	5704 Spray ducts and manifolds	38
76.	Fire Fighting Equipment Components	
	7603 Fire extinguishers	29

Part VII.

Group 01.	Engine	
	0101 Crankcase, block, cylinder head	40
	0102 Crankshaft	40
	0106 Engine lubrication system	40
03.	Fuel System	
	0309 Fuel filters	40
06.	Electrical System	
	0605 Ignition components	41

22.	Body Chassis or Hull and Accessory Items	42
2210	Data plates	42
57.	Spray Equipment Components	42
5703	Air blower assembly	42
5704	Spray ducts and manifolds	42
SECTION IV. REPAIR PARTS FOR DS, GS, AND DEPOT MAINTENANCE		
Part I.	Engine	
Group 01.	0100 Engine assembly	43
	0101 Crankcase, block, cylinder head	43
	0102 Crankshaft	44
	0103 Flywheel assembly	46
	0104 Pistons, connecting rods	46
	0105 Valves, camshafts and timing system	47
	0106 Engine lubrication system	48
	0107 Engine starting system	49
	0108 Manifolds	49
03.	Fuel System	
	0301 Carburetor	50
	0302 Fuel pump	50
	0304 Air cleaner	50
	0306 Tanks, lines, fittings	51
	0308 Engine speed governor and controls	52
	0311 Engine starting aids	53
	0312 Throttle or choke controls	53
04.	Exhaust System	
	0401 Muffler and pipes	53
05.	Cooling System	
	0502 Deflectors, shrouds	54
06.	Electrical System	
	0601 Generator	54
	0602 Generator regulator	56
	0603 Starting motor	56
	0606 Engine safety controls	58
	0607 Instrument or engine control panel	58
	0612 Batteries, storage	58
	0615 Radio interference suppression	59
15.	Frame	
	1501 Frame assembly	60
18.	Body, Cab, Hood and Hull	
	1801 Body, cab, hood	60
	1808 Straps	61
22.	Body, Chassis or Hull, and Accessory Items	
	2201 Canvas items	61
	2210 Data plates	61
47.	Gages (Non-Electrical), Weighing and Measuring Devices	
	4702 Gages, lines and fittings	62
55.	Pumps	
	5500 Pump assembly	63
	5501 Shafts, rotors	63
	5505 Suction or discharge system	64
	5507 Pump drive	64
57.	Spray Equipment	
	5703 Air blower assembly	64
	5707 Instrument panel	66
	5708 Tanks, valves, lines, hoses, fittings, and liquid strainer	67
95.	General Use Standardized Parts	
	9501 Bulk material	70
99.	Parts Peculiar	
	9901 Multi-listed parts	70

Part II.

Group 01. Engine	
0100 Engine assembly	71
0101 Crankcase, block, cylinder head	71
0102 Crankshaft	71
0105 Valves, camshafts and timing system	71
0106 Engine lubrication system	71
03. Fuel System	
0309 Fuel filters	72
05. Cooling System	
0502 Deflectors, shrouds	72
06. Electrical System	
0605 Ignition components	72
22. Body, Chassis or Hull and Accessory Items	
2210 Data plates	74
57. Spray Equipment Components	
5703 Air blower assembly	75
5704 Spray ducts and manifolds	75
95. General Use Standardized Parts	
9501 Bulk material	75

Part III.

Group 01. Engine	
0100 Engine assembly	76
0101 Crankcase, block, cylinder head	76
0102 Crankshaft	76
0105 Valves, camshafts and timing system	76
0106 Engine lubrication system	76
03. Fuel System	
0306 Tanks, lines, fittings	77
0309 Fuel filters	77
04. Exhaust System	
0401 Muffler and pipes	77
05. Cooling System	
0502 Deflectors, shrouds	77
06. Electrical System	
0605 Ignition components	78
22. Body Chassis or Hull, and Accessory Items	
2210 Data plates	80
57. Spray Equipment Components	
5703 Air blower assembly	80
5704 Spray ducts and manifolds	80
5708 Tanks, valves, lines, hoses, fittings and liquid strainers	81
95. General Use Standardized Parts	
9501 Bulk material	81

Part IV.

Group 01. Engine	
0100 Engine assembly	82
0101 Crankcase, block, cylinder head	82
0102 Crankshaft	82
0105 Valves, camshafts and timing system	82
0106 Engine lubrication system	82
03. Fuel System	
0309 Fuel filters	83
05. Cooling System	
0502 Deflectors shrouds	83
06. Electrical System	
0605 Ignition components	83
22. Body Chassis or Hull and Accessory Items	
2210 Data plates	85

	Page
57. Spray Equipment Components	
5703 Air blower assembly	86
5704 Spray ducts and manifolds	86
76. Fire Fighting Equipment Components	
7603 Fire extinguishers	86
95. General Use Standardized Parts	
9501 Bulk material	86
Part V.	
Group 01. Engine	
0100 Engine assembly	87
0101 Crankcase, block, cylinder head	87
0102 Crankshaft	87
0105 Valves, camshafts and timing system	87
0106 Engine lubrication system	87
03. Fuel System	
0306 Tanks, lines, fittings	88
0309 Fuel filters	88
04. Exhaust System	
0401 Muffler and pipes	88
05. Cooling System	
0502 Deflectors, shrouds	88
06. Electrical System	
0605 Ignition components	89
22. Body Chassis or Hull and Accessory Items	
2210 Data plates	90
57. Spray Equipment Components	
5703 Air blower assembly	91
5704 Spray ducts and manifolds	91
5708 Tanks, valves, lines hoses, fittings and liquid strainers	91
Part VI.	
Group 01. Engine	
0100 Engine assembly	92
0101 Crankcase, block, cylinder head	92
0102 Crankshaft	92
0105 Valves, camshafts and timing system	92
0106 Engine lubrication system	92
03. Fuel System	
0309 Fuel filters	93
05. Cooling System	
0502 Deflectors, shrouds	93
06. Electrical System	
0605 Ignition components	93
22. Body Chassis or Hull and Accessory Items	
2210 Data plates	95
57. Spray Equipment Components	
5703 Air blower assembly	95
5704 Spray ducts and manifolds	96
76. Fire Fighting Equipment Components	
7603 Fire extinguishers	96
Part VII.	
Group 01. Engine	
0100 Engine assembly	97
0101 Crankcase, block, cylinder head	97
0102 Crankshaft	97
0105 Valves, camshafts and timing system	97
0106 Engine lubrication system	97
03. Fuel System	
0309 Fuel filters	98
05. Cooling System	
0502 Deflector shrouds	98

	Page
06. Electrical System	
0605 Ignition components	98
22. Body Chassis or Hull and Accessory Items	
2210 Data plates	100
57. Spray Equipment Components	
5703 Air blower assembly	100
5704 Spray ducts and manifolds	101
SECTION V. FEDERAL STOCK NUMBER AND PART NUMBER INDEX	143

SECTION I

INTRODUCTION

1. Scope

This manual contains a list of repair parts required for the performance of organizational, direct support, general support, and depot maintenance of the sprayer.

2. General

This repair parts list is divided into five principal sections, including a Federal stock number index.

a. Section II, Prescribed Load Allowance List (PLA), is a consolidated listing of repair parts quantitatively allocated for initial stockage at the organizational level. This is a mandatory minimum stockage allowance.

b. Section III, Repair Parts List, is a list of repair parts authorized for the performance of maintenance at the organizational level.

c. Section IV, Repair Parts List, is a list of repair parts authorized for the performance of maintenance at direct support, general support, and depot level.

d. Section V, Federal Stock Number and Manufacturer's Part Number Index, is an index of Federal stock numbers and manufacturer's part numbers to page and manufacturer's codes.

e. Part I applies to repair parts peculiar to all end items. Part II applies to repair parts peculiar to Serial No. range 101 through 148 only. Part III applies to repair parts peculiar to Serial No. range 151 through 165 only.

Part IV applies to repair parts peculiar to Serial No. range 166 through 186 only. Part V applies to repair parts peculiar to Serial No. range 201 through 245. Part VI applies to repair parts peculiar to Serial No. range 65-301 through 65-360. Part VII applies to repair parts peculiar to Serial No. range 65-361 through 65-465.

3. Explanation of Columns

The following provides an explanation of columns in the tabular lists.

a. Source, Maintenance, and Recoverability Codes.

(1) Source Code indicates the selection status and source for the listed item. Source codes used are:

Code	Explanation
P	Applied to repair parts which are stocked in or supplied from DSA/GSA or Army supply system, and authorized for use at indicated maintenance categories.
M	Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.
A	Applied to assemblies which are not procured or stocked as such but made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories.
X1	Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or components.
X2	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
C	Applied to repair parts authorized for local procurements. If not obtainable from local procurement, such repair parts will be requisitioned through normal supply channels with a supporting statement of nonavailability from local procurement.

Note: Source code is not shown on common hardware items known to be readily available in Army supply channels and through local procurement.

- (2) Maintenance Code indicates the lowest category of maintenance authorized to maintain the listed item. The maintenance level codes are:

Code	Explanation
O	Organizational maintenance
F	Direct support maintenance
H	General support maintenance
D	Depot maintenance

- (3) Recoverability Code indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable. Recoverability code is:

Code	Explanation
R	Applied to repair parts and assemblies which are economically repairable at DSU and GSU activities and normally are furnished by supply on an exchange basis.

b. Federal Stock Number indicates the Federal stock number for the item.

c. Description column indicates the Federal item name and a brief description of the item. A five-digit manufacturer's or other service code is shown in parentheses followed by the manufacturer's part number. Repair parts quantities included in kits, sets, and assemblies that differ from the actual quantity used in the specific item, are listed in parentheses following the repair part name.

d. Unit of Issue indicates the unit used as a basis of issue, e.g., ea, pr, ft, yd, etc.

e. Quantity Incorporated in Unit Pack indicates the actual quantity contained in the unit pack.

f. Quantity Incorporated in Unit indicates the actual number of parts used in the application. A zero is shown when components of kits or sets are listed that are not applicable to the specific end item.

g. Fifteen-Day Organizational Maintenance Allowance.

- (1) The allowance columns are divided into four subcolumns. Indicated in each subcolumn is the quantity of items authorized for the number of equipments supported. Items authorized for use as required but not for initial stockage are identified with an asterisk in the allowance column.

- (2) The quantitative allowances for organizational level of maintenance represents one initial prescribed load for a 15-day period for the number of equipments supported. Units and organizations authorized additional prescribed loads will multiply the number of prescribed loads authorized by the quantity of repair parts reflected in the appropriate density column to obtain the total quantity of repair parts authorized.

- (3) Items identified by an asterisk may be requisitioned as required. Subsequent changes and/or additions to allowances will be limited to the provisions of AR 735-35. The range of items authorized will be made by this Command based upon engineering experience, demand data, or TAERS information.

- (4) Allowances are based on 600 hours of operation per year.

h. Thirty-Day DS/GS Maintenance Allowance.

- (1) The allowance columns are divided into three subcolumns. Indicated in each subcolumn is the quantity of items authorized for a number of equipments supported. Items authorized for use as required but for initial stockage are identified with an asterisk in the allowance column.

- (2) The quantitative allowances for DS/GS levels of maintenance will represent initial stockage for a 30-day period for the number of equipments supported.

i. One-Year Allowances Per 100 Equipments/Contingency Planning Purposes indicates the quantity of items required for distribution and contingency planning purposes.

j. Depot Maintenance Allowance Per 100 Equipments indicates the total quantity of items recommended for depot maintenance of 100 equipments. Items recommended for immediate use only are identified with an asterisk in the allowance column.

k. Illustration.

- (1) Figure Number indicates the figure number of the illustration in which the item is shown.
- (2) Item or Symbol Number indicates the callout number used to reference the item in the illustration.

4. Special Information

The following publications pertain to the sprayer and its components.

TM 5-3740- 200-15	Operator, Organiza- tional, Field and Depot Maintenance Manual
LO 5-3740- 200-15	Lubrication Order

5. Instructions for Locating Repair Parts

a. When Federal stock number or manufacturer's part number is unknown.

- (1) *First.* Using the index of contents, determine the functional group or subgroup, i.e., engine; engine assembly, transmission, transmission assembly, within which the repair part belongs. Locate the appropriate page in the manual and identify the part.
- (2) *Second.* Locate the repair part and the illustration figure and item number as shown in the last two columns of the repair parts listing.
- (3) *Third.* Identify the repair part on the illustration.

b. When Federal stock number or manufacturer's part number is known.

- (1) *First.* Use the index to locate the Federal stock number or manufacturer's part number. This index is arranged in alphameric sequence cross-referenced to page number and manufacturer's code.
- (2) *Second.* Refer to the appropriate page in the parts listing. Locate the repair part and the illustration figure and item number as shown in the last two columns of the parts listing.

6. Abbreviations

amp	ampere(s)
AWG	American Wire Gage
dc	direct current
dia	diameter(s)
ea	each
ft	foot(feet)
grp	group
id	inside diameter(s)
in.	inch(es)
lg	length(long)
mm	millimeter
mtg	mounting(s)
No.	number(s)
od	outside diameter
sh	sheet
thd	thread(ed)
thk	thick(ness)
thru	through
uf	microfarad(s)
v	volt(s)
w	wide(width)
w/	with

7. Index of Federal Supply Codes

Code	Manufacturers
00736	Air-Maze Corp.
01510	Miehle-Dexter Super Charger Div. of Christensen Machine Co., Inc.
04255	Weatherhead Co.
04959	Autovent Fan & Blower Div. of Nelson Herman Corp. Moline, Inc.
09058	Brown & Sharpe Mfg. Co.
11583	Champion Spark Plug Co.
19728	Prestolite Co.
22375	Fischer and Porter Co.
23838	Fyr-Fyter Co., Inc.
30327	Imperial Brass Mfg. Co.
60038	Timken Roller Bearing Co.
61976	United Specialties Co.
66289	Wisconsin Motor Corp.
70470	Astrup Company
70655	Auto Vehicle Parts Co.
70903	Belden Mfg. Co.
71176	Browning Mfg. Co., Inc.
71956	Dodge Mfg. Co.
72850	Eclipse Machine Div. of Bendix Corp.
72987	Estwing Mfg. Co.
73370	Fram Corp.
77060	Packard Electric Div. of General Motors Corp.
78480	Tillotson Mfg. Co.
79470	The Weatherhead Co.
79575	Wico Electric Co.
79960	Zenith Carburetor Div. of Bendix Corp.
80124	Vibration Eliminator Co.
81336	Chief of Engineers
82247	Spraying Systems Co., Inc.

Code	Manufacturers
82254	Curtis Dyna-Products Corp.
82696	Mansure, E. L., Co.
82796	Fairbanks Morse & Co.
82797	Erie Forge & Steel Corp.
82976	Carrier Corp.
85274	Lwyer, F. W. Mfg. Co.
86906	Schuessler, William
87373	Z & W Manufacturing Corp.
92697	Patent Scaffolding Co., Inc.
93146	Buffalo Turbine Agricultural Equipment
95875	Hallett Mfg. Co.
96906	Military Standard
97296	Arjay Machine Co.
97403	Army Engineer Research & Development Laboratories

8. Reporting of Equipment Publication Improvements

DA Form 2028 (Recommended Changes to DA Publications) will be used for reporting discrepancies and recommendations for improving this equipment publication. This form will be completed by the individual using the manual and forwarded direct to Commanding General, U. S. Army Mobility Equipment Command, AMSME-MPD, 4300 Goodfellow Blvd., St. Louis, Mo. 63120.

SECTION II

PREScribed LOAD ALLOWANCE

(1) Federal Stock Number	(2) Description	(3) 15-day org maint alw			
		(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100
	PART I				
	GROUP 01 — ENGINE				
	0100 — ENGINE ASSEMBLY				
2805-720-4773	GASKET SET: engine overhaul (66289) Q214	*	2	2	4
	GROUP 03 — FUEL SYSTEM				
	0301 — CARBURETOR				
2910-807-7153	GASKET SET, CARBURETOR (79960) C181-329	*	2	2	4
	0302 — FUEL PUMP				
2910-776-7902	PUMP, FUEL (66289) LP42C	*	*	2	2
	GROUP 06 — ELECTRICAL SYSTEM				
	0601 — GENERATOR				
3030-528-4261	BELT, V: generator drive (71946) 4L250	*	*	2	2
	0602 — GENERATOR REGULATOR				
2920-785-6393	REGULATOR, VOLTAGE (19728) VB04201ET	*	*	2	2
	0603 — STARTING MOTOR				
1015-298-8702	GASKET: bracket mtg, copper	*	*	*	2
2920-710-6107	PARTS KIT, ELECTRICAL ENGINE STARTER (19728) K1T19728-36	*	*	*	2
	0615 — RADIO INTERFERENCE SUPPRESSION				
5910-127-7252	CAPACITOR: arature terminal on regulator to shield box (81347) ESC8071CA445	*	*	*	2
	GROUP 55 — PUMPS				
	5507 — PUMP DRIVE				
3030-542-3702	BELT, V: pump drive (71176) AP26	*	*	2	2
	GROUP 57 — SPRAY EQUIPMENT				
	5703 — AIR BLOWER ASSEMBLY				

(1) Federal Stock Number	(2) Description	(3) 15-day org maint alw			
		(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100
3030-246-0152	BELT, V: blower drive, matched set of 3 (71176) BP60-3	*	*	2	2
3740-542-3717	GASKET: intake and exhaust flange (01510) 7932 GROUP 99 — PARTS PECULIAR 9901 — MULTI-LISTED PARTS	*	2	2	3
2805-641-7404	GASKET	*	2	2	3
	PART II GROUP 01 — ENGINE 0106 — ENGINE LUBRICATION SYSTEM				
5330-289-0776	WASHER, NONMETALLIC: cover screw (73370) 10076	*	*	*	2
2940-529-2738	FILTER ELEMENT, FLUID, PRESSURE: oil (73370) 6946	2	7	13	25
5330-291-3405	WASHER, NONMETALLIC (73370) 10611	2	7	13	25
	GROUP 03 — FUEL SYSTEM 0309 — FUEL FILTERS				
2910-358-4317	BOWL, SEDIMENT FUEL: glass (78480) 07759	*	*	2	2
2910-282-7557	WASHER, NONMETALLIC: bowl mtg (78480) 08227	2	2	4	8
	GROUP 06 — ELECTRICAL SYSTEM 0605 — IGNITION COMPONENTS				
2920-712-1267	REPAIR KIT, MAGNETO (81336) 79575-4	*	2	2	3
2920-293-5212	SPARK PLUG: 18mm (11583) XED16	2	3	5	10
5330-599-5356	GASKET: spark plug (11583) A676 5703 — AIR BLOWER ASSEMBLY	*	2	2	3
3740-542-3716	GASKET: element to body and top (00736) 10M06	*	*	*	2
	PART III GROUP 01 — ENGINE 0106 — ENGINE LUBRICATION SYSTEM				
5330-298-0776	WASHER, NONMETALLIC: cover screw (73370) 10076	*	*	*	2
2940-141-9025	FILTER ELEMENT (73370) C21P2	2	7	13	25
5330-599-1285	GASKET, COVER WASHER, NONMETALLIC (73370) 11582	2	7	13	25
	GROUP 03 — FUEL SYSTEM 0309 — FUEL FILTERS				
2910-354-3834	BOWL, SEDIMENT, FUEL: glass (78480) 06137	*	*	2	2
5330-187-2962	WASHER, NONMETALLIC: bowl mtg (78480) 06096	2	2	4	8

(1) Federal Stock Number	(2) Description	(3) 15-day org maint alw			
		(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100
	GROUP 06 — ELECTRICAL SYSTEM 0605 — IGNITION COMPONENTS				
2920-844-2035	REPAIR KIT, MAGNETO (82796) SK72	*	2	2	3
2920-841-1890	SPARK PLUG (11583) XMD18	2	3	5	10
5330-599-5356	GASKET: spark plug (11583) A676	*	2	2	3
	GROUP 57 — SPRAY EQUIPMENT 5703 — AIR BLOWER ASSEMBLY				
3740-542-3716	GASKET: element to body and top (00736) 10M06	*	*	*	2
	PART IV GROUP 01 — ENGINE 0106 — ENGINE LUBRICATION SYSTEM				
5330-298-0776	WASHER, NONMETALLIC: cover screw (73370) 10076	*	*	*	2
2940-529-2738	FILTER ELEMENT, FLUID, PRESSURE: oil (73370) 6946	2	7	13	25
5330-291-3405	WASHER, NONMETALLIC: cover (73370) 10611	2	7	13	25
	GROUP 03 — FUEL SYSTEM 0309 — FUEL FILTERS				
2910-358-4317	BOWL, SEDIMENT, FUEL: glass (78480) 07759	*	*	2	2
2910-282-7557	WASHER, NONMETALLIC: bowl mtg (78480) 08227	2	2	4	8
	GROUP 06 — ELECTRICAL SYSTEM 0605 — IGNITION COMPONENTS				
2920-712-1267	REPAIR KIT, MAGNETO (81336) 79575-4	*	2	2	3
2920-293-5212	SPARK PLUG: 18 mm (11583) XED16	2	3	5	10
5330-599-5356	GASKET: spark plug (11583) A676	*	2	2	3
	GROUP 57—SPRAY EQUIPMENT 5703—AIR BLOWER ASSEMBLY				
3740-542-3716	GASKET: element to body and top (00736) 10M06	*	*	*	2
	PART V GROUP 01—ENGINE 0106—ENGINE LUBRICATION SYSTEM				
5330-298-0776	WASHER, NONMETALLIC: cover screw (73370) 10076	*	*	*	2
2940-141-9025	FILTER ELEMENT (73370) C21P2	2	7	13	25
5330-599-1285	GASKET, COVER WASHER, NONMETALLIC (73370) 11582	2	7	13	25
	GROUP 03—FUEL SYSTEM 0309—FUEL FILTERS				
2910-354-3834	BOWL, SEDIMENT: glass	*	*	2	2
5330-187-2962	WASHER, NONMETALLIC (78480) 06096	2	2	4	8

(1) Federal Stock Number	(2) Description	(3) 15-day org maint alw			
		(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100
	GROUP 06—ELECTRICAL SYSTEM 0605—IGNITION COMPONENTS				
2920-844-2035	REPAIR KIT, MAGNETO (82796) SK72	*	2	2	3
2920-841-1890	SPARK PLUG (11583) XMD18	2	3	5	10
5330-599-5356	GASKET: spark plug (11583) A676	*	2	2	3
	PART VI GROUP 01—ENGINE				
	0106—ENGINE LUBRICATION SYSTEM				
5330-298-0776	WASHER, NONMETALLIC: cover screw (73370) 10076	*	*	*	2
2940-141-9025	FILTER ELEMENT (73370) C21P2	2	7	13	25
5330-599-1285	GASKET, COVER WASHER, NONMETALLIC (73370) 11582	2	7	13	25
	GROUP 03—FUEL SYSTEM 0309—FUEL FILTERS				
2910-354-3834	BOWL, SEDIMENT: glass (78480) 06137	*	*	2	2
5330-187-2962	WASHER, NONMETALLIC: bowl mtg (78480) 06096	2	2	4	8
	GROUP 06—ELECTRICAL SYSTEM 0605—IGNITION COMPONENTS				
2920-844-2035	REPAIR KIT, MAGNETO (82796) SK72	*	2	2	3
2920-841-1890	SPARK PLUG (11583) XMD18	2	3	5	10
5330-599-5356	GASKET: spark plug (11583) A676	*	2	2	3
	PART VII GROUP 01—ENGINE				
	0106—ENGINE LUBRICATION SYSTEM				
5330-298-0776	WASHER, NONMETALLIC: cover screw (73370) 10076	*	*	*	2
2940-141-9025	FILTER ELEMENT (73370) C21P2	2	7	13	25
5330-599-1285	GASKET, COVER WASHER, NONMETALLIC (73370) 11582	2	7	13	25
	GROUP 03—FUEL SYSTEM 0309—FUEL FILTERS				
2910-354-3834	BOWL, SEDIMENT: glass (78480) 06137	*	*	2	2
5330-187-2962	WASHER, NONMETALLIC: bowl mtg (78480) 06096	2	2	4	8
	GROUP 06—ELECTRICAL SYSTEM 0605—IGNITION COMPONENTS				
2920-844-2035	REPAIR KIT, MAGNETO (82796) SK72	*	2	2	3
2920-841-1890	SPARK PLUG (11583) XMD18	2	3	5	10
5330-599-5356	GASKET: spark plug (11583) A676	*	2	2	3

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.			CODE	PART NUMBER			(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(c) FIG. NO.	(b) ITEM OR SYM. NO.
0001				SECTION III - REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE PART I										
0002				GROUP 01 - ENGINE										
0002A				0100 - ENGINE ASSEMBLY										
0003	P	0	2805-720-4773	GASKET SET: ENGINE OVERHAUL	EA	66289 Q21A		1	*	2				
0022				0101 - CRANKCASE, BLOCK, CYLINDER HEAD										
0028		0	5305-049-9608	BOLT, MACHINE: CYLINDER HEAD MTG	EA	66289 XD19		15	*	*	*	*	2	18
0029		0	5306-207-9166	BOLT, MACHINE: CYLINDER HEAD MTG	EA	66289 XD21		1	*	*	*	*	2	12
0030		0	5306-021-5377	BOLT, MACHINE: SAFETY SWITCH AND CYLINDER HEAD	EA	66289 PA332		1	*	*	*	*	2	9
0038		0	5315-753-3893	PIN, SPRING: PRIMER STOP	EA	66289 PF18		1	*	*	*	*	1	29
0041		0	4730-505-2399	PLUG, PIPE: CRANKCASE OIL HOLES	EA	66289 PM163A		3	*	*	*	*	1	26
0044	X2	0	2910-317-5613	SPRING, HELICAL, TORSION: PRIMER HANDLE	EA	66289 PH17A		1	*	*	*	*	1	30
0047		0	5310-637-2400	WASHER, FLAT: CYLINDER HEAD MTG	EA	66289 AB10083S1		17	*	*	*	*	2	10
0051	X2	0	2805-718-6972	CYLINDER HEAD	EA	66289 PH03A3		1	*	*	*	*	2	8
0052	X1		5310-502-3078	INSERT, SPARK PLUG	EA			2	*	*	*	*	2	7
0053				0102 - CRANKSHAFT										
0054		0	5305-206-1071	BOLT, MACHINE: BLOWER DRIVE SHEAVE	EA	66289 XD17		3	*	*	*	*		2
0055	X2	0		BUSHING, FLANGED: BLOWER DRIVE SHEAVE, 1 7/16 IN. ID	EA	82254 CFR0089		1	*	*	*	*		3
0068		0	5315-952-3107	KEY, MACHINE: BLOWER DRIVE SHEAVE	EA	66289 UC75FS1		1	*	*	*	*		8
0070	X2	0	5310-692-8335	NUT ASSEMBLY, CRANK NUT, CRANK	EA	66289 UC75F		1	*	*	*	*		14
0072	X1	0	5315-276-5762	PIN, SPRING: CRANK NUT	EA	66289 PA333		1	*	*	*	*		13
0073		0	5315-271-3012	PIN, SPRING: SPRAY PUMP SHEAVE	EA			1	*	*	*	*		12
0074		0		SHEAVE, CRANKSHAFT: SPRAY PUMP	EA	81336 B13200E5A35		1	*	*	*	*		21
0082	X2	0	5310-641-9308	WASHER, LOCK: CRANK NUT	EA	66289 PE59		1	*	*	*	*		1
0087		0		0103 - FLYWHEEL ASSEMBLY										18
0090														
0091		0	5305-206-1071	BOLT, MACHINE: GENERATOR PULLEY TO FLYWHEEL	EA	66289 XD17		4	*	*	*	*		2
0095	X2	0		PULLEY, GENERATOR DRIVE	EA	66289 MD292-A		1	*	*	*	*		20
0096		0	5310-012-0214	WASHER, LOCK: GENERATOR PULLEY TO FLYWHEEL SCREW	EA			4	*	*	*	*		8

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
	SOURCE	MAINT.						RECOV.	(a)	(b)	(c)	(d)	(a)	(b)																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																									</

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE			(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	SOURCE	MAINT.	RECOV.			MANUFACTURER'S		(a) 1-5			(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR NO.	
						CODE	PART NUMBER									
0232	X1			2805-366-6270	GASKET: INTAKE MANIFOLD MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100)	66289 QB75	EA			1					16	6
0233	X2	0		2805-353-5889	MANIFOLD, EXHAUST	66289 LD242	EA			1	*	*	*	*	17	6
0234	X2	0		2805-776-8111	MANIFOLD, INTAKE	66289 LC266A	EA			1	*	*	*	*	16	5
0235		0		5310-012-6189	NUT, PLAIN, HEXAGON: INTAKE AND EXHAUST		EA			2	*	*	*	*	16	1
0236		0		4730-187-4200	MANIFOLD MTG	66289 XK1	EA			1	*	*	*	*	16	28
0236A		0		5307-011-2572	PLUG, PIPE: INTAKE MANIFOLD	66289 PC110	EA			2	*	*	*	*	6	12
0237		0		5310-637-9541	STUD, PLAIN: MANIFOLD MTG WASHER, LOCK: INTAKE AND EXHAUST MANIFOLD MTG		EA			2	*	*	*	*	16	2
0238					GROUP 03 - FUEL SYSTEM											
0238A					0301 - CARBURETOR											
0239		0		5306-018-0078	BOLT, MACHINE: CARBURETOR MTG		EA			2	*	*	*	*	16	4
0240	P	0		2910-715-5328	CARBURETOR, FLOAT (INCLUDES COMPONENTS OF GASKET SET, STOCK No. 2910-807-7153)	66289 L63L	EA			1	*	*	*	*	16	23
0241		0		4730-287-3281	PLUG, PIPE: CARBURETOR BOWL DRAIN		EA			1	*	*	*	*	16	22
0242	X1			2910-358-4787	GASKET: CARBURETOR MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5847)	66289 QC58A	EA			1	*	*	*	*	16	26
0243	P	0		2910-807-7153	GASKET SET, CARBURETOR	79960 C181-329	EA			1	*	2	2	4	16	24
0244	X1				GASKET: BOWL TO BODY	79960 C142-74	EA			1	*	*	*	*	16	29
0249		0		5310-596-4911	WASHER, LOCK: CARBURETOR MTG	66289 PE4	EA			2	*	*	*	*	16	
0250					0302 - FUEL PUMPS											
0251	X1			2910-776-7900	GASKET: FUEL PUMP MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5845)	66289 QD670	EA			1					16	10
0252	P	0		2910-776-7902	PUMP, FUEL	66289 LP42C	EA			1	*	*	*	*	16	9
0253		0		5305-068-0502	SCREW, CAP, HEXAGON HEAD: FUEL PUMP MTG		EA			2	*	*	*	*	16	15
0254		0		5310-261-7341	WASHER, LOCK: FUEL PUMP MTG	66289 PE3	EA			2	*	*	*	*	16	14
0255					0304 - AIR CLEANER											
0256	X2	0		2940-695-8797	AIR, CLEANER	66289 LO-83	EA			1	*	*	*	*	12	7
0257	X1				CUP ASSEMBLY, OIL	61976 176B8	EA			1					12	5
0258	X1				FILTER AND CAP	61976 179B3	EA			1					12	3

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	SOURCE	MAINT. CODE						RECOV. CODE	(a)	(b)	(c)	(d)	(a)	(b)
0259	P	O	5330-292-0320	GASKET: CAP AND FILTER MTG, FIBER	EA		1	*	*	*	*	12	4	
0260	P	O	2940-366-9747	GASKET: FILTER MTG, CORK	EA		1	*	*	*	*	12	6	
0261	O	O	5306-531-1798	BOLT, MACHINE: BRACKET MTG	EA		2	*	*	*	*	12	10	
0262	X2	O	2940-374-3084	BRACKET ASSEMBLY, AIR CLEANER	EA		1	*	*	*	*	12	9	
0263	X2	O	4730-202-7761	CLAMP, HOSE: HOSE TO CARBURETOR RETAINING	EA		2	*	*	*	*	12	15	
0264	X1	O	2940-774-4747	GASKET: AIR CLEANER BRACKET MTG (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, SEE GROUP 0100) (CAN BE MANUFACTURED FROM PAPER, Stock No. 5330-233-5816)	EA		1	*	*	*	*	12	14	
0265	M	O		HOSE, PREFORMED, RUBBER: AIR CLEANER TO CARBURETOR MANUFACTURE FROM: HOSE, RUBBER (12 IN. REQUIRED)	EA		1					12	16	
0265A	P	O	4720-218-5644	NUT, PLAIN, WING: AIR CLEANER COVER, SELF-LOCKING	FT			SEE SRP 95D1						
0266	O	O	5310-366-6163	STUD: AIR CLEANER MTG STEEL	EA		1	*	*	*	*	12	1	
0267	O	O	5307-025-7993	WASHER, LOCK: AIR CLEANER COVER MTG	EA		1	*	*	*	*	12	8	
0268	O	O	5310-543-2795	WASHER, LOCK: BRACKET MTG	EA		1	*	*	*	*	12	2	
0269	O	O	5310-596-4911		EA		2	*	*	*	*	12	11	
0270				0306 - TANKS, LINES, FITTINGS										
0271	O	O	4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: CARBURETOR TO FUEL LINE	EA		1	*	*	*	*	16	13	
0272	O	O	4730-640-5832	ELBOW, PIPE TO TUBE: FUEL LINE TO FUEL PUMP	EA		1	*	*	*	*	16	11	
0273	O	O	4730-814-4132	ELBOW, PIPE TO TUBE: TANK TO STARTER LINE, FUEL: FUEL PUMP TO CARBURETOR	EA		1	*	*	*	*	16	7	
0274	M	O		MANUFACTURE FROM: NUT, TUBE COUPLING	EA		2	*	*	*	*	16	12	
0274A	X2	O	4730-011-6452	TUBE, COPPER (8 IN. REQUIRED)	EA									
0274B	P	O	4710-277-5525	LINE, FUEL, PLASTIC: TEFLON, 3/16 IN. ID, 1/4 IN. OD, 1/32 WALL THICK, 53 IN. LG	EA		1	*	*	*	*	13	2	
0275	P	O	4710-872-1781	MOUNT, FUEL TANK	EA		1	*	*	*	*	13	11	
0276	X2	O	4730-277-5575	NIPPLE, PIPE: FUEL STRAINER TO FUEL PUMP	EA		1	*	*	*	*	16	8	
0277	O	O	5310-584-5005	NUT, PLAIN, HEXAGON: STRAP CLAMPING AND TANK MTG	EA		6	*	*	*	*	13	9	
0278	O	O	5305-068-0502	SCREW, CAP, HEXAGON HEAD: TANK MOUNT TO FRAME	EA		4	*	*	*	*	13	10	
0279	O	O	5305-988-1170	SCREW, MACHINE: FUEL TANK STRAP CLAMPING	EA		2	*	*	*	*	13	7	
0280	O	O	2910-816-4057	STRAP, STEEL: FUEL TANK HOLD DOWN	EA		2	*	*	*	*	13	6	
0281	X2	O		TANK, FUEL: GASOLINE	EA		1	*	*	*	*	13	5	
0282	X2	O	2910-580-0607	CAP, FUEL TANK	EA		1	*	*	*	*	13	3	
0283	X2	O	5330-582-1084	WASHER, NONMETALLIC: FUEL TANK CAP	EA		1	*	*	*	*	13	4	
0284	P	O	4730-011-8831	PLUG, PIPE: TANK DRAIN	EA		1	*	*	*	*	13	12	

LINE NO.	SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION		(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
									(a)	(b)	(c)	(d)	(a)	(b)
	(a)	(b)							1-5	6-20	21-50	51-100	FIG. NO.	ITEM OR SYM. NO.
0286	M	O				EA		1					13	1
0286A		O	4730-814-1132	TUBE, SYPHON: FUEL TANK	82254 CFA40045	EA		1						
0286B	P	O	4710-277-5525	MANUFACTURE FROM:	30327 269P	EA		1	*			*		
0287		O	5310-527-3289	ELBOW, PIPE TO TUBE		FT			SEE GRP 9501					
0288				TUBE, COPPER (12 IN. REQUIRED)		EA		6	*			*	13	8
0289	X2	O		WASHER, LOCK: TANK MOUNT TO FRAME AND STRAP CLAMP SCREW		EA		1	*			*		
0290	M	O	2990-374-3163	0308 - ENGINE SPEED GOVERNOR AND CONTROLS	66289 TT66 82254 CFA40829	EA		1	*			*	15	12
0290A	P	O	2990-085-9035	CONTROL ASSEMBLY, GOVERNOR		EA		1	*			*		
0291	X2	O	3750-678-6664	CHAIN, SINGLE JACK		EA		1	*			*	15	14
0292	X2	O	2805-536-8835	MANUFACTURE FROM:	66289 VE542B	EA		1	*			*	15	17
0293	X2	O	5310-353-5895	CHAIN, WELDLESS (10 IN. REQUIRED)	66289 VE527M	EA		1	*			*	15	8
0294		O	5315-839-2325	COLLAR ASSEMBLY	66289 VB134C	EA		1	*			*	15	7
0295		O	5315-012-1224	CONTROL, GOVERNOR	66289 PD173A	EA		3	*			*	15	2
0296		O	5315-366-6291	LEVER GOVERNOR CONTROL	66289 X1-1	EA		1	*			*	15	11
0297		O	5315-272-6827	NUT, SLEEVE: ADJUSTING	66289 X1-7	EA		1	*			*	15	6
0298		O		PIN, COTTER: CHAIN CONTROL, LEVER PIN SCREW PIN	66289 TC368A	EA		1	*			*	15	3
0299	X2	O	5305-012-2159	PIN, COTTER: IN LEVER CHAIN END	66289 P1-115E	EA		1	*			*	15	5
0300		O	5305-012-2159	PIN, STRAIGHT, HEADLESS: GOVERNOR CONTROL LEVER	66289 PK121	EA		1	*			*	15	10
0301		O	5305-012-2159	PIN, STRAIGHT, THREADED: GOVERNOR ADJUSTING	66289 XE61	EA		1	*			*	15	13
0302	X2	O	5305-012-2159	RETAINER, SPRING	66289 PM111-1	EA		1	*			*	15	4
0303		O	5310-366-6294	SCREW, MACHINE: FOR COTTER PIN "H" LEVER	66289 PH77	EA		1	*			*	15	9
0304	P	O	2990-732-1179	SETScrew: COLLAR STOP	66289 T96DS1	EA		1	*			*	15	14
0317		O	4730-585-2359	SPRING, HELICAL, COMPRESSION: SCREW ADJUSTING	66289 PF18	EA		1	*			*	15	19
0321		O	5305-071-2237	WASHER, FLAT		EA		2	*			*	15	7
0322		O	5305-068-0502	GOVERNOR ASSEMBLY		EA		2	*			*	15	17
0325	X2	O	2990-739-9930	PLUG, PIPE: GOVERNOR HOUSING		EA		1	*			*	15	1
0326		O	5310-543-2705	SCREW, CAP, HEXAGON HEAD: GOVERNOR MTG	66289 PM75A	EA		4	*			*	15	6
0335				SPRING, GOVERNOR CONTROL		EA		1	*			*		
0336	X2	O	2910-776-7903	WASHER, LOCK: GOVERNOR MTG		EA		1	*			*	1	32
0337	X2	O	5330-542-1420	0311 - ENGINE STARTING AIDS	66289 TA126	EA		1	*			*	1	31
0338				SHAFT ASSEMBLY, PRIMING		EA		1	*			*		
0339	X2	O	2990-294-6749	PACKING, PREFORMED: FUEL PUMP PRIMING SHAFT	66289 JK50	EA		1	*			*	15	16
				0312 - THROTTLE OR CHOKE CONTROLS		EA		1	*			*		
				CONTROL ASSEMBLY, PUSH-PULL: CHOKE	66289 VE693	EA		1	*			*		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a) SOURCE	(b) MAIN			(c) RECOV.	CODE			PART NUMBER	(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM NO. OR SYM.
0340		0	5310-010-7823	NUT, STAMPED: BUSHING RETAINER	EA			1	*	*	*	*	15	15	
0341		0	5315-828-8190	PIN, COTTER: GOVERNOR CONTROL ROD TO CARBURETOR	EA			1	*	*	*	*	16	27	
0342	X2	0		ROD, THROTTLE: CARBURETOR TO GOVERNOR	EA			1	*	*	*	*	16	25	
0343				GROUP 04 - EXHAUST SYSTEM											
0343A				0401 - MUFFLER AND PIPES											
0344	X2	0		BRACKET, MUFFLER	EA			1	*	*	*	*			
0345		0	5306-012-6078	BOLT, MACHINE: LOWER SUPPORT TO MUFFLER BRACKET	EA			2	*	*	*	*	17	8	
0346	X2	0		CAP, SPRING: LOWER SUPPORT CLAMP TO MUFFLER BRACKET	EA			4	*	*	*	*	17	9	
0347	X1			CLAMP, SUPPORT: LOWER	EA			1	*	*	*	*	17	17	
0348	X1			CLAMP, SUPPORT: UPPER	EA			1	*	*	*	*	17	1	
0349		0	5310-584-5005	NUT, PLAIN, HEXAGON: UPPER CLAMP TO LOWER CLAMP	EA			2	*	*	*	*	17	14	
0350		0	5310-045-1005	NUT, SELF-LOCKING, HEXAGON: LOWER SUPPORT TO MUFFLER BRACKET	EA			2	*	*	*	*	17	16	
0351		0	5305-068-0500	SCREW, CAP, HEXAGON HEAD: UPPER CLAMP TO LOWER CLAMP	EA			2	*	*	*	*	17	2	
0352	X2	0		SPRING, HELICAL, COMPRESSION: LOWER SUPPORT TO MUFFLER BRACKET	EA			4	*	*	*	*	17	10	
0353	X1			SUPPORT, MUFFLER BRACKET	EA			1	*	*	*	*	17	11	
0354		0	5310-527-3289	WASHER, LOCK: UPPER CLAMP TO LOWER CLAMP	EA			2	*	*	*	*	17	15	
0355		0	4730-221-3928	ELBOW, PIPE: EXHAUST PIPE TO MUFFLER	EA			1	*	*	*	*	17	4	
0356	P	0	2990-141-9229	MUFFLER, EXHAUST	EA			1	*	*	*	*	17	3	
0357		0	4730-278-3358	PLUG, PIPE: MUFFLER DRAIN	EA			1	*	*	*	*	17	18	
0358	M	0		PIPE, EXHAUST	EA			1	*	*	*	*	17	5	
0358A	P	0	4710-162-0991	MANUFACTURE FROM: PIPE, STEEL (1 1/4 IN. REQUIRED)	EA			2	SEE ERP 95D1	*	*	*			
0359		0	5305-068-0502	SCREW, CAP, HEXAGON HEAD: MUFFLER SUPPORT TO CANOPY	EA			2	*	*	*	*	17	13	
0360		0	5310-595-5599	WASHER, FLAT: SUPPORT TO CANOPY MTG	EA			2	*	*	*	*	17	12	
0361				GROUP 05 - COOLING SYSTEM											
0361A				0502 - DEFLECTORS, SHROUDS											
0363	X2	0		CLIP, CABLE: SHIELD BOX TO AMMETER LEAD	EA			1	*	*	*	*	4	9	
0364	X2	0		COVER, AIR SHROUD	EA			1	*	*	*	*	18	3	
0365	X2	0	2990-776-8106	DEFLECTOR, HEAT	EA			1	*	*	*	*	18	6	
0366	X2	0		SCREEN, FLYWHEEL	EA			1	*	*	*	*	4	19	
0367		0	5305-988-1723	SCREW, MACHINE: AIR SHROUD TO BLOCK	EA			2	*	*	*	*	18	7	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a) SOURCE	(b) MAIN						(c) RECOV.	(d)	(e)	(f)	(g)	(h)	
0368		0		5305-988-1726	SCREW, MACHINE: FLYWHEEL SCREEN MTG	EA	4	*	*	*	*	*	4	11
0369		0		5305-988-1721	SCREW, MACHINE: SHROUD MTG	EA	11	*	*	*	*	*	18	2
0370		0		5305-988-1725	SCREW, MACHINE: SHROUD TO BLOCK	EA	1	*	*	*	*	*	18	5
0371	X2	0			SHROUD, CYLINDER	EA	1	*	*	*	*	*	18	1
0372		0		5310-543-2705	WASHER, LOCK: FLYWHEEL SCREEN MTG	EA	4	*	*	*	*	*	4	10
0374		0		5310-261-7341	WASHER, LOCK: SHROUD MTG	EA	13	*	*	*	*	*	18	4
0376				GROUP 06 - ELECTRICAL SYSTEM										
0376A				0601 - GENERATOR										
0377	X2	0		3030-528-4261	ARM, STABILIZER: GENERATOR ADJUSTING	EA	1	*	*	*	*	*	19	26
0378	P	0		5306-680-6004	BELT, V: GENERATOR DRIVE	EA	1	*	*	2	*	*	19	20
0379		0			BOLT, MACHINE: ADJUSTING ARM TO GENERATOR AND FRAME			*	*	*	*	*		
0380		0		5305-206-1071	BOLT, MACHINE: GENERATOR MTG	EA	2	*	*	*	*	*	19	27
0381	P	0	R	2920-861-1320	GENERATOR, BATTERY CHARGING (INCLUDES COMPONENTS OF REPAIR, STOCK No. 2920-843-6741)	EA	2	*	*	*	*	*	19	1
0432		0		5310-045-1005	NUT, SELF-LOCKING, HEXAGON: GENERATOR MOUNTING	EA	2	*	*	*	*	*	19	8
0439	X2	0			WASHER, CLAMP: GENERATOR TENSION ADJUSTING	EA	1	*	*	*	*	*	19	28
0440	X2	0			WASHER, FLAT: GENERATOR MTG	EA	1	*	*	*	*	*	19	7
0441		0		5310-639-8061	WASHER, LOCK: GENERATOR MTG	EA	4	*	*	*	*	*	19	2
0442					0602 - GENERATOR REGULATOR									
0443		0		5310-800-5282	NUT, PLAIN, HEXAGON: REGULATOR	EA	2	*	*	*	*	*	26	17
0444	P	0		2920-785-6393	REGULATOR, VOLTAGE	EA	1	*	*	2	*	*	26	4
0445		0		5305-044-3507	SCREW, MACHINE: REGULATOR	EA	2	*	*	*	*	*	26	14
0446		0		5305-988-1725	SCREW, MACHINE: REGULATOR A.D. BOX MTG	EA	2	*	*	*	*	*	26	19
0447		0		5310-527-3289	WASHER, LOCK: REGULATOR MTG	EA	4	*	*	*	*	*	26	18
0448		0		5310-655-6314	WASHER, LOCK: REGULATOR MTG	EA	4	*	*	*	*	*	26	16
0449					0603 - STARTING MOTOR									
0450	X2	0			BRACKET, STARTER SUPPORT	EA	1	*	*	*	*	*	21	3
0451	X2	0			CABLE, ELECTRICAL: STARTER TO STARTER SWITCH	EA	1	*	*	*	*	*	21	9
0452	P	0		1015-298-8702	GASKET: BRACKET MTG, COPPER	EA	2	*	*	*	*	*	21	2
0453	P	0	R	2920-555-6315	MOTOR ASSEMBLY, STARTING 12 VOLT (INCLUDES COMPONENTS OF PARTS KIT, STOCK No. 2920-710-6107)	EA	1	*	*	*	*	*	21	
0454	X1			2920-505-5108	ARMATURE, STARTER	EA	1						21	14
0455	X1			2920-353-7422	BAND, COVER ELECTRICAL BRUSH: STARTING MOTOR	EA	1						21	11

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION					
	SOURCE	MAINT. RECOV.						(a)	(b)	(c)	(d)	(a)	(b)	(c)	(d)	FIG. NO.	ITEM NO.
				MANUFACTURER'S													
				CODE	PART NUMBER												
0595				0615 - RADIO INTERFERENCE SUPPRESSION													
0596	P	O		5910-127-752	EA	1		*	*				2	26	15		
0597	M	O			EA	1								26	10		
0597A	P	O		2920-986-9691	EA	2		SEE GRP 9501									
0597B	P	O		6145-164-7033	EA	1		SEE GRP 9501									
0598	X2	O			EA	1		*	*			*	*	26	11		
0599	X2	O			EA	1		*	*			*	*	26	12		
0600	M	O			EA	1								26	22		
0600A	P	O		5940-321-9299	EA	2		SEE GRP 9501									
0600B	P	O		6145-164-7033	EA	1		SEE GRP 9501				*	*	26	17		
0601	O	O		5310-800-5282	EA	1		*	*			*	*	26	14		
0602	O	O		5305-044-3507	EA	2		*	*			*	*	26	19		
0603	O	O		5305-988-1725	EA	1		*	*			*	*	26			
0604	X2	O		2920-627-0946	EA	2		*	*			*	*	26	13		
0605	X2	O		2920-654-3703	EA	1								26	8		
0606	X1	O		5910-677-5348	EA	1		*	*			*	*	26	7		
0607	P	O			EA	1								26	1		
0608	X1			2920-962-4598	EA	1								26			
0609	M	O		2920-986-9691	EA	1								26	5		
0609A	P	O		2920-986-9691	EA	2		SEE GRP 9501						26			
0609B	P	O		6145-295-0804	EA	2		SEE GRP 9501				*	*	26	21		
0610	X2	O			EA	4		*	*			*	*	26	20		
0611	O	O		5310-333-6117	EA	4		*	*			*	*	26	2		
0612	O	O		5305-012-0687	EA	4		*	*			*	*	26			
0613	O	O		5305-013-1899	EA	4		*	*			*	*	26	9		
0614	O	O		5310-655-6314	EA	2		*	*			*	*	26	16		
0615	O	O		5310-527-3288	EA	4		*	*			*	*	26	3		
0616	O	O		5310-013-8526	EA	8		*	*			*	*	26	8		
0617	O	O		5310-527-3289	EA	2		*	*			*	*	26	18		

LINE NO.	(1) SOURCE, MAINT. AND RECV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION					
	(a) SOURCE	(b) MAINT.						(c) RECV.	(d) RECV.	(a)	(b)	(c)	(d)	(a)	(b)		
																CODE	PART NUMBER
0629				GROUP 18 - BODY, CAB, HOOD AND HULL													
0629A				1801 - BODY, CAB, HOOD													
0630				CANOPY ASSEMBLY	EA		1										28
0631	X2	0		DECK PLATE	EA		1										28
0632	X2	0		FLANGE, MUFFLER	EA		1										28
0633			5310-58A-5005	NUT, PLAIN, HEXAGON: FLANGE MTG	EA		4										28
0634			5305-068-0502	SCREW, MACHINE: FLANGE MTG	EA		4										28
0635			5310-527-3289	WASHER, LOCK: FLANGE MTG	EA		4										28
0636				PANEL, FRONT	EA		1										28
0637	X2	0		GROMMET, FRONT PANEL	EA		8										28
0638	X2	0		RETAINER, FRONT PANEL	EA		8										28
0639	X2	0		STUD, FRONT PANEL	EA		8										28
0640	X2	0		PANEL, REAR	EA		1										28
0641	X2	0		GROMMET, REAR PANEL	EA		8										28
0642	X2	0		RETAINER, REAR PANEL	EA		8										28
0643	X2	0		STUD, REAR PANEL	EA		8										28
0644	X2	0		RECEPTACLE: PANEL LATCHING	EA		14		SEE GRP 9901								28
0645			5320-118-1759	RIVET, SOLID: RECEPTACLE MTG	EA		28										28
0646	X2	0		STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	EA		5		SEE GRP 1808								28
0647	X2	0		STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	EA		1		SEE GRP 1808								28
0648	X2	0		STRAP, HOLD DOWN: MANIFOLD SUPPORT	EA		1		SEE GRP 1808								28
0649			5325-281-3993	STUD, SNAP, FASTENER: CURTAIN	EA		18										28
0650			5305-639-8115	SCREW, CAP, HEXAGON HEAD: CANOPY TO FRAME	EA		8										28
0651			5305-012-0697	SCREW, MACHINE: CANOPY TO FRAME	EA		4										28
0652				1808 - STRAPS													
0653				STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	EA		2										28
0654	X2	0		STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	EA		1										28
0655	X2	0		STRAP, HOLD DOWN: MANIFOLD TO CANOPY	EA		1										28
0656				GROUP 22 - BODY, CHASSIS OR HULL, AND ACCESSORY ITEMS													
0656A				2201 - CANVAS ITEMS													
0657				CURTAIN ASSEMBLY	EA		2										28
0658	M	0	9320-771-1512	SHIM: CURTAIN STRIP TO DECK PLATE	EA		2										28
0658A	P	0	5330-505-6611	MANUFACTURE FROM: RUBBER SHEET, SOLID (16 IN. REQUIRED FOR EACH SHIM)	FT				SEE GRP 9901								

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
0659	M	O	9320-771-1513	SHIM: CURTAIN STRIP TO DECK PLATE MANUFACTURE FROM: RUBBER SHEET, SOLID (9 IN. REQUIRED FOR EACH SHIM)	EA		4	SEE GRP 9501				28	24
0659A	P	O	5330-505-6611	STRIP, CURTAIN MANUFACTURE FROM: STEEL, STRIP, CARBON, HOT ROLLED (3 FT 1 IN. REQUIRED FOR EACH STRIP)	FT		2	SEE GRP 9501				28	7
0660	M	O	3740-971-1418	NUT, PLAIN, HEXAGON: CURTAIN MTG	EA		26	*	*	*	*	28	26
0660A	P	O	9515-55A-0893	RECEPTACLE: CURTAIN HOLD DOWN STRAP	EA		13	*	*	*	*	28	18
0661	X2	O	5310-58A-5005	RIVET, SOLID: RECEPTACLE MTG	EA		26	*	*	*	*	28	16
0662	O	O	5320-118-1759	SCREW, CAP, HEXAGON HEAD: CURTAIN MTG	EA		26	*	*	*	*	28	5
0663	O	O	5305-068-0510	WASHER, LOCK: CURTAIN MTG	EA		26	*	*	*	*	28	25
0665	O	O	5310-527-3289	2210 - DATA PLATES									
0666				LABEL SET, IDENTIFICATION	EA		1	*	*	*	*		
0667	X2	O		PLATE, IDENTIFICATION: AIR PRESSURE VALVE	EA		1	*	*	*	*		
0668	X2	O		PLATE, IDENTIFICATION: BY-PASS	EA		2	*	*	*	*		
0669	X2	O		PLATE, IDENTIFICATION: FLOW CONTROL	EA		1	*	*	*	*		
0672	X2	O		PLATE, IDENTIFICATION: INSECTICIDE	EA		1	*	*	*	*		
0673	X2	O		PRESSURE	EA		1	*	*	*	*		
0674	X2	O		PLATE, IDENTIFICATION: INTAKE	EA		1	*	*	*	*		
0675	X2	O		PLATE, IDENTIFICATION: NOZZLE	EA		1	*	*	*	*		
0676	X2	O		PLATE, INSTRUCTION: ON AND OFF	EA		1	*	*	*	*		
0679	X2	O	2920-447-9295	PLATE, NAME: BLOWER	EA		14	*	*	*	*		
0681	X2	O	5320-117-7106	RIVET, SOLID: IDENTIFICATION PLATES MTG	EA		6	*	*	*	*		
0682	X2	O		SCREW, DRIVE: BLOWER NAMEPLATE MTG	EA		8	*	*	*	*		
0685	O	O		SCREW, TAPPING, THREAD CUTTING: PLATE MOUNTING	EA			*	*	*	*		
0687				GROUP 47 - GAGES (NON-ELECTRICAL), WEIGHING AND MEASURING DEVICES									
0687A				4702 - GAGES, LINES AND FITTINGS									
0688	M	O		BRACKET, HOSE CLIP	EA		1	SEE GRP 9501				21	22
0688A	P	O	9515-529-0429	MANUFACTURE FROM: STEEL STRIP, CARBON, HOT ROLLED (3/4 IN. REQUIRED)	FT		1	*	*	*	*		
0689	X2	O	6690-704-1862	FLOWMETER	EA		1	*	*	*	*	33	39
0690	X1			BODY, METER	EA		1	*	*	*	*	33	39

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAIN	(c) RECOV.			(a)	(b)			(c)	(d)	(a)	(b)		
						MANUFACTURER'S CODE	PART NUMBER							FIG. NO.	ITEM OR SYM NO.
0692	X1	O		4730-044-4704	FLOAT, OUT	22375 CFRM0469	EA		1	*	*		*	33	34
0693	X1				PLUS, PIPE: FLOWMETER BODY	22375 101A710	EA		2					33	67
0694	X1				RING, O: INLET FITTING	22375 101A923	EA		1					33	70
0695	X1				RING, O: INLET FITTING	22375 101A926	EA		1					33	69
0696	X1			5330-806-7624	RING, O: INLET FITTING	22375 101A714	EA		2					33	68
0697	X1				RING, O: OUT ADAPTER	22375 376C032	EA		1					33	36
0698	X1				RING, OUT ADAPTING: BRASS	22375 304A193	EA		1					33	37
0699	X1				STOP, FLAT	22375 CFRM0468	EA		1					33	35
0700	X1				TUBE, METER	81336 D13200E5399-7	EA		1	*	*		*	33	65
0701	X2	O		6685-855-7226	GAGE, PRESSURE: SCALE MARK 0 TO 100	85274 1215-12	EA		1	*	*		*	33	41
0702	X2	O			MANOMETER	85274 1216-13MM4	EA		1						
0703	X1				CLIP, SCALE	85274 1215-12MM6	EA		1						
0704	X1				CLIP, SCALE	85274 1215-12MM1	EA		2						
0705	X1				PLUG, VALVE, RING	85274 1215-12MM5	EA		1						
0706	X1				SCALE	85274 1215-12MM2	EA		2						
0707	X1				TRAP, SAFETY	85274 1215-12MM3	EA		1						
0708	X1				WELL AND TUBE		EA		1	*	*	*	*	33	10
0709	O			5310-011-3102	NUT, PLAIN, HEXAGON: MANOMETER MTG	96906 MS35650-102	EA		2	*	*	*	*	33	24
0710	O			5310-012-0361	NUT, PLAIN, HEXAGON: MANOMETER MTG	96906 MS35242-77	EA		2	*	*	*	*	33	40
0711	O			5305-013-3648	SCREW, MACHINE: MANOMETER MTG		EA		2	*	*	*	*	33	42
0712	O			5305-043-6667	TUBE: AIR PRESSURE LINE FROM PRESSURE VALVE TO MANOMETER		EA		1	*	*	*	*	33	25
0713	M	O			MANUFACTURE FROM: PLASTIC TUBING (8 IN. REQUIRED)	81336 D13200E5399-24	EA		1	SEE GRP 9501				33	27
0714	P	O		4710-809-8149	TUBE: MANOMETER VENT	81336 D13200E5399-23	FT		1						
0715	P	O		4710-809-8149	MANUFACTURE FROM: PLASTIC TUBING (2 1/2 IN. REQUIRED)		FT			SEE GRP 9501					
0716	X2	O		5310-527-3288	VALVE, NEEDLE: AIR PRESSURE, BOTH ENDS	81336 D13200E5399-2	EA		1	*	*	*	*	33	62
0717	O	O		5310-595-7235	MALE, 1/8-27 THD SIZE	96906 MS35333-22	EA		2	*	*	*	*	33	26
					WASHER, LOCK: MANOMETER MTG	81336 MS35333-20	EA		1	*	*	*	*	33	9
0718					GROUP 55 - PUMPS										
0718A					5500 - PUMP ASSEMBLY										
0722	O	O		4730-084-0469	FITTING, LUBRICATION: CAP AND STAND	09058 92-5660-1348	EA		3	*	*	*	*	29	13
0726	O	O		5310-012-0377	NUT, PLAIN, HEXAGON: PUMP AND SHIM MTG	96906 MS35690-602	EA		4	*	*	*	*	29	23
0728	O	O			PUMP ASSEMBLY, WATER	09058 820-6-305	EA		1	*	*	*	*	29	
0730	X2	O		5305-012-2181	SCREW, CAP, HEXAGON HEAD: PUMP AND SHIM MOUNTING	96906 MS35291-66	EA		4	*	*	*	*	29	20
					SHIM: PUMP MTG	81336 A13200E5431	EA		1	*	*	*	*	29	21
0731	X2	O		5310-595-7237	WASHER, LOCK: PUMP AND SHIM MTG	96906 MS35333-42	EA		4	*	*	*	*	29	22
0733	O	O													

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) IS DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a) SOURCE	(b) MAIN			(c) RECOV.	(a) 1-5			(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM NO.		
0747				5505 - SUCTION OR DISCHARGE SYSTEM											
0748	P	O	5330-793-1057	GASKET: RELIEF VALVE NUT	EA			1		SEE	GRP 9901			29	26
0749	X2	O	4320-167-8216	PLUNGER, RELIEF VALVE	EA			1		*	*	*	*	29	28
0750	X2	O		SCREW, ADJUSTING: RELIEF VALVE, w/NUT	EA			1		*	*	*	*	29	24
0751	X2	O		SPRING, HELICAL, COMPRESSION: RELIEF PLUNGER	EA			1		*	*	*	*	29	27
0752				5507 - PUMP DRIVE											
0753	P	O	3030-542-3702	BELT, V: PUMP DRIVE	EA			1		*	*	2	2	29	39
0754	O	O	5306-207-9782	BOLT, MACHINE: BUSHING TO SHEAVE	EA			3		*	*	*	*	29	38
0757	X2	O		SHEAVE, PUMP DRIVE	EA			1		*	*	*	*	29	3
0758				GROUP 57 - SPRAY EQUIPMENT											
0758A				5703 - AIR BLOWER ASSEMBLY											
0759	X2	O		AIR BLOWER ASSEMBLY	EA			1		*	*	*	*		23
0762	P	O	3030-246-0152	BELT, V: BLOWER DRIVE, MATCHED SET OF 3	EA			1		*	*	2	2	31	22
0764	O	O	5306-207-9782	BOLT, MACHINE: BUSHING TO SHEAVE	EA			3		*	*	*	*	31	
0767	X2	O		BREATHER ASSEMBLY, VENTILATION	EA			1		*	*	*	*		
0768	X1	O		BASE, BREATHER	EA			1		*	*	*	*	31	37
0769	X2	O		ELEMENT, BREATHER	EA			1		*	*	*	*	31	38
0770	X2	O		SCREW, MACHINE: SHIELD TO BASE MTG	EA			1		*	*	*	*	31	41
0771	X1	O		SHIELD, BREATHER	EA			1		*	*	*	*	31	39
0772	X2	O		WASHER, LOCK: SHIELD TO BASE MTG	EA			1		*	*	*	*	31	40
0773	X2	O	5310-013-8530	BUSHING, PULLEY SHEAVE	EA			1		*	*	*	*	31	21
0777	X2	O		FITTING, LUBRICATING: END PLATE	EA			2		*	*	*	*	30	13
0778	X2	O		FITTING, RELIEF	EA			2		*	*	*	*	30	3
0781	P	O	3740-542-3717	GASKET: INTAKE AND EXHAUST FLANGE	EA			2		*	*	2	2	30	
0794	X2	O		PLATE, NAME: BLOWER	EA			1		SEE	GRP 2210			30	28
0795	X2	O		PLUG, MAGNETIC: OIL DRAIN, STEEL, 3/8-18 THD SIZE	EA			1		*	*	*	*	31	27
0796		O	4730-044-4688	PLUG, PIPE: BEARING CAP	EA			2		*	*	*	*	30	10
0797		O	4730-044-4698	PLUG, PIPE: GEAR END PLATE	EA			6		*	*	*	*	31	5
0798		O	4730-044-5686	PLUG, PIPE: PLATE	EA			2		*	*	*	*	31	4
0804	X2	O		SCREW, DRIVE: BLOWER NAMEPLATE MTG	EA			6		SEE	GRP 2210				
0811	X2	O		PULLEY, THREE GROOVE: BLOWER DRIVE	EA			1		*	*	*	*	31	24
0819	X2	O	3020-877-1194	BRACKET, BELT TENSION: BLOWER ALIGNMENT AND BELT ADJUSTING	EA										
0820		O	5310-584-5005	NUT, PLAIN, HEXAGON: BELT TENSION BRACKET	EA			1		*	*	*	*	30	17
0821		O	5305-637-4034	SCREW, CAP, HEXAGON HEAD: BELT TENSION BRACKET	EA			2		*	*	*	*	30	16
0831	X2	O		FLANGE: MANIFOLD MTG	EA			2		*	*	*	*	30	15
					EA			1		*	*	*	*	30	26

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION			
	(a) SOURCE	(b) MAIN					(c) RECOV.	(d) RECOV.	(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(e) FIG. NO.	(f) ITEM NO. FOR SYM.
0832	X2	0	5305-637-4028	GUARD ASSEMBLY, BELT	EA	1	*	*	*	*	*	27	3	
0833		0		SCREW, CAP, HEXAGON HEAD: BELT GUARD	EA	6	*	*	*	*	*	27	1	
0834		0	5305-639-8115	SCREW, CAP, HEXAGON HEAD: BELT GUARD	EA	1	*	*	*	*	*	27	1	
0835		0	5310-011-5547	WASHER, LOCK: BELT GUARD MTO	EA	7	*	*	*	*	*	27	2	
0836	X2	0	5310-012-0377	MANIFOLD ASSEMBLY, INTAKE	EA	1	*	*	*	*	*	30	31	
0837		0		NUT, PLAIN, HEXAGON: BLOWER TO FRAME	EA	2	*	*	*	*	*	31	32	
0838		0	5310-012-0377	NUT, PLAIN, HEXAGON: BLOWER TO FRAME	EA	2	*	*	*	*	*	30	33	
0839		0	5305-639-8118	SCREW, CAP, HEXAGON HEAD: BLOWER TO	EA	2	*	*	*	*	*	31	34	
0840		0	5305-639-8118	SCREW, CAP, HEXAGON HEAD: BLOWER TO	EA	2	*	*	*	*	*	30	14	
0841		0	5305-638-9082	SCREW, CAP, HEXAGON HEAD: FLANGE	EA	12	*	*	*	*	*	30	24	
0842		0	5305-550-1310	SCREW, CAP, HEXAGON HEAD: INTAKE	EA	12	*	*	*	*	*	30	29	
0843		0	5310-013-8542	WASHER, LOCK: BLOWER TO FRAME AND	EA	16	*	*	*	*	*	30	25	
0844		0	5310-013-8542	WASHER, LOCK: BLOWER TO FRAME MTO	EA	2	*	*	*	*	*	31	33	
0845		0	5310-595-7237	WASHER, LOCK: INTAKE MANIFOLD MTO	EA	12	*	*	*	*	*	30	30	
0855				5707 - INSTRUMENT PANEL	EA	1	*	*	*	*	*	33	30	
0856	X2	0	5310-584-5005	BRACKET, PANEL	EA	11	*	*	*	*	*	33	5	
0857		0		NUT, PLAIN, HEXAGON: PANEL MTO AND	EA	1	*	*	*	*	*	33	5	
0858		0		BRACKET TO CANOPY	EA	1	*	*	*	*	*	33	5	
0859	X2	0		PANEL ASSEMBLY, INSTRUMENT	EA	1	SEE GRP 2210	*	*	*	*	33	8	
0860	X2	0		LABEL SET, IDENTIFICATION	EA	5	*	*	*	*	*	33	7	
0861	X2	0		MOUNT, VIBRATION: PANEL MTO	EA	1	*	*	*	*	*	33	7	
0862	X1	0	5320-117-7106	PANEL, INSTRUMENT	EA	14	SEE GRP 2210	*	*	*	*	33	31	
0863		0	5305-627-4028	RIVET, SOLID: IDENTIFICATION PLATES	EA	1	*	*	*	*	*	33	6	
0864		0	5310-527-3289	MOUNTING	EA	11	*	*	*	*	*	33	6	
0865				SCREW, CAP, HEXAGON HEAD: BRACKET TO	EA	1	*	*	*	*	*	33	31	
0866				CANOPY	EA	11	*	*	*	*	*	33	6	
0867				WASHER, LOCK: PANEL MTO AND BRACKET	EA	11	*	*	*	*	*	33	6	
0865				TO CANOPY	EA	11	*	*	*	*	*	33	6	
0865				5708 - TANKS, VALVES, LINES, HOSES, FITTINGS, AND LIQUID STRAINER	EA	11	*	*	*	*	*	33	6	
0866		0	4730-202-6694	BUSHING, PIPE: HOSE STRAINER, FLOW	EA	2	*	*	*	*	*	33	32	
0867		0	4730-194-0219	METER	EA	2	*	*	*	*	*	33	15	
0867		0	4730-194-0219	BUSHING, PIPE: LINE STRAINER	EA	2	*	*	*	*	*	33	15	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
								(a)	(b)	(c)	(d)		
	(a) SOURCE	(b) MAIN	(c) RECOV.					CODE	PART NUMBER	1-5	6-20	21-50	51-100
0868		0		730-277-7899	BUSHING, PIPE: OUTLET LINE FROM LINE STRAINER	EA	1	*	*	*	*	33	17
0869		0		730-277-7899	BUSHING, PIPE: PUMP TO UNION	EA	2	*	*	*	*	29	31
0870		0		730-277-7899	BUSHING, PIPE: SPRAY LINE	EA	1	*	*	*	*	34	6
0871		0		730-289-0147	BUSHING, PIPE: STRAINER TO HOSE CONNECTOR	EA	1	*	*	*	*	33	52
0872		0		730-278-2538	CLAMP, HOSE: SUCTION HOSE	EA	2	*	*	*	*	33	45
0873	X2	0			CLIP, HOSE: LINE STRAINER TUBE SUPPORT	EA	1	*	*	*	*	33	19
0874	X2	0		820-845-1096	COCK, DRAIN: PUMP OUTLET LINE	EA	1	*	*	*	*	33	35
0875	X2	0			CONNECTOR, HOSE, PIPE: HOSE STRAINER AND INLET HOSE, BRASS, 3/8-18 THD SIZE ONE END, OTHER END 3/8 IN. ID HOSE	EA	1	*	*	*	*	29	
0876	X2	0			CONNECTOR, HOSE, PIPE: PUMP TO CONTROL PANEL	EA	2	*	*	*	*	33	53
0877	X2	0		730-287-1614	CONNECTOR, HOSE, PIPE: SPRAY LINE	EA	1	SEE GRP 9401				33	29
0878	X2	0			COUPLING, PIPE: PRESSURE TUBE ELBOW TO EXHAUST FLANGE	EA	1	SEE GRP 9401				34	7
0879	X2	0		730-289-0587	COUPLING, PIPE: THREE WAY VALVE, BY-PASS	EA	1	*	*	*	*	30	21
0880	X2	0			CROSS, PIPE: SPRAY NOZZLE TUBES, BRASS, ALL ENDS MALE, 1/8-27 THD SIZE	EA	3	*	*	*	*	33	2
0881	X2	0			ELBOW, HOSE: PLASTIC HOSE CONNECTION	EA	2	*	*	*	*	34	12
0882	X2	0			ELBOW, HOSE: REAR OF PANEL, BY-PASS, THREE-WAY VALVE STRAINER	EA	1	SEE GRP 9401				29	37
0883		0		730-277-5553	ELBOW, PIPE: AIR PRESSURE GAGE, TEE	EA	4	SEE GRP 9401				33	1
0884		0		730-249-3882	THREE-WAY VALVE	EA	4	*	*	*	*	33	59
0885		0		730-814-1132	ELBOW, PIPE: AIR PRESSURE VALVE	EA	2	*	*	*	*	33	61
0886		0		730-814-1132	ELBOW, PIPE TO TUBE: AIR PRESSURE LINE	EA	2	*	*	*	*	33	3
0887	X2	0			ELBOW, PIPE TO TUBE: PRESSURE TUBE TO EXHAUST FLANGE	EA	1	*	*	*	*	30	20
0888		0		730-814-1132	ELBOW, PIPE TO TUBE: SPRAY NOZZLE, BRASS, ONE END FEMALE, 5/16-24 THD SIZE, OTHER END MALE, 1/8-27 THD SIZE	EA	2	*	*	*	*	34	19
0889	X2	0			ELBOW, PIPE TO TUBE: SPRAY TO CROSS	EA	2	*	*	*	*	34	13
0890	M	0			HOSE: BY-PASS TO SUPPLY TANK, PLASTIC, 10 FT LG	EA	1	*	*	*	*	33	72
0890A	P	0		730-289-4869	HOSE: INTAKE, SUCTION	EA	1	*	*	*	*	33	54
0992		0		730-014-4574	MANIFOLD FROM: HOSE, RUBBER (10 FT REQUIRED)	FT	2	SEE GRP 9400					
0993		0		730-014-4574	LOCKNUT, PIPE: AIR PRESSURE VALVE TO MANOMETER	EA	2	*	*	*	*	33	4
0994		0		730-014-4574	LOCKNUT, PIPE: CLOSE NIPPLE TO SPRAY MANIFOLD	EA	2	*	*	*	*	34	18
0995		0		730-390-0138	LOCKNUT, PIPE: NIPPLE LOCKING	EA	2	*	*	*	*	30	22
					LOCKNUT, PIPE: SUCTION HOSE CONNECTOR AT LINE STRAINER	EA	1	*	*	*	*	33	55

LINE NO.	SOURCE	MAINT. AND RECV. CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUS-TRATION		
								(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) SYM OR NO.	
				MANUFACTURER'S										
				CODE	PART NUMBER									
0996		0	4730-014-4575	LOCKNUT, PIPE: THREE-WAY VALVE, BY-PASS, FLOW CONTROL	EA		5	*	*	*	*	33	28	
0997		0	4730-188-1854	NIPPLE, PIPE: FLOW CONTROL ELBOW	EA	82254 CFA40615	1	*	*	*	*	33	56	
0998		0	4730-196-1974	NIPPLE, PIPE: FLOW CONTROL VALVE TO TEE	EA		1	*	*	*	*	33	66	
0999		0	4730-233-3593	NIPPLE, PIPE: FLOW METER	EA		2	*	*	*	*	33	33	
1000		0	4730-230-1996	NIPPLE, PIPE: PRESSURE TUBE ELBOW TO EXHAUST FLANGE	EA		1	*	*	*	*	30	23	
1001		0	4730-230-1996	NIPPLE, PIPE: SPRAY MANIFOLD	EA	81336 D13200E5399-13	2	*	*	*	*	34	17	
1002	X2	0		NIPPLE, PIPE: TEE TO BUSHING	EA		1	*	*	*	*	29	34	
1003	X2	0		NIPPLE, PIPE: THREE WAY VALVE, 1/4-18 TWD SIZE, 1 5/8 IN. LG, SPECIAL	EA	82254 CFA40023	2	*	*	*	*	33	60	
1004	X2	0	5305-276-7951	SCREW, MACHINE: TO NOSE CLIP	EA		1	*	*	*	*	33	51	
1005	X1	0		STRAINER ASSEMBLY, HOSE BODY, STRAINER	EA	82254 CFR40587	1	*	*	*	*	33	47	
1006	X2	0		CAP, END	EA	82247 4652-2	1	*	*	*	*	33	46	
1007	X2	0		SCREEN, STRAINER	EA	93146 4649	1	*	*	*	*	33	50	
1008	X2	0		SCREW, MACHINE: CAP TO BODY MTG	EA	82247 3910	1	*	*	*	*	33	48	
1009	X2	0	5305-011-3975	SPRING, INNER	EA	93146 4263	1	*	*	*	*	33	16	
1010	X2	0		SPRING, OUTER	EA	93146 4296	1	*	*	*	*	33	12	
1011	X2	0		STRAINER ASSEMBLY, LINE	EA	82247 A3-44TWB	1	*	*	*	*	33	14	
1012	X2	0		BODY, STRAINER	EA	82247 5050	1	*	*	*	*	33	13	
1013	X1	0		CAP, STRAINER	EA	82247 5051	1	*	*	*	*	33	11	
1014	X2	0	4730-044-4693	GASKET: STRAINER SCREEN TO BODY	EA	82247 5052	1	*	*	*	*	33	58	
1015	X2	0		PLUS, PIPE: STRAINER BODY CAP	EA	82247 4537A3-44TW	1	*	*	*	*	29	36	
1016	X2	0		SCREEN, STRAINER	EA		1	*	*	*	*			
1017	X2	0		TEE, PIPE: FLOW CONTROL VALVE	EA		1	*	*	*	*			
1018	X2	0		TEE, PIPE: PUMP OUTLET LINE	EA		1	*	*	*	*			
1019	X2	0		TEE, PIPE: SPRAY NOZZLE TUBE CONNECTION, BRASS, ONE END, MALE, 1/8-27 TWD SIZE, 1/4 IN. OD TUBE, 5/16-24 TWD SIZE	EA		1	*	*	*	*			
1020	X2	0		TEE, PIPE: SPRAY NOZZLE TUBE CONNECTION, BRASS, ONE END, MALE, 1/8-27 TWD SIZE, 1/4 IN. OD TUBE, 5/16-24 TWD SIZE	EA	81336 D13200E5341-3	4	*	*	*	*	34	14	
1021	X2	0		TEE, PIPE TO TUBE: INSECTICIDE TUBE, BRASS, ONE END MALE, 1/8-27 TWD SIZE, OTHER ENDS MALE, 5/16-24 TWD SIZE	EA	81336 D13200E5341-9	1	*	*	*	*	34	5	
1022	X2	0		TUBE ASSEMBLY: ELBOW TO SPRAY NOZZLE, TEFLON, 13 IN. LG	EA	81336 D13200E5341-1	10	*	*	*	*	34	15	
1023	M	0		TUBE ASSEMBLY: INSECTICIDE MANUFACTURE FROM:	EA	81336 D13200E5341-8	2	*	*	*	*	34	9	
1023A		0	4730-278-8365	NUT, TUBE COUPLING	EA		2	*	*	*	*			
1023B		0	4730-278-8829	NUT, TUBE COUPLING	EA		2	*	*	*	*			
1023C	P	0	5330-362-1562	PACKING, PREFORMED	EA		2	*	*	*	*			
1023D	X2	0	4730-200-0213	SLEEVE, COMPRESSION	EA		2	*	*	*	*			
1023E	P	0	4710-277-5526	TUBE, COPPER (10 3/4 IN. REQUIRED FOR EACH TUBE ASSEMBLY)	EA		2	*	*	*	*	34	8	
				SEE ERP 9501										

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC. IN UNIT PACK	(6) QTY INC. IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAIN							(c) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR NO.
1024	X2	0		TUBE, FLUID: PUMP TO STRAINER AND PANEL, 7 IN. LG	EA				*	*	*	*	33	18
1025	X2	0		TUBE, FLUID: THREE WAY VALVE TO SUPPLY BY-PASS TEFLON, 1 1/4 IN. ID, 3/8 IN. OD, 13 1/2 IN. LG	EA				*	*	*	*	33	22
1026	X2	0		TUBE, TEFLON: THREE-WAY VALVE TO MANIFOLD HEAD, 1 1/4 IN. ID, 3/8 IN. OD, 5 FT LG	EA				*	*	*	*	33	21
1027	M	0		TUBE, VINYL: AIR PRESSURE LINE FROM PRESSURE VALVE TO AIR BLOWER MANUFACTURE FROM:	EA				*	*	*	*	33	23
1027A	P	0	4710-809-8149	PLASTIC, TUBING (22 IN. REQUIRED)	EA				SEE GRP 9501					
1028	X2	0		UNION, HALF: BY-PASS HOSE	EA				SEE GRP 9501					
1029	X2	0		UNION, HALF: INLET LINE	EA				SEE GRP 9501					
1030	X2	0		VALVE, NEEDLE: FLOW CONTROL, 1/4-18 THD SIZE	EA									
1031	X1	0	5310-012-0361	NUT, PLAIN, HEXAGON: WHEEL MTO	EA				*	*	*	*	33	14
1032	X2	0		WHEEL, FLOW VALVE	EA				*	*	*	*	33	24
1033	X2	0		VALVE, THREE WAY: FLOW CONTROL, BRASS, 1/4-18 THD SIZE	EA				*	*	*	*	33	43
1034	0	0	5305-206-8263	SCREW, MACHINE: POINTER TO VALVE	EA				*	*	*	*	33	63
1035				GROUP 95 - GENERAL USE STANDARDIZED PARTS										
1036				9501 - BULK MATERIAL										
1037	P	0	2990-085-9035	CHAIN, WELDLESS: PHOSPHATE FINISH, 0.062 IN. ID, 23 LINKS PER FIT	FT				*	*	*	*		
1039	P	0	4720-289-1869	HOSE, RUBBER: 3/8 IN. ID, 50 FT LG (GE)	FT				*	*	*	*		
1040	P	0	4720-218-5614	HOSE, RUBBER: 1 1/2 IN. ID	FT				*	*	*	*		
1041	P	0	5330-270-8469	PAPER, GASKET: 36 IN. W, 1/32 IN. THK	YD				*	*	*	*		
1042	P	0	4710-162-0991	PIPE, STEEL: 1 1/4 IN. ID	FT				*	*	*	*		
1043	P	0	4710-809-8149	PLASTIC TUBING: 1/4 IN. DIA	FT				*	*	*	*		
1044	P	0	5330-505-6611	RUBBER SHEET, SOLID: 1/16 IN. THK, 24 IN. V	FT				*	*	*	*		
1045	P	0	9515-554-0893	STEEL STRIP, CARBON, HOT ROLLED: 1/8 IN. THK, 1 1/4 IN. W	FT				*	*	*	*		
1046	P	0	9515-529-0429	STEEL STRIP, CARBON, HOT ROLLED: 1/8 IN. THK, 2 IN. W	FT				*	*	*	*		
1047	P	0	4710-271-5525	TUBE, COPPER: 0.250 IN. DIA	FT				*	*	*	*		
1048	P	0	4710-271-5526	TUBE, COPPER: 5/16 IN. DIA	FT				*	*	*	*		
1049	P	0	6145-295-0804	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 12 AWG, 19 STRANDS OF No. 25 AWG, 0.155 IN. DIA	FT				*	*	*	*		
1050	P	0	6145-164-7033	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 14 AWG, 19 STRANDS OF No. 27 AWG, 0.115 IN. DIA	FT				*	*	*	*		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAIN	(c) RECOV.			CODE	PART NUMBER			(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
1051	P	O		6145-16A-7023	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 16 AWG, 19 STRANDS, 0.102 IN. DIA		70903 1941			*	*	*	*		
1052					GROUP 99 - PARTS PECULIAR										
1052A					9901 - MULTI-LISTED PARTS										
1053	X2	O			CONNECTOR, HOSE, PIPE: 3/8-24 THD SIZE ONE END, OTHER END, 1/2-18 THD SIZE		81336 D13200E5399-20		2	*	*	*	*		
1054	X2	O			ELBOW, HOSE: ONE END, 3/8-24 THD SIZE, OTHER END, 1/4-18 THD SIZE		81336 D13200E5399-19		5	*	*	*	*		
1055	P	O		2805-641-7404	GASKET				2	*	*	*	3		
1057	X2	O			UNION, HALF: BRASS, ONE END, 1/4-18 THD SIZE, OTHER END 3/8-24 THD SIZE		81336 D13200E5399-11		2	*	*	*	*		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.						(c) RECOV.	(d) 51-100	(e) FIG. NO.	(f) ILLUSTRATION		
1058				PART 11									
1058A				GROUP 01 - ENGINE									
1066				0102 - CRANKSHAFT									
1067	X2	O		SHEAVE, CRANKSHAFT: BLOWER DRIVE	EA		1	*	*	*	*	*	*
1070				0106 - ENGINE LUBRICATION SYSTEM									
1072		O	4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: YEE TO GOVERNOR OIL LINE	EA		1	*	*	*	*	10	16
1073		O	5306-543-4308	BOLT, MACHINE: FILTER MTG	EA		1	*	*	*	*	10	22
1074	X2	O		FILTER ASSEMBLY, OIL BODY ASSEMBLY	EA		1	*	*	*	*	10	20
1075	X1	O		COVER ASSEMBLY	EA		1	*	*	*	*	10	14
1076	X2	O		COVER, FILTER	EA		1	*	*	*	*	10	10
1077	X1	O		GASKET: FIBER	EA		1	*	*	*	*	10	9
1078	X2	O	5330-056-9588	HANDLE ASSEMBLY	EA		1	*	*	*	*	10	7
1079	X1	O		RING, SNAP	EA		1	*	*	*	*	10	11
1080	X2	O		WASHER, SHOULDERED	EA		1	*	*	*	*	10	13
1081	X2	O	5310-417-8620	SPRING, COMPRESSION	EA		1	*	*	*	*	10	12
1082	X2	O		WASHER, NON-METALLIC: COVER SCREW	EA		1	*	*	*	*	10	8
1083	P	O	5330-298-0776	FILTER ELEMENT, FLUID, PRESSURE: OIL	EA		1	2	7	13	25	2	23
1084	P	O	2940-529-2738	NUT, PLAIN, SQUARE: OIL FILTER STRAP	EA		1	*	*	*	*	10	5
1085	O	O	5310-368-1908	SCREW, MACHINE: OIL FILTER STRAP	EA		1	*	*	*	*	10	21
1086	O	O	5305-013-3083	STRAP, BODY	EA		1	*	*	*	*	10	3
1087	X2	O		WASHER, LOCK: OIL FILTER STRAP	EA		1	*	*	*	*	10	6
1088	O	O	5310-368-1911	WASHER, NON-METALLIC: COVER	EA		1	2	7	13	25	10	24
1089	P	O	5330-291-3405	HOSE ASSEMBLY, RUBBER: OIL LINE, PRESSURE	EA		1	*	*	*	*	10	25
1090	P	O	2940-606-6816	LINE ASSEMBLY, OIL: CRANKCASE TO GOVERNOR	EA		1	*	*	*	*	10	25
1091	M	O		MANUFACTURE FROM:									
1092		O	4730-011-6452	NUT, TUBE COUPLING	EA		2	*	*	*	*	*	*
1092A	P	O	4710-277-5525	TUBE, COPPER (6 1/2 IN. REQUIRED)	EA		1	SEE GRP 9501	*	*	*	10	1
1093	O	O	5310-176-8160	NUT, PLAIN, HEXAGON: FILTER MTG	EA		1	*	*	*	*	10	15
1094	O	O	4730-603-4470	TEE, PIPE: OIL FILTER INLET	EA		1	*	*	*	*	10	2
1095	O	O	5310-596-4911	WASHER, LOCK: FILTER MTG	EA		1	*	*	*	*	10	2
1096				GROUP 03 - FUEL SYSTEM									
1096A				0309 - FUEL FILTERS									
1097	X2	O	4730-639-9638	STRAINER ASSEMBLY	EA		1	*	*	*	*	16	20
1098	X1	O		BAIL ASSEMBLY	EA		1	*	*	*	*	16	19
1099	P	O	2910-358-4317	BOWL, SEDIMENT, FUEL: GLASS	EA		1	*	*	*	*	16	16
1100	X1	O	2910-305-5749	COVER, STRAINER	EA		1	*	*	*	*	16	16

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.							(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ILLUSTRATION
					MANUFACTURER'S									
					CODE	PART NUMBER								
1101	P	O	2910-358-5327	SCREEN, FUEL STRAINER	EA	78480 07762			*	*	*	*	16	17
1102	X1		2910-368-6657	VALVE, FUEL REGULATING: SHUT OFF	EA	78480 07769							16	21
1103	P	O	2910-282-7557	WASHER, NONMETALLIC: BOWL MTG	EA	78480 08227			2	2	4	8	16	18
1108				GROUP 06 - ELECTRICAL SYSTEM										
1108A				0605 - IGNITION COMPONENTS										
1109	P	O	2920-566-7806	CABLE, SPECIAL PURPOSE	EA	66289 YD2120			*	*	*	*	2	4
1110	X2	O	5340-447-9222	CLAMP, CABLE: SPARK PLUG WIRES	EA	66289 PG314			*	*	*	*	2	1
1111	P	O R	2920-800-8156	MAGNETO ASSEMBLY (INCLUDES COMPONENTS OF REPAIR KIT, Stock No. 2920-712-1267)	EA	79575 XHS2484			*	*	*	*	22	
1112	X1		2930-353-6609	BEARING, SLEEVE: DRIVE CUP	EA	79575 5518							22	4
1113	X1		2920-374-3481	BEARING UNIT, BALL, CYLINDRICAL										
1114	X1		3110-144-8882	CARTRIDGE: ROTOR SHAFT	EA	79575 X7672							22	6
1115	X1		2920-353-6611	BEARING, BALL ANNULAR: ROTOR	EA	79575 7617							22	5
1116	X1		2520-367-7985	RETAINER, BALL BEARING	EA	79575 5567							22	57
1117	X1		2920-335-4178	BRACKET, TERMINAL	EA	79575 X7724							22	19
1118	X1		2920-428-3751	CLAMP, ELECTRICAL: COIL CORE	EA	79575 5633							22	21
1119	X1		2920-607-1324	COIL, MAGNETO	EA	79575 X7895							22	22
1120	X1		2920-368-6715	CORE ASSEMBLY: MAGNETO COIL	EA	79575 X5524							22	33
1121	X1		2920-740-2845	COUPLING, MAGNETO: IMPULSE	EA	79575 X8774							22	26
1122	X1		2920-366-6296	ARM, TRIP	EA	79575 A179X							22	35
1123	X1		2920-368-6715	CUP, MAGNETO DRIVE	EA	79575 2061A							22	28
1124	X1		2920-740-2845	FLANGE, DRIVEN GROUP	EA	79575 X6586							22	31
1125	X1		2920-366-6306	NUT, IMPULSE LOCK	EA	79575 8738							22	24
1126	X1		2920-367-7999	RETAINER, DRIVE SPRING	EA	79575 2288							22	34
1127	X1		2920-662-9135	RING, LOCK: RETAIN NG, IMPULSE	EA	79575 6424							22	27
1128	X1		5340-353-6606	COUPLING SPRING, SPIRAL, TENSION: IMPULSE	EA	79575 2122							22	32
1129	X1		5340-740-2871	COUPLING SPRING, TRIP ARM	EA	79575 15-186							22	29
1130	X1		2920-740-2846	WASHER: DRIVE CUP SPACER	EA	79575 6585							22	30
1131	X1		5310-187-3458	WASHER, FLAT: DRIVE FLANGE	EA	79575 7908							22	25
1132	X1		5310-353-6620	WASHER, KEY	EA	79575 M42XA							22	16
1133	X1		2920-787-0480	COVER, UNIT	EA	79575 6425							22	48
1134	X1		2920-598-9432	ROD GROUP, GROUND	EA	79575 X7910							22	50
1135	X1		5305-276-7951	SPRING, HELICAL, COMPRESSION	EA	79575 X7867							22	13
1136	X1		5940-314-0255	SCREW, MACHINE: TERMINAL BLOCK MTG	EA	79575 6732							22	15
1137	X1		5310-013-5830	TERMINAL BLOCK: HIGH TENSION	EA	79575 X7892							22	14
1138	X1		8305-740-2859	WASHER, LOCK: TERMINAL BLOCK MTG	EA	79575 7644							22	58
1139	X1		5330-297-4578	FELT, STRIP: BREAKER ARM	EA	79575 5519							22	42
1140	X1			GASKET: IMPULSE STOP	EA								22	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(6) QTY INC IN UNIT	(8) ILLUSTRATION		
	(a) SOURCE	(b) MAIN					(c) RECOV.	(a) 1-5	(b) 6-20	(c) 21-50		(d) 51-100	(a)	(b)
1141	X1		2920-360-8381	GASKET: MAGNETO MTG (COMPONENT OF GASKET SET, STOCK NO. 2805-720-4773, SEE GROUP 0100, PART 1) (CAN BE MANUFACTURED FROM PAPER, STOCK NO. 5330-233-5636)	EA	1						22	3	
1142	X1			GEAR, DRIVE	EA	1							22	23
1143	X1			HOUSING, MAIN: MAGNETO	EA	1							22	11
1144	X1			LEAD, ELECTRICAL: BREAKER TO CAPACITOR	EA	1							22	55
1145	X1		5310-012-0614	NUT, PLAIN, HEXAGON: IMPULSE STOP SET	EA	1							22	38
1146	X1		2510-039-7699	SCREW LOCKING	EA	1							22	37
1147	X1		2920-740-2873	PLATE, IMPULSE STOP	EA	1							22	10
1148	X1		5305-281-8308	PLATE, NAME: MAGNETO	EA	1							22	20
1149	X1			ROTOR	EA	1				SEE GRP 2210			22	56
1150	X1		5305-639-6026	SCREW, ASSEMBLED WASHER: BREAKER CLAMP, CONTACT MTG, CORE CLAMP MTG	EA	1							22	18
1151	X1		5305-335-4180	BRACKET MTG	EA	1							22	41
1152	X1		5305-424-2999	SCREW, DRIVE: NAMEPLATE MTG	EA	2							22	9
1153	X1		5305-022-5561	SCREW, MACHINE: COVER MTG	EA	3							22	17
1154	X1		5305-630-6834	SCREW, MACHINE: IMPULSE STOP CLAMP	EA	4							22	52
1155	X1		2920-353-6614	SETScrew: IMPULSE STOP	EA	1							22	59
1156	X1		2920-353-6610	SHIELD, BALL BEARING	EA	1							22	51
1157	X1		5310-275-1353	SPACER, SLEEVE: BEARING GAGE	EA	1							22	54
1158	X1		5310-188-4185	WASHER: COVER MTG	EA	1							22	44
1159	X1		5310-351-0698	WASHER, FLAT: BREAKER ARM PIVOT	EA	3							22	46
1160	X1			WASHER, FLAT: BREAKER POINT ALIGNING	EA	1							22	49
1161	X1		5310-012-1744	WASHER, FLAT: POINT ALIGNMENT STEEL, CADMIUM OR ZINC PLATED, 3/16 ID, 5/16 OD, 0.004 IN. THK	EA	1							22	36
1162	X1		5330-262-3306	WASHER, LOCK: IMPULSE STOP CLAMP	EA	1							22	12
1163	X1		5310-012-0377	WICK: CAN VIPER, FELT	EA	1							22	53
1164	P	O	2920-712-1267	NUT, PLAIN, HEXAGON: MAGNETO MTG	EA	1						*	22	43
1165	X1		2920-662-9133	REPAIR KIT, MAGNETO	EA	1				*		*	22	3
1166	X1		5910-740-2855	BEARING, SLEEVE: BREAKER PLATE	EA	1							22	47
1167	X1		2920-740-2882	CONDENSER, CAP	EA	1							22	37
1168	X1		2920-428-3830	CONTACT SET, DISTRIBUTOR	EA	1							22	12
1169	X1		2920-740-2852	DEFLECTOR, DIRT AND OIL	EA	1							22	53
1170	X1		5315-367-7994	GASKET: COVER, LEAD	EA	1							22	7
1171	X1		5340-281-6688	PIN, LOCK: BREAKER ARM	EA	1							22	43
1172	X1		2920-353-6618	RING, RETAINING: ROTARY BEARINGS	EA	1							22	1
1173			5305-269-3217	SEAL, PLAIN: OIL	EA	2				*		*	22	3
1174	O		5305-584-8736	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG	EA	2				*		*	22	6
1175	P	O	2920-293-5212	SCREW, MACHINE: CABLE CLAMP ATTACHMENT	EA	2				3		10	2	5
1176	P		5330-599-5356	SPARK PLUG: 18 MM	EA	2				2		3	2	2
1177	O		5310-543-2705	GASKET: SPARK PLUG	EA	1				*		*	22	2
1178	O		5310-502-9930	WASHER, LOCK: CABLE CLAMP ATTACHMENT	EA	2				*		*	22	2
1179	O		5310-627-6128	WASHER, LOCK: MAGNETO MTG	EA	1				*		*	22	45

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.			(c) RECOV.				(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM NO.	
					(b) MAINT.	(c) RECOV.									
1180				GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS											
1180A				2210 - DATA PLATES											
1181	X2	O	2805-685-6019	PLATE, INSTRUCTION: ENGINE OPERATION	EA			1	*	*	*	*			
1182	X2	O		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA			1	*	*	*	*			
1183	X2	O		PLATE, NAME: MAGNETO	EA			1	*	*	*	*			
1184	X2	O	5305-335-1180	SCREW, DRIVE: NAMEPLATE MTO	EA			2	*	*	*	*			
1185				GROUP 57 - SPRAY EQUIPMENT COMPONENTS											
1185A				5703 - AIR BLOWER ASSEMBLY											
1186	X2	O		FILTER, SILENCER: AIR BLOWER	EA			1	*	*	*	*	32	5	
1187	X1	O		BODY, FILTER	EA			1	*	*	*	*	32	6	
1188	X2	O		ELEMENT, FILTER SILENCER	EA			1	*	*	*	*	32	4	
1189	P	O	3740-542-3716	GASKET: ELEMENT TO BODY AND TOP	EA			2	*	*	*	2	32	1	
1190	X2	O	5310-010-3129	NUT, PLAIN, WING: TOP TO BODY	EA			1	*	*	*	*	32	8	
1191	X2	O		TOP ASSEMBLY	EA			1	*	*	*	*	32	1	
1192	M	O		FELT: TOP ASSEMBLY	EA			1	*	*	*	*	32	7	
1192A	P	O	5330-191-1096	MANUFACTURE FROM: FELT SHEET	SH				SEE GRP 9501						
1193	O	O	5310-366-620A	(7 IN. X 7 IN. REQUIRED)	EA			1	*	*	*	*	32	3	
1194	O	O	5310-013-8542	WASHER, FLAT: TOP TO BODY	EA			1	*	*	*	*	32	2	
1195				WASHER, LOCK: TOP TO BODY											
1195A				5704 - SPRAY DUCTS AND NOZZLES											
1196	X2	O		MANIFOLD SPRAY ASSEMBLY	EA			1	*	*	*	*	34	2	
1197	X2	O		CLAMP, DRUM	EA			5	*	*	*	*	34	10	
1198	X2	O		ELBOW, LONG	EA			1	*	*	*	*	34	11	
1199	X2	O		ELBOW, SHORT	EA			1	*	*	*	*	34	1	
1200	X2	O		END CAP	EA			2	*	*	*	*	34	1	
1201	X2	O		NOZZLE HEAD	EA			1	*	*	*	*	34	3	
1202	X2	O		SCREW, TOGGLE: CLAMP DRUM CLAMPING	EA			5	*	*	*	*	34	1	
1203	X2	O	3440-977-8672	NOZZLE ASSEMBLY: SPRAY	EA			10	*	*	*	*	34	16	
1204				GROUP 95 - GENERAL USE STANDARDIZED PARTS											
1204A				9501 - BULK MATERIAL											
1205	P	O	5330-191-1096	FELT SHEET: 1/4 IN. THK, 30 IN. W, 36 IN. LONG	SH				*	*	*	*			

LINE NO.	(1) SOURCE MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION		(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.							(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
1206				PART III										
1206A				GROUP 01 - ENGINE										
1206B				0100 - ENGINE ASSEMBLY										
1212	X2	0		EXTENSION, OIL DRAIN	82254 CFR40975	EA		1	*	*	*	*	*	*
1215				0102 - CRANKSHAFT										
1216	X2	0		SHEAVE, CRANKSHAFT: BLOWER DRIVE	82254 CFR40088	EA		1	*	*	*	*	*	*
1219				0106 - ENGINE LUBRICATION SYSTEM										
1220		0	4730-278-1323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	66289 RF269	EA		1	*	*	*	*	10	16
1221		0	5306-513-1308	BOLT, MACHINE: FILTER MTG	66289 RV28	EA		1	*	*	*	*	10	22
1223	X2	0	2940-358-2536	FILTER, FLUID, PRESSURE: OIL	73370 5310	EA		1	*	*	*	*	10	20
1224	X1	0	2940-393-5988	BODY ASSEMBLY	73370 5241	EA		1	*	*	*	*	10	14
1225	X1	0	5330-056-9588	COVER ASSEMBLY	73370 102033	EA		1	*	*	*	*	10	10
1227	X2	0		COVER, FILTER	73370 102032	EA		1	*	*	*	*	10	9
1228	X1	0		GASKET: FIBER	73370 8112	EA		1	*	*	*	*	10	7
1229	X2	0		HANDLE ASSEMBLY	73370 102483	EA		1	*	*	*	*	10	11
1230	X2	0	5310-417-8620	RING, SNAP	73370 10776	EA		1	*	*	*	*	10	13
1231	X2	0		WASHER, SHOULDERED	73370 10208	EA		1	*	*	*	*	10	12
1232	P	0	5330-298-0776	SPRING, COMPRESSION	73370 10076	EA		1	*	*	*	*	2	8
1233	P	0	2940-141-9025	WASHER, NONMETALLIC: COVER SCREW	73370 C21P2	EA		1	2	7	13	25	10	23
1234	P	0	5330-599-1285	FILTER ELEMENT	73370 11582	EA		1	2	7	13	25	10	6
1235	P	0	5310-368-1908	GASKET, COVER WASHER, NONMETALLIC	73370 13446	EA		1	*	*	*	*	10	5
1236		0	5305-013-3083	NUT, PLAIN, SQUARE: OIL FILTER STRAP	73370 12398	EA		1	*	*	*	*	10	21
1237	X2	0	2940-732-4214	SCREW, MACHINE: OIL FILTER STRAP	73370 11563	EA		1	*	*	*	*	10	3
1238		0	5310-013-0542	STRAP: OIL FILTER MTG	73370 10124	EA		1	*	*	*	*	10	4
1239		0	5310-176-8160	WASHER, LOCK: OIL FILTER STRAP	66289 RF1301	EA		1	*	*	*	*	10	1
1240		0	4730-603-1470	NUT, PLAIN, HEXAGON: FILTER MTG	66289 RM1319G	EA		1	*	*	*	*	10	15
1241	X2	0	2940-542-3807	TEE, PIPE: OIL FILTER INLET	66289 PE4	EA		1	*	*	*	*	10	25
1242		0	5310-596-4911	TUBE ASSEMBLY, OIL		EA		1	*	*	*	*	10	2
1243				WASHER, LOCK: FILTER MTG										
1243A				GROUP 03 - FUEL SYSTEM										
1244	X2	0		0306 - TANKS, LINES, FITTINGS										
1245	X2	0		CLIP, FUEL LINE	82254 CFA40970	EA		1	*	*	*	*	*	*
1246	X2	0		NUT: CLIP SCREW	82254 CFA40974	EA		1	*	*	*	*	*	*
1247	X2	0	5310-595-7235	SCREW: CLIP MTG	82254 CFA40972	EA		1	*	*	*	*	*	*
				WASHER, LOCK: CLIP MTG	96906 MS35333-20	EA		1	*	*	*	*	*	*

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR W.A.S. NO.
1322	X1			2920-356-1221	SEAL: ROTOR SHAFT	EA		1					35	5
1323	X1			5310-794-8555	SPACER, GROUND SWITCH	EA		1					36	10
1324	X1				WASHER, FLAT: RETAINING DRIVE END BEARING	EA							35	14
1325	X1			5310-205-7981	WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA		1					35	14
1326	X1			5310-205-7981	WASHER: GREASE RETAINING INNER BEARING SUPPORT	EA		1					35	4
1327	X1				WASHER: GREASE RETAINING, OUTER BEARING SUPPORT	EA		1					35	18
1328	X1			5310-285-1591	WASHER: ROTOR SHAFT OUTER SEAL	EA		1					35	6
1329	P	O		2920-887-1289	CABLE, IGNITION: SPARK PLUG	EA		2	*	*	*	*	2	4
1330	X2	O			CLAMP, CABLE: SPARK PLUG WIRES	EA		2	*	*	*	*	2	1
1331	P	O		5305-013-1238	SCREW, MACHINE: CABLE CLAMP MTG	EA		2	*	*	*	*	2	3
1332	P	O		2920-841-1890	SPARK PLUG	EA		2	3	5	10	*	2	6
1333	P	O		5310-013-8542	WASHER, LOCK: CABLE CLAMP MTG	EA		1	*	*	*	*	2	2
1334	P	O		5330-599-5356	GASKET: SPARK PLUG	EA		2	*	2		3	2	5
1335					GROUP 22 - BODY CHASSIS OR HULL, AND ACCESSORY ITEMS									
1335A					2210 - DATA PLATES									
1336	X2	O			PLATE, INSTRUCTION: ENGINE OPERATING	EA		1	*	*	*	*	*	
1337	X2	O			PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*	*	
1338	X2	O			PLATE, NAME: MAGNETO	EA		1	*	*	*	*	*	
1339	X2	O		5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA		2	*	*	*	*	*	
1340					GROUP 57 - SPRAY EQUIPMENT COMPONENTS:									
1340A					5703 - AIR BLOWER ASSEMBLY									
1341	X2	O			ADAPTER: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*	
1342	X2	O			ELBOW: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*	
1343	X1	O			FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	32	32
1344	X1	O			BODY, FILTER	EA		1	*	*	*	*	32	32
1345	X2	O			ELEMENT, FILTER SILENCER	EA		1	*	*	*	*	32	32
1346	P	O		3740-542-3716	GASKET: ELEMENT TO BODY AND TOP	EA		2	*	*	*	*	32	32
1347	X2	O		5310-010-3129	NUT, PLAIN, WING: TOP TO BODY	EA		1	*	*	*	*	32	32
1348	X2	O			TOP ASSEMBLY	EA		1	*	*	*	*	32	32
1349	M	O			FELT: TOP ASSEMBLY	EA		1	*	*	*	*	32	32
1349A					MANUFACTURE FROM:				SEE GRP 9501	*	*	*	*	
1349A	P	O		5330-191-1096	FELT SHEET (7 IN BY 7 IN. REQUIRED)	SH		1	*	*	*	*	32	32
1350	P	O		5310-366-6294	WASHER, FLAT: TOP TO BODY	EA								
1351	P	O		5310-013-8542	WASHER, LOCK: TOP TO BODY	EA								

LINE NO.	(1) SOURCE, MAINT. AND RECV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	SOURCE	MAINT. AND RECV.					(a)	(b)	(c)	(d)	(c)	(b)	
													FIG. NO.
1352				5704 - SPRAY DUCTS AND MANIFOLDS	EA	1	*	*	*	*	*	34	2
1353	X2	0		MANIFOLD SPRAY ASSEMBLY	EA	5	*	*	*	*	*	34	10
1354	X2	0		CLAMP, DRUM	EA	1	*	*	*	*	*	34	11
1355	X2	0		ELBOW, LONG	EA	1	*	*	*	*	*	34	1
1356	X2	0		ELBOW, SHORT	EA	2	*	*	*	*	*	34	4
1357	X2	0		END CAP	EA	1	*	*	*	*	*	34	3
1358	X2	0		NOZZLE HEAD	EA	5	*	*	*	*	*	34	16
1359	X2	0		SCREW, TOGGLE: CLAMP DRUM CLAMPING	EA	10	*	*	*	*	*		
1360	X2	0		NOZZLE ASSEMBLY: SPRAY	EA	10	*	*	*	*	*		
1361	X1			HUB ASSEMBLY	EA	10	*	*	*	*	*		
1362	X1			IMPELLER: SPRAY NOZZLE	EA	10	*	*	*	*	*		
1363	X1			NUT, SELF-LOCKING, HEXAGON: FACE PLATE	EA	20	*	*	*	*	*		
1364	X1			SCREW, No. 4-40 THD SIZE	EA	10	*	*	*	*	*		
1365	X1			PLATE, FACE	EA	20	*	*	*	*	*		
				SCREW, MACHINE: FACE PLATE TO NOZZLE, No. 4-40 THD SIZE, 3/4 IN. LG	EA	20	*	*	*	*	*		
1366				5708 - TANKS, VALVES, LINES, HOSES, FITTINGS, AND LIQUID STRAINERS									
1367	X2	0		CLIP, HOSE	EA	2	*	*	*	*	*		
1368	X2	0		NUT, PLAIN, HEXAGON: CLIP MTG	EA	2	*	*	*	*	*		
1369	X2	0		SCREW, MACHINE: CLIP MTG, 6-32 x 1/2, RHD	EA	2	*	*	*	*	*		
1370		0		WASHER, LOCK: CLIP MTG	EA	2	*	*	*	*	*		
1371				GROUP 95 - GENERAL USE STANDARDIZED PARTS									
				9501 - BULK MATERIAL									
1371A				FELT SHEET	SH		*	*	*	*	*		
1372	P	0		5330-191-1096									

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.			(c) RECOV.	(a) 1-5			(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR NO.	
PART IV														
1373				GROUP 01 - ENGINE										
1373A				0102 - CRANKSHAFT										
1381				SHEAVE, CRANKSHAFT: BLOWER DRIVE										
1382	X2	O		82254 CFR0088	EA			1	*	*	*	*	*	*
1386				0106 - ENGINE LUBRICATION SYSTEM										
1387		O	4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA			1	*	*	*	*	*	10
1388		O		BOLT, MACHINE: FILTER MTG	EA			4	*	*	*	*	*	10
1389	X2	O	5306-543-4308	FILTER ASSEMBLY, OIL	EA			1	*	*	*	*	*	22
1390	X1	O		BODY ASSEMBLY	EA			1	*	*	*	*	*	10
1391	X2	O		COVER ASSEMBLY	EA			1	*	*	*	*	*	20
1392	X1	O		COVER, FILTER	EA			1	*	*	*	*	*	14
1393	X2	O	5330-056-9588	GASKET: FIBER	EA			1	*	*	*	*	*	10
1394	X1	O		HANDLE ASSEMBLY	EA			1	*	*	*	*	*	9
1395	X2	O		RING, SNAP	EA			1	*	*	*	*	*	7
1396	X2	O	5310-017-8620	WASHER, SHOULDERED	EA			1	*	*	*	*	*	10
1397	X2	O		SPRING, COMPRESSION	EA			1	*	*	*	*	*	11
1398	X2	O		WASHER, NONMETALLIC: COVER SCREW	EA			1	*	*	*	*	*	12
1399	P	O	5330-298-0776	FILTER ELEMENT, FLUID, PRESSURE: OIL	EA			1	2	7	13	25	10	8
1400	P	O	5310-368-1908	NUT, PLAIN, SQUARE: OIL FILTER STRAP	EA			1	*	*	*	*	*	5
1401	O	O	5305-013-3080	SCREW, MACHINE: OIL FILTER STRAP	EA			1	*	*	*	*	*	21
1402	X2	O		STRAP, BODY	EA			1	*	*	*	*	*	3
1403	O	O	5310-013-8542	WASHER, LOCK: OIL FILTER STRAP	EA			1	*	*	*	*	*	4
1404	P	O	5330-291-3409	WASHER, NONMETALLIC: COVER	EA			1	2	7	13	25	10	6
1405	P	O	2940-606-6816	HOSE ASSEMBLY, RUBBER: OIL LINE, PRESSURE	EA			1	*	*	*	*	*	24
1406	M	O		LINE ASSEMBLY, OIL: CRANKCASE TO GOVERNOR	EA			1	*	*	*	*	*	25
1406A				MANUFACTURE FROM:	EA			1						
1407	O	O	4730-011-6452	NUT, TUBE COUPLING	EA			2	*	*	*	*	*	1
1408	O	O	5310-176-8160	NUT, PLAIN, HEXAGON: FILTER MTG	EA			4	*	*	*	*	*	1
1409	P	O	4730-603-4470	TEE, PIPE: OIL FILTER INLET	EA			1	*	*	*	*	*	15
1410	P	O	4710-277-5525	TUBE, COPPER (6 1/2 IN. REQUIRED)	FT			1	SEE GRP 9501	*	*	*	*	2
1411	O	O	5310-596-4911	WASHER, LOCK: FILTER MTG	EA			4	*	*	*	*	*	
1411A				GROUP 03 - FUEL SYSTEM										
1412	X2	O	4730-639-9638	0309 - FUEL FILTERS	EA			1	*	*	*	*	*	16
1413	X1	O		STRAINER ASSEMBLY	EA			1	*	*	*	*	*	20
1414	P	O	2910-358-4317	BAIL ASSEMBLY	EA			1	*	*	*	*	*	19
1415	X1	O	2910-305-5749	BOWL, SEDIMENT, FUEL: GLASS	EA			1	*	*	*	*	*	16
1416	P	O	2910-358-5327	COVER, STRAINER	EA			1	*	*	*	*	*	16
				SCREEN, FUEL STRAINER	EA			1	*	*	*	*	*	17

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. CODE						(c) 1-5	(d) 6-20	(e) 21-50	(f) 51-100	(g) FIG. NO.	(h) ILLUSTRATION
1417	X1		2910-368-6657	VALVE, FUEL REGULATING: SHUT OFF	EA		1					16	21
1418	P	O	2910-282-7557	WASHER, NON-METALLIC: BOWL MTG	EA		1					16	18
1423				GROUP 06 - ELECTRICAL SYSTEM									
1424				0605 - IGNITION COMPONENTS									
1424				CABLE, SPECIAL PURPOSE	EA		2	*	*	*	*	2	4
1425	P	O	2920-566-7806	CLAMP, CABLE: SPARK PLUG WIRES	EA		1	*	*	*	*	2	1
1425	X2	O	5340-447-9222	MAGNETO ASSEMBLY	EA		1	*	*	*	*	22	
1426	P	O R	2920-800-8156	(INCLUDES COMPONENTS OF REPAIR KIT, STOCK No. 2920-712-1267)									
1427	X1		2930-353-6609	BEARING, SLEEVE: DRIVE CUP	EA		1					22	4
1428	X1		2920-374-3481	BEARING UNIT, BALL, CYLINDRICAL	EA		1					22	6
1429	X1		3110-144-8882	CARTRIDGE: ROTOR SHAFT	EA		1					22	5
1430	X1		2920-353-6611	BEARING, BALL ANNULAR: ROTOR	EA		1					22	57
1431	X1			RETAINER, BALL BEARING	EA		1					22	19
1432	X1		2920-367-7985	BRACKET, TERMINAL	EA		2					22	21
1433	X1		2920-335-4178	CLAMP, ELECTRICAL: COIL CORE	EA		1					22	22
1434	X1		4920-428-3751	COIL, MAGNETO	EA		1					22	33
1435	X1		2920-607-1324	CORE ASSEMBLY: MAGNETO COIL	EA		1					22	26
1436	X1		2920-366-6269	COUPLING, MAGNETO: IMPULSE ARM, TRIP	EA		1					22	35
1437	X1		2920-368-6715	CUP, MAGNETO DRIVE	EA		1					22	28
1438	X1		2920-740-2845	FLANGE, DRIVE GROUP	EA		1					22	31
1439	X1		2920-366-6306	NUT, IMPULSE LOCK	EA		1					22	24
1440	X1		2920-367-7999	RETAINER, DRIVE SPRING	EA		1					22	34
1441	X1			RING, LOCK: RETAINING, IMPULSE COUPLING	EA		1					22	27
1442	X1		2920-662-9135	SPACER, DRIVE FLANGE	EA		1					22	32
1443	X1		5340-353-6606	SPRING, SPIRAL, TENSION: IMPULSE COUPLING	EA		1					22	29
1444	X1		5340-740-2871	SPRING, TRIP ARM	EA		1					22	30
1445	X1		2920-740-2846	WASHER: DRIVE CUP SPACER	EA		1					22	25
1446	X1		5310-187-3458	WASHER, FLAT: DRIVE FLANGE	EA		1					22	16
1447	X1		5310-353-6620	WASHER, THRUST	EA		1					22	48
1448	X1		2920-787-0480	COVER, UNIT	EA		1					22	13
1449	X1			ROD GROUP, GROUND	EA		3					22	50
1450	X1		5305-276-7951	SCREW, MACHINE: TERMINAL BLOCK MTG	EA		2					22	15
1451	X1		2920-598-9432	SPRING, HELICAL, COMPRESSION	EA		1					22	14
1452	X1		5940-314-0255	TERMINAL BLOCK: HIGH-TENSION	EA		3					22	58
1453	X1		5310-013-5830	WASHER, LOCK: TERMINAL BLOCK MTG	EA		1					22	42
1454	X1		8305-740-2858	FELT, STRIP: BREAKER ARM	EA		1					22	3
1455	X1		5330-297-4578	GASKET: IMPULSE STOP	EA		1					22	
1456	X1		2920-360-8381	GASKET: MAGNETO MTG	EA		1					22	

(COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, GROUP 0100, PART 1)
(CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5846)

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDER. STOCK NUMBER	DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. RECOV.			(a) 1-5	(b) 6-20		(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ILLUSTRATION		
1457	X1			GEAR, DRIVE	EA		1					22	23
1458	X1		5310-012-0614	HOUSING, MAIN: MAGNETO	EA		1					22	11
1459	X1		2510-039-7699	LEAD, ELECTRICAL: BREAKER TO CAPACITOR	EA		1					22	55
1460	X1		2920-740-2873	NUT, PLAIN, HEXAGON: IMPULSE STOP	EA		1					22	38
1461	X1		5305-281-8308	SETScrew LOCKING	EA		1					22	37
1462	X1			PLATE, IMPULSE STOP	EA		1					22	10
1463	X1			PLATE, NAME: MAGNETO	EA		1	SEE GRP 2210				22	20
1464	X1			ROTOR	EA		1					22	56
1465	X1		5305-639-6026	SCREW, ASSEMBLED WASHER: BREAKER CLAMP, CONTACT MTO, CORE CLAMP MTO	EA		4					22	18
1466	X1		5305-335-1180	SCREW, ASSEMBLED WASHER: TERMINAL BRACKET MTO	EA		1					22	41
1467	X1		5305-121-2999	SCREW, DRIVE: NAMEPLATE MTO	EA		1					22	39
1468	X1		5305-022-5561	SCREW, MACHINE: COVER MTO	EA		2					22	8
1469	X1		5305-638-6834	SCREW, MACHINE: IMPULSE STOP CLAMP	EA		3					22	9
1470	X1		2920-353-6614	SETScrew: IMPULSE STOP	EA		4					22	17
1471	X1		2920-353-6610	SHIELD, BALL BEARING	EA		1					22	52
1472	X1		2920-353-6610	SPACER, SLEEVE: BEARING CAGE	EA		1					22	59
1473	X1		5310-275-1353	WASHER: COVER MTO	EA		1					22	51
1474	X1		5310-188-1185	WASHER, FLAT: BREAKER ARM PIVOT	EA		3					22	40
1475	X1		5310-351-0698	WASHER, FLAT: BREAKER POINT	EA		1					22	54
1476	X1			ALIGNING	EA		1					22	44
1477	X1		5310-012-1744	WASHER, FLAT: POINT ALIGNMENT	EA		1					22	46
1478	X1		5330-262-3306	WASHER, LOCK: IMPULSE STOP CLAMP	EA		1					22	49
1479	X1	O	5310-012-0377	WICK: CAM WIPER, FELT	EA		4					22	36
1480	P	O	2920-712-1267	NUT, PLAIN, HEXAGON: MAGNETO MTO	EA		1					22	12
1481	X1		2920-662-9133	REPAIR KIT, MAGNETO	EA		1					22	53
1482	X1		5910-740-2895	BEARING, SLEEVE: BREAKER PLATE	EA		1					22	43
1483	X1		2920-740-2882	CONDENSER, CAP	EA		1					22	1
1484	X1		2920-128-3830	CONTACT SET, DISTRIBUTOR	EA		1					22	3
1485	X1		2920-740-2892	DEFLECTOR, DIRT AND OIL	EA		1					22	10
1486	X1		5315-367-7954	GASKET: COVER, LEAD	EA		1					22	5
1487	X1		5340-281-6688	PIN, LOCK: BREAKER ARM	EA		1					22	2
1488	X1		2920-353-6618	RING, RETAINING: ROTARY BEARINGS	EA		1					22	22
1489	O		5305-514-9662	SEAL, PLAIN: OIL	EA		1					22	45
1490	O		5305-013-1238	SCREW, CAP, HEXAGON HEAD: MAGNETO MTO	EA		2					22	1
1491	P	O	2920-293-5212	SCREW, MACHINE: CABLE CLAMP ATTACHMENT	EA		2					22	3
1492	P	O	5330-599-5356	SPARK PLUG: 18 MM	EA		2					22	5
1493	O		5310-013-8542	GASKET: SPARK PLUG	EA		1					22	2
1494	O		5310-582-9930	WASHER, LOCK: CABLE CLAMP ATTACHMENT	EA		2					22	2
1495	O		5310-595-7237	WASHER, LOCK: MAGNETO MTO	EA		1					22	45
1495A				GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS									
1496	X2	O	2805-685-6019	2210 - DATA PLATES	EA		1						
				PLATE, INSTRUCTION: ENGINE OPERATION									

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY IN UNIT PACK	(6) QTY IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAIN						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM NO.
1497	X2	0		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*		
1498	X2	0		PLATE, NAME: MAGNETO	EA		1	*	*	*	*		
1499	0	0	5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA		2	*	*	*	*		
1500				GROUP 57 - SPRAY EQUIPMENT COMPONENTS									
1500A				5703 - AIR BLOWER ASSEMBLY									
1501	X2	0		FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	32	5
1502	X1	0		BODY, FILTER	EA		1	*	*	*	*	32	6
1503	X2	0		ELEMENT, FILTER SILENCER	EA		1	*	*	*	*	32	4
1504	P	0	3740-542-3716	GASKET: ELEMENT TO BODY AND TOP	EA		2	*	*	*	*	32	1
1505	0	0	5310-010-3129	NUT, PLAIN, WING: TOP TO BODY	EA		1	*	*	*	*	32	8
1506	X2	0		TOP ASSEMBLY	EA		1	*	*	*	*	32	7
1507	M	0		FELT: TOP ASSEMBLY	EA		1	*	*	*	*	32	
1507A	P	0	5330-191-1096	MANUFACTURE FROM: FELT SHEET	SH			SEE GRP 9501					
1508	0	0	5310-366-6294	(7 IN. BY 7 IN. REQUIRED)	EA		1	*	*	*	*	32	3
1509	0	0	5310-013-8542	WASHER, FLAT: TOP TO BODY	EA		1	*	*	*	*	32	2
1510				WASHER, LOCK: TOP TO BODY									
1510A				5704 - SPRAY DUCTS AND MANIFOLDS									
1511	X2	0		MANIFOLD SPRAY ASSEMBLY	EA		1	*	*	*	*		2
1512	X2	0		CLAMP, DRUM	EA		5	*	*	*	*	34	10
1513	X2	0		ELBOW, LONG	EA		1	*	*	*	*	34	11
1514	X2	0		ELBOW, SHORT	EA		1	*	*	*	*	34	1
1515	X2	0		END CAP	EA		2	*	*	*	*	34	4
1516	X2	0		NOZZLE HEAD	EA		1	*	*	*	*	34	1
1517	X2	0		NOZZLE TOGGLE: CLAMP DRUM CLAMPING	EA		5	*	*	*	*	34	3
1518	X2	0	3440-977-8672	SCREW, 1517	EA		10	*	*	*	*	34	16
1519				NOZZLE ASSEMBLY: SPRAY									
1519A				GROUP 76 - FIRE FIGHTING EQUIPMENT COMPONENTS									
1520	X2	0		7603 - FIRE EXTINGUISHERS									
1521	X2	0		BRACKET, MOUNTING: EXTINGUISHER	EA		1	*	*	*	*		
1522	X2	0		EXTINGUISHER, FIRE	EA		1	*	*	*	*		
1523	0	0	5310-616-6949	NUT, PLAIN, HEXAGON: BRACKET MTG	EA		4	*	*	*	*		
1524	X2	0	5305-010-0959	SCREW, MACHINE: BRACKET MTG	EA		8	*	*	*	*		
1525				WASHER, LOCK: BRACKET MTG									
1525A				GROUP 95 - GENERAL USE STANDARDIZED PARTS									
1526	P	0	5330-191-1096	9501 - BULK MATERIAL	SH								
				FELT SHEET									

LINE NO.	(1) SOURCE, MAINT. AND RECV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAIN	(c) RECV.						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM NO.
1527														
1527A														
1527B														
1535	X2	0							*	*	*	*	*	*
1536														
1537	X2	0							*	*	*	*	*	*
1540														
1541		0												
1542	X2	0							*	*	*	*	10	16
1543	X1	0							*	*	*	*	10	22
1544	X1	0							*	*	*	*	10	10
1545	X2	0							*	*	*	*	10	14
1546	X1	0							*	*	*	*	10	10
1547	X2	0							*	*	*	*	10	9
1548	X1	0							*	*	*	*	10	11
1549	X2	0							*	*	*	*	10	13
1550	X2	0							*	*	*	*	10	12
1551	X2	0							*	*	*	*	10	8
1552	P	0							2	7	13	25	10	23
1553	P	0							2	7	13	25	10	6
1554	P	0							*	*	*	*	10	5
1555		0							*	*	*	*	10	21
1556	X2	0							*	*	*	*	10	3
1557		0							*	*	*	*	10	1
1558		0							*	*	*	*	10	15
1559		0							*	*	*	*	10	25
1560		0							*	*	*	*	10	2
1561	X2	0							*	*	*	*	10	
1562		0							*	*	*	*	10	
1563														
1564	X2	0							*	*	*	*	*	*
1565	X2	0							*	*	*	*	*	*
1566	X2	0							*	*	*	*	*	*
1567		0							*	*	*	*	*	*

PART V

GROUP 01 - ENGINE

0100 - ENGINE ASSEMBLY

EXTENSION, OIL DRAIN

82254 CFA0975

0102 - CRANKSHAFT

SHEAVE, CRANKSHAFT: BLOWER DRIVE

71176 3TE60

0106 - ENGINE LUBRICATION SYSTEM

ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO

GOVERNOR OIL LINE

BOLT, MACHINE: FILTER MTG

FILTER, FLUID: PRESSURE

BODY, ASSEMBLY

COVER ASSEMBLY

COVER, FILTER

GASKET: FIBER

HANDLE ASSEMBLY

RING, SNAP

WASHER, SHOULDERS, HELICAL SPRING

SPRING, COMPRESSION

WASHER, NONMETALLIC: COVER SCREW

GASKET, COVER WASHER, NONMETALLIC

NUT, PLAIN, SQUARE: OIL FILTER STRAP

SCREW, MACHINE: OIL FILTER STRAP

STRAP: OIL FILTER MTG

WASHER, LOCK: OIL FILTER STRAP

NUT, PLAIN, HEXAGON: FILTER MTG

TEE, PIPE: OIL FILTER INLET

TUBE ASSEMBLY, OIL

WASHER, LOCK: FILTER MTG

GROUP 03 - FUEL SYSTEM

0306 - TANKS, LINES, FITTINGS

CLIP, FUEL LINE

NUT: CLIP SCREW

SCREW: CLIP MTG

WASHER, LOCK: CLIP MTG

82254 CFA0970

82254 CFA0974

82254 CFA0972

96906 MS35333-20

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.			(c) RECOV.	MANUFACTURER'S			(a)	(b)	(c)	(d)	(a)	(b)	
						CODE									PART NUMBER
1645	X1		5310-205-7981	WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA		1					35	4		
1646	X1		5310-205-7981	WASHER: GREASE RETAINING INNER BEARING SUPPORT	EA		1					35	4		
1647	X1			WASHER: GREASE RETAINING, OUTER BEARING SUPPORT	EA		1					35	18		
1648	X1		5310-285-1591	WASHER: ROTOR SHAFT OUTER SEAL	EA		1					35	6		
1649	P	O	2920-887-1289	CABLE, IGNITION: SPARK PLUG	EA		2					35	4		
1650	X2	O		CLAMP, CABLE: SPARK PLUG WIRES	EA		2					2	1		
1651	P	O	5305-013-1238	SCREW, MACHINE: CABLE CLAMP MTG	EA		2					2	3		
1652	P	O	2920-841-1890	SPARK PLUG	EA		2					2	6		
1653	P	O	5310-013-8542	WASHER, LOCK: CABLE CLAMP MTG	EA		1					2	2		
1654	P	O	5330-599-5356	GASKET: SPARK PLUG	EA		2					2	5		
1655				GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS											
1655A				2210 - DATA PLATES											
1656	X2	O		PLATE, INSTRUCTION: ENGINE OPERATION	EA		1								
1657	X2	O		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1								
1658	X2	O		PLATE, NAME: MAGNETO	EA		1								
1659	X2	O	5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA		2								
1660				GROUP 57 - SPRAY EQUIPMENT COMPONENTS											
1660A				5703 - AIR BLOWER ASSEMBLY											
1661	X2	O		ADAPTER: OVERBOARD OIL DRAIN	EA		1								
1662	X2	O	4730-230-1924	ELBOW: OVERBOARD OIL DRAIN	EA		1								
1663	X2	O		FILTER, SILENCER: AIR BLOWER	EA		1								
1664	X1	O		BODY, FILTER	EA		1								
1665	X2	O		BOLT, MACHINE: TOP	EA		1						1		
1666	X2	O		ELEMENT, FILTER STRAINER	EA		1						5		
1667	X2	O		TOP ASSEMBLY	EA		1						2		
1668	X2	O	5310-227-6566	WASHER, FLAT: TOP	EA		1						3		
1669				5704 - SPRAY DUCTS AND MANIFOLDS											
1670	X2	O		MANIFOLD SPRAY ASSEMBLY	EA		1						2		
1671	X2	O		CLAMP, DRUM	EA		5						10		
1672	X2	O		ELBOW, LONG	EA		1						11		
1673	X2	O		ELBOW, SHORT	EA		1						1		
1674	X2	O		END CAP	EA		2						4		
1675	X2	O		NOZZLE HEAD	EA		1						4		
1676	X2	O		SCREW, TOGGLE: CLAMP DRUM CLAMPING	EA		5						3		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.	(c) RECOV.			CODE	PART NUMBER		(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.	
1677	X2	0			NOZZLE ASSEMBLY: SPRAY	EA							34	16	
1678	X1				HUB ASSEMBLY	EA									
1679	X1				IMPELLER: SPRAY NOZZLE	EA									
1680	X1				NUT, SELF-LOCKING, HEXAGON: FACE		8225A CFA10961 8225A CFA10964 87373 ZW5139	10							
					PLATE SCREW			10							
1681	X1				PLATE, FACE	EA	8225A CFA10963	20							
1682	X1				SCREW, MACHINE: FACE PLATE TO NOZZLE, No. 4-40 THD SIZE, 3/4 IN. LG	EA	87373 ZW5155	10							
1683					5708 - TANKS, VALVES, LINES HOSES; FITTINGS AND LIQUID STRAINERS	EA	8225A CFA10962	20							
1684	X2	0			CLIP, HOSE	EA	8225A CFA10971	2							
1685	X2	0			NUT, PLAIN, HEXAGON: CLIP MTG	EA	8225A CFA10974	2							
1686	X2	0			SCREW, MACHINE: CLIP MTG, 6-32 x 1/2, RDHD										
1687		0		5310-595-7235	WASHER, LOCK: CLIP MTG	EA	8225A CFA10972 96906 MS3333-20	2							

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT		(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAIN	(c) RECOV.						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(c) FIG. NO.	(b) ITEM OR NO.
1688														
1688A														
1692														
1696	X2	O		0101 - CRANKCASE, BLOCK, CYLINDER HEAD EXTENSION, OIL DRAIN	EA		1		*	*	*	*		
1697														
1698	X2	O		0102 - CRANKSHAFT	EA		1		*	*	*	*		
1701														
1702				0106 - ENGINE LUBRICATION SYSTEM										
1703				ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA		1		*	*	*	*	10	16
1704	X2	O		BOLT, MACHINE: FILTER MTG	EA		1		*	*	*	*	10	22
1705	X1	O		FILTER, FLUID, PRESSURE	EA		1		*	*	*	*	10	10
1706	X2	O		BODY, ASSEMBLY	EA		1		*	*	*	*	10	20
1707	X1	O		COVER ASSEMBLY	EA		1		*	*	*	*	10	14
1708	X2	O		COVER, FILTER	EA		1		*	*	*	*	10	10
1709	X1	O		GASKET: FIBER	EA		1		*	*	*	*	10	9
1710	X2	O		HANDLE ASSEMBLY	EA		1		*	*	*	*	10	7
1711	X2	O		RING, SNAP	EA		1		*	*	*	*	10	11
1712	X2	O		WASHER, SHOULDERED	EA		1		*	*	*	*	10	13
1713	X2	O		SPRING, COMPRESSION	EA		1		*	*	*	*	10	12
1714	P	O		WASHER, NONMETALLIC: COVER SCREW	EA		1		*	*	*	*	10	8
1715	P	O		FILTER ELEMENT	EA		1		2	7	13	25	10	23
1716	P	O		GASKET, COVER WASHER, NONMETALLIC	EA		1		*	*	*	*	10	6
1717	X2	O		NUT, PLAIN, SQUARE: OIL FILTER STRAP	EA		1		*	*	*	*	10	5
1718	X2	O		SCREW, MACHINE: OIL FILTER STRAP	EA		1		*	*	*	*	10	21
1719				STRAP: OIL FILTER MTG	EA		1		*	*	*	*	10	3
1720				WASHER, LOCK: OIL FILTER STRAP	EA		1		*	*	*	*	10	1
1721				NUT, PLAIN, HEXAGON: FILTER MTG	EA		1		*	*	*	*	10	15
1722	X2	O		TEE, PIPE: OIL FILTER INLET	EA		1		*	*	*	*	10	25
1723				TUBE ASSEMBLY, OIL	EA		1		*	*	*	*	10	2
1723A				WASHER, LOCK: FILTER MTG										
1724				GROUP 03 - FUEL SYSTEM										
1725	X2	O		0309 - FUEL FILTERS										
1726	X1	O		STRAINER ASSEMBLY	EA		1		*	*	*	*	16	20
1727	P	O		BAIL ASSEMBLY	EA		1		*	*	*	*	16	19
1728	X1	O		BOWL, SEDIMENT: GLASS	EA		1		*	*	*	*	16	16
1729	P	O		COVER, STRAINER	EA		1		*	*	*	*	16	17
1730	X1	O		STRAINER ELEMENT, SEDIMENT	EA		1		*	*	*	*	16	21
1731	P	O		VALVE, FUEL REGULATOR: SHUT OFF WASHER, NONMETALLIC: BOWL MTG	EA		1		2	2		8	16	18

LINE NO.	SOURCE		(1) SOURCE, MAINT. AND RECOV. CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
									(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) SYM. OR NO.
1736					GROUP 05 - ELECTRICAL SYSTEM									
1736A					0505 - IGNITION COMPONENTS									
1737	P	O	R	2920-979-3504	MAGNETO (INCLUDES COMPONENTS OF REPAIR KIT, STOCK NO. 2920-844-2035) PLATE, NAME: MAGNETO	EA	1		*	*	*	*		
1743	X2	O			GASKET: MAGNETO MTG (COMPONENT OF GASKET SET, STOCK NO. 2805-720-1773, SEE GROUP 0100, PART 1)	EA	1		SEE GRP 2210				36	3
1778	X1			2920-360-8381	(CAN BE MANUFACTURED FROM PAPER, STOCK NO. 5330-233-5816)	EA	1							
1779	X2	O		2990-603-1773	GEAR, HELICAL: DRIVE	EA	1		*	*	*	*	36	1
1780		O		5310-012-0377	NUT, PLAIN, HEXAGON: MAGNETO MTG	EA	1		*	*	*	*	36	2
1781		O		5315-011-2766	PIN, COTTER: DRIVE GEAR	EA	1		*	*	*	*	36	23
1782		O		5305-514-9662	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG	EA	2		*	*	*	*	36	1
1783		O		5310-582-9930	WASHER, LOCK: MAGNETO MTG	EA	2		*	*	*	*	36	2
1784		O		5310-595-7237	WASHER, LOCK: MAGNETO MTG	EA	1		*	*	*	*	36	22
1785	P	O		2920-844-2035	REPAIR KIT, MAGNETO	EA	1		*	*	*	*	36	20
1786	X1			2920-142-1633	ARM, CONTACT SET, DISTRIBUTOR	EA	1		*	*	*	*	35	3
1787	X1			5340-598-3180	CLIP, RETAINING: ROTOR DRIVE SHAFT	EA	1		*	*	*	*	36	9
1788	X1			5340-675-5253	CLIP, RETAINING: SWITCH	EA	1		*	*	*	*	36	16
1789	X1			2910-217-3163	CONDENSER	EA	1		*	*	*	*	36	5
1790	X1			5305-281-6387	GASKET: END CAP	EA	1		*	*	*	*	36	8
1791	X1				SCREW, CAP END	EA	1		*	*	*	*	36	15
1792	X1				SEAL, CONDENSER	EA	1		*	*	*	*	35	5
1793	X1			2920-355-1221	SEAL: ROTOR SHAFT	EA	1		*	*	*	*	36	10
1794	X1				SPACER, GROUND SWITCH	EA	1		*	*	*	*	35	15
1795	X1			5310-794-8555	WASHER, FLAT: RETAINING: DRIVE END	EA	1		*	*	*	*	36	10
1796	X1			5310-205-7981	BEARING	EA	1		*	*	*	*	35	14
1797	X1				WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA	1		*	*	*	*	35	14
1798	X1				WASHER: GREASE RETAINING INNER BEARING	EA	1		*	*	*	*	35	14
1799	X1			5310-265-1591	SUPPORT	EA	1		*	*	*	*	35	14
1800	P	O		2920-887-1209	SUPPORT	EA	1		*	*	*	*	35	18
1801	X2	O			WASHER: ROTOR SHAFT OUTER SEAL	EA	2		*	*	*	*	35	16
1802	P	O		5305-013-1239	CABLE, IGNITION: SPARK PLUG	EA	2		*	*	*	*	2	4
1803	P	O		2920-841-1830	CLAMP, CABLE: SPARK PLUG WIRES	EA	2		*	*	*	*	2	1
1804	P	O		5310-013-6542	SCREW, MACHINE: CABLE CLAMP MTG	EA	2		*	*	*	*	2	3
1805	P	O		5330-599-5356	SPARK PLUG	EA	1		*	*	*	*	2	2
					WASHER, LOCK: CABLE CLAMP MTG	EA	2		*	*	*	*	2	5
					GASKET: SPARK PLUG	EA	2		*	*	*	*	2	5

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION					
	SOURCE	MAINT.						RECOV.	(a)	(b)	(c)	(d)	(a)	(b)			
															MANUFACTURER'S CODE	PART NUMBER	
1806				GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS													
1806A				2210 - DATA PLATES													
1807	X2	O		PLATE, INSTRUCTION: ENGINE OPERATION	EA		1	*	*	*	*	*	*				
1808	X2	O		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*	*	*				
1809	X2	O		PLATE, NAME: MAGNETO	EA		1	*	*	*	*	*	*				
1810	X2	O	5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA		2	*	*	*	*	*	*				
1811				GROUP 57 - SPRAY EQUIPMENT COMPONENTS													
1811A				5703 - AIR BLOWER ASSEMBLY													
1812	X2	O		ADAPTER: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*	*				
1813	X2	O		ELBOW: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*	*				
1814	X2	O		FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	*	*				
1815	X1	O		BODY, FILTER	EA		1	*	*	*	*	*	*				
1816	X2	O		BOLT, MACHINE: TOP	EA		1	*	*	*	*	*	*				
1817	X2	O		ELEMENT, FILTER STRAINER	EA		1	*	*	*	*	*	*				
1818	X2	O		TOP ASSEMBLY	EA		1	*	*	*	*	*	*				
1819	X2	O		WASHER, FLAT: TOP	EA		1	*	*	*	*	*	*				
1820			5310-227-6566	5704 - SPRAY DUCTS AND MANIFOLDS													
1821	X2	O		NOZZLE ASSEMBLY: SPRAY	EA		10	*	*	*	*	*	*				
1822	X1			HUB, ASSEMBLY	EA		10	*	*	*	*	*	*				
1823	X1			IMPELLER: SPRAY NOZZLE	EA		10	*	*	*	*	*	*				
1824	X1			NUT, SELF-LOCKING, HEXAGON: FACE													
1825	X1			PLATE SCREW	EA		20	*	*	*	*	*	*				
1826	X1			PLATE, FACE	EA		10	*	*	*	*	*	*				
1827	X2	O		SCREW, MACHINE: FACE PLATE TO NOZZLE, No. 1-10 THD SIZE, 3/8 IN. LG	EA		20	*	*	*	*	*	*				
1828	X2	O		CLAMP ASSEMBLY: NOZZLE ASSEMBLY	EA		3	*	*	*	*	*	*				
1829	X2	O		NOZZLE HEAD ASSEMBLY: SPRAY	EA		1	*	*	*	*	*	*				
1830	X2	O		BODY: NOZZLE HEAD	EA		1	*	*	*	*	*	*				
1831	X2	O		COVER: NOZZLE HEAD	EA		1	*	*	*	*	*	*				
1832	P	O	5330-956-4307	GASKET, LONG: COVER MTG	EA		2	*	*	*	*	*	*				
1833	X2	O	5330-925-0455	GASKET, SHORT: COVER MTG	EA		4	*	*	*	*	*	*				
1834	X2	O		SCREW, MACHINE: COVER MTG, 1/4-28 THD SIZE, 1/2 IN. LG	EA		28	*	*	*	*	*	*				
				WASHER, LOCK: COVER MTG, 1/4 I.T.	EA		28	*	*	*	*	*	*				
				8225A CFAH0961	EA			*	*	*	*	*	*				
				8225A CFAH0964	EA			*	*	*	*	*	*				
				87373 ZW5139	EA			*	*	*	*	*	*				
				8225A CFAH0963	EA			*	*	*	*	*	*				
				87373 ZW5155	EA			*	*	*	*	*	*				
				8225A CFAH0962	EA			*	*	*	*	*	*				
				8225A CFB55020	EA			*	*	*	*	*	*				
				8225A CFAH1536	EA			*	*	*	*	*	*				
				8225A CFAH1535-1	EA			*	*	*	*	*	*				
				8225A CFAH1535-5	EA			*	*	*	*	*	*				
				8225A CFAH1537	EA			*	*	*	*	*	*				
				8225A CFAH1538	EA			*	*	*	*	*	*				
				8225A CFAH1100	EA			*	*	*	*	*	*				
				96906 MS35333-25	EA			*	*	*	*	*	*				

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAIN	(c) RECOV.							(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM NO.
1835					GROUP 76 - FIRE FIGHTING EQUIPMENT COMPONENTS										
1835A					7603 - FIRE EXTINGUISHERS										
1836	X2	0			BRACKET, MOUNTING: FIRE EXTINGUISHER	EA			1	*	*	*	*		
1837	X2	0			EXTINGUISHER, FIRE	EA			1	*	*	*	*		
1838	X2	0			NUT, PLAIN, HEXAGON: BRACKET MTO, 1/4-20 THD SIZE	EA			2	*	*	*	*		
1839	X2	0			SCREW, MACHINE: BRACKET MTO, 1/4-20 x 1/2	EA			2	*	*	*	*		
1840	X2	0			WASHER, LOCK: BRACKET MTO, 1/4 IN. SCREW SIZE	EA			2	*	*	*	*		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ILLUSTRATION
1841				PART VII									
1841A				GROUP 01 - ENGINE									
1845				0101 - CRANKCASE, BLOCK, CYLINDER HEAD									
1849	X2	0		EXTENSION, OIL DRAIN	EA		1	*	*	*	*		
1850				0102 - CRANKSHAFT									
1851	X2	0		SHEAVE, CRANKSHAFT: BLOWER DRIVE	EA		1	*	*	*	*		
1854				0106 - ENGINE LUBRICATION SYSTEM									
1855		0	4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA		1	*	*	*	*	10	16
1856		0	5306-543-4308	BOLT, MACHINE: FILTER MTG	EA		1	*	*	*	*	10	22
1857	X2	0	2940-358-2436	FILTER, FLUID, PRESSURE	EA		1	*	*	*	*	10	20
1858	X1	0	2940-358-2536	BODY, ASSEMBLY	EA		1	*	*	*	*	10	14
1859	X2	0	2940-393-5988	COVER ASSEMBLY	EA		1	*	*	*	*	10	10
1860	X1	0		COVER, FILTER	EA		1	*	*	*	*	10	9
1861	X2	0	5330-056-9588	GASKET: FIBER	EA		1	*	*	*	*	10	7
1862	X1	0		HANDLE ASSEMBLY	EA		1	*	*	*	*	10	11
1863	X2	0		RING, SNAP	EA		1	*	*	*	*	10	13
1864	X2	0	5310-117-8620	WASHER, SHOULDERS	EA		1	*	*	*	*	10	12
1865	X2	0		SPRING, COMPRESSION	EA		1	*	*	*	*	10	8
1866	P	0	5330-298-0776	WASHER, NONMETALLIC: COVER SCREW	EA		1	2	7	13	25	10	23
1867	P	0	2940-141-9025	FILTER ELEMENT	EA		1	2	7	13	25	10	6
1868	P	0	5330-599-1205	GASKET, COVER WASHER, NONMETALLIC	EA		1	*	*	*	*	10	5
1869		0	5310-368-1908	NUT, PLAIN, SQUARE: OIL FILTER STRAP	EA		1	*	*	*	*	10	21
1870		0	5305-013-3083	SCREW, MACHINE: OIL FILTER STRAP	EA		1	*	*	*	*	10	3
1871	X2	0	2940-732-4214	STRAP: OIL FILTER MTG	EA		1	*	*	*	*	10	1
1872		0	5310-013-8542	WASHER, LOCK: OIL FILTER STRAP	EA		1	*	*	*	*	10	1
1873		0	5310-176-8160	NUT, PLAIN, HEXAGON: FILTER MTG	EA		1	*	*	*	*	10	15
1874		0	4730-603-4470	TEE, PIPE: OIL FILTER INLET	EA		1	*	*	*	*	10	25
1875	X2	0	2940-542-3807	TUBE ASSEMBLY, OIL	EA		1	*	*	*	*	10	2
1876		0	5310-596-4911	WASHER, LOCK: FILTER MTG	EA		1	*	*	*	*	10	
1877				GROUP 03 - FUEL SYSTEM									
1878				0309 - FUEL FILTERS									
1878	X2	0	4730-639-9638	STRAINER ASSEMBLY	EA		1	*	*	*	*	16	20
1879	X1	0	2910-382-8768	BAIL ASSEMBLY	EA		1	*	*	*	*	16	19
1880	P	0	2910-354-3834	BOWL, SEDIMENT: GLASS	EA		1	*	*	2	*	16	16
1881	X1	0	2910-305-5749	COVER, STRAINER	EA		1	*	*	*	*	16	16
1882	P	0	2910-142-2738	STRAINER ELEMENT, SEDIMENT	EA		1	*	*	*	*	16	17

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
								(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100		
	(a) SOURCE	(b) MAINT. RECOV.										MANUFACTURER'S CODE	PART NUMBER
1883	X1		2910-368-6657	VALVE, FUEL REGULATING: SHUT OFF	EA		1					16	21
1884	P	O	5330-187-2962	WASHER, NONMETALLIC: BOWL MTG	EA		1					16	18
1889				GROUP 06 - ELECTRICAL SYSTEM									
1889A				0605 - IGNITION COMPONENTS									
1890	P	O R	2920-979-3504	MAGNETO (INCLUDES COMPONENTS OF REPAIR KIT, STOCK No. 2920-844-2035)	EA		1	*	*	*	*		
1896	X2	O		PLATE, NAME: MAGNETO	EA		1	SEE GRP 2210				36	3
1931	X1		2920-360-8381	GASKET: MAGNETO MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100, PART 1) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5846)	EA		1						
1932	X2	O	2990-603-4773	GEAR, HELICAL: DRIVE	EA		1	*	*	*	*	36	4
1933	O	O	5315-011-2726	PIN, COTTER: DRIVE GEAR	EA		1	*	*	*	*	36	23
1934	O	O	5310-012-0377	NUT, PLAIN, HEXAGON: MAGNETO MTG	EA		1	*	*	*	*	36	24
1935	O	O	5305-514-5662	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG	EA		2	*	*	*	*	36	1
1936	O	O	5310-582-9930	WASHER, LOCK: MAGNETO MTG	EA		2	*	*	*	*	36	2
1937	O	O	5310-595-7237	WASHER, LOCK: MAGNETO MTG	EA		1	*	*	*	*	36	22
1938	P	O	2920-844-2035	REPAIR KIT, MAGNETO	EA		1	*	*	*	*	36	20
1939	X1		2920-142-1888	ARM, CONTACT SET, DISTRIBUTOR	EA		1					35	3
1940	X1		5340-598-3180	CLIP, RETAINING: ROTOR DRIVE SHAFT	EA		1					35	9
1941	X1		5340-675-5253	CLIP, RETAINING: SWITCH	EA		1					36	16
1942	X1			CONDENSER	EA		1					36	5
1943	X1		2920-217-3489	GASKET: END CAP	EA		4					36	8
1944	X1		5305-281-6387	SCREW, CAP END	EA		1					36	15
1945	X1			SEAL, CONDENSER	EA		1					35	5
1946	X1		2920-356-1221	SEAL: ROTOR SHAFT	EA		1					35	10
1947	X1			SPACER, GROUND SWITCH	EA		1					35	14
1948	X1		5310-794-8555	WASHER, FLAT: RETAINING DRIVE END BEARING	EA		1					35	4
1949	X1		5310-205-7981	WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA		1					35	18
1950	X1		5310-205-7981	WASHER: GREASE RETAINING INNER BEARING SUPPORT	EA		1					35	4
1951	X1			WASHER: GREASE RETAINING, OUTER BEARING SUPPORT	EA		1					35	4
1952	X1		5310-285-1591	WASHER: ROTOR SHAFT OUTER SEAL	EA		1					35	18
1953	P	O	2920-887-1289	CABLE, IGNITION: SPARK PLUG	EA		2	*	*	*	*	2	1
1954	X2	O		CLAMP, CABLE: SPARK PLUG WIRES	EA		2	*	*	*	*	2	1
1955	O	O	5305-013-1238	SCREW, MACHINE: CABLE CLAMP MTG	EA		2	*	*	*	*	2	3
1956	P	O	2920-841-1890	SPARK PLUG	EA		2	*	*	*	*	2	2
1957	O	O	5310-013-8542	WASHER, LOCK: CABLE CLAMP MTG	EA		1	*	*	*	*	2	2
1958	P	O	5330-599-5356	GASKET: SPARK PLUG	EA		2	*	*	*	*	2	5

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. AL W.				(8) ILLUSTRATION	
	(a) SOURCE	MAINT.							(c)	(d)	(e)	(f)		
		(b)	(c)											
									(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR NO.
1959					GROUP 22 - BODY CHASSIS OR HULL, AND ACCESSORY ITEMS									
1959A					2210 - DATA PLATES									
1960	X2	0			PLATE, INSTRUCTION: ENGINE OPERATION	EA		1	*	*	*	*		
1961	X2	0			PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*		
1962	X2	0			PLATE, NAME: MAGNETO	EA		1	*	*	*	*		
1963	X2	0		5305-335-1180	SCREW, DRIVE: NAMEPLATE MTO	EA		2	*	*	*	*		
1964					GROUP 57 - SPRAY EQUIPMENT COMPONENTS									
1964A					5703 - AIR BLOWER ASSEMBLY									
1965	X2	0			ADAPTER: OVERBOARD OIL DRAIN	EA		1	*	*	*	*		
1966	X2	0			ELBOW: OVERBOARD OIL DRAIN	EA		1	*	*	*	*		
1967	X2	0		1730-230-1924	FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	37	1
1968	X1	0			BODY, FILTER	EA		1	*	*	*	*	37	5
1969	X2	0			BOLT, MACHINE: TOP	EA		1	*	*	*	*	37	2
1970	X2	0			ELEMENT, FILTER STRAINER	EA		1	*	*	*	*	37	2
1971	X2	0			TOP ASSEMBLY	EA		1	*	*	*	*	37	3
1972	X2	0		5310-227-6566	WASHER, FLAT: TOP	EA		1	*	*	*	*	37	4
1973					5704 - SPRAY DUCTS AND MANIFOLDS									
1974	X2	0			NOZZLE ASSEMBLY: SPRAY	EA		10	*	*	*	*	34	16
1975	X1				HUB ASSEMBLY	EA		10	*	*	*	*		
1976	X1				IMPELLER: SPRAY NOZZLE	EA		10	*	*	*	*		
1977	X1				NUT, SELF-LOCKING, HEXAGON: FACE	EA		10	*	*	*	*		
1978	X1				PLATE SCREW	EA		20	*	*	*	*		
1979	X1				PLATE, FACE	EA		10	*	*	*	*		
1980	X2	0			SCREW, MACHINE: FACE PLATE TO NOZZLE, No. 1-40 THD SIZE, 3/4 IN. LG	EA		20	*	*	*	*	38	1
1981	X2	0			BODY: NOZZLE HEAD	EA		1	*	*	*	*		
1982	X2	0			CLAMP ASSEMBLY: NOZZLE ASSEMBLY	EA		3	*	*	*	*	38	4
1983	P	0			COVER: NOZZLE HEAD	EA		2	*	*	*	*	38	2
1984	P	0		5330-956-1306	GASKET, LONG: COVER MTO	EA		4	*	*	*	*	38	3
1985	X2	0		5330-925-0455	GASKET, SHORT: COVER MTO	EA		4	*	*	*	*	38	3
1986	X2	0			NOZZLE HEAD ASSEMBLY: SPRAY	EA		1	*	*	*	*	38	
1987	X2	0			SCREW, MACHINE: COVER MTO, 1/4-28 THD SIZE, 1/2 IN. LG	EA		28	*	*	*	*	38	6
					WASHER, LOCK: COVER MTO, 1/4 I.T.	EA		28	*	*	*	*	38	5

LINE NO.	(1) SOURCE, MAINT. AND RECVY. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. P. CTY GCGY. 100 EQUIP. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECVY.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
0001					SECTION IV - REPAIR PARTS FOR DS, GS, AND DEPOT MAINTENANCE PART I										
0002					GROUP 01 - ENGINE										
0002A					0100 - ENGINE ASSEMBLY										
0003	P	O		2805-720-4773	GASKET SET: ENGINE OVERHAUL	EA		1	2	4	8	100			
0004	X1			2940-774-4747	GASKET: AIR CLEANER BRACKET MTG	EA		1	SEE GRP 0304						
0005	X1			2910-358-4787	GASKET: CARBURETOR MTG	EA		1	SEE GRP 0301						
0006	X1			2805-366-6218	GASKET: CYLINDER BLOCK TO CRANKCASE	EA		1	SEE GRP 0101						
0007	X1			2805-360-8332	GASKET: CYLINDER HEAD	EA		1	SEE GRP 0101						
0008	X1				GASKET: ENGINE BASE TO CRANKCASE	EA		1	SEE GRP 0106						
0009	X1			2910-776-7900	GASKET: FUEL PUMP MTG	EA		1	SEE GRP 0302						
0010	X1			2805-776-8017	GASKET: GEAR COVER SPACER TO CRANKCASE	EA		1	SEE GRP 0105						
0011	X1			2805-776-8016	GASKET: GEAR COVER TO SPACER	EA		1	SEE GRP 0105						
0012	X1			2805-527-7732	GASKET: GOVERNOR MTG	EA		1	SEE GRP 0308						
0013	X1			2805-366-6270	GASKET: INTAKE AND EXHAUST MANIFOLD MOUNTING	EA		3	SEE GRP 0108						
0014	X1			2920-360-8381	GASKET: MAGNETO MTG	EA		1	SEE GRP 0605						
0015	X1			5330-292-1503	GASKET: MAIN BEARING, RETAINER PLATE, 0.003 IN. THK (AS REQUIRED) (1)	EA		1	SEE GRP 0102						
0016	X1			2805-366-9740	GASKET: MAIN BEARING, RETAINER PLATE, 0.006 IN. THK (AS REQUIRED) (2)	EA		2	SEE GRP 0102						
0017	X1			2805-919-3602	GASKET: OIL FILLER CAP	EA		1	SEE GRP 0106						
0018	X1			2805-776-8115	GASKET: OIL PUMP TO CRANKCASE	EA		1	SEE GRP 0106						
0019	X1			1650-663-4816	GASKET: TAPPET COVER PLATE	EA		2	SEE GRP 0105						
0022					0101 - CRANKCASE, BLOCK, CYLINDER HEAD										
0023	X2	H	R		CRANKCASE ASSEMBLY	EA		1							28
0027		O		4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA		1	SEE GRP 0106						
0028		O		5305-049-9608	BOLT, MACHINE: CYLINDER HEAD MTG	EA		15	PARTS II THRU VII						18
0029		O		5306-207-9166	BOLT, MACHINE: CYLINDER HEAD MTG	EA		1							12
0030		O		5306-021-5377	BOLT, MACHINE: SAFETY SWITCH AND CYLINDER HEAD	EA		1							9
0031	X1			2805-366-6218	GASKET: CYLINDER BLOCK TO CRANKCASE (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, SEE Group 0100)	EA		1							7
0032	X1			2805-360-8332	GASKET: CYLINDER HEAD (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, SEE Group 0100)	EA		1							13

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY IN UNIT PACK	(6) QTY IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTY/GC PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. OR NO.
0033	X1		2910-776-7900	GASKET: FUEL PUMP MTG (COMPONENT OF GASKET SET, STOCK NO. 2805-720-4773, SEE GROUP 0102) (CAN BE MANUFACTURED FROM PAPER, STOCK NO. 5330-233-5245)	EA		1	SEE GRP 0302						
0034	X2	F	2805-776-8078	NOZZLE, OIL SPRAY	EA		1	*	*	*	*	*	1	6
0035	H		5310-012-1949	NUT, PLAIN, HEXAGON: CYLINDER BLOCK TO CRANKCASE	EA		6	*	*	*	*	*	6	5
0036	F		5310-013-4556	NUT, PLAIN, HEXAGON: OIL SPRAY NOZZLE	EA		1	*	*	*	*	*	1	7
0037	X2	O	5330-542-1420	PACKING, PREFORMED: FUEL PUMP PRIMING SHAFT	EA		1	SEE GRP 0311						
0038	O		5315-753-3893	PIN, SPRING: PRIMER STOP	EA		1	*	*	*	*	*	1	29
0039	X2	H	5340-232-5723	PLUG, EXPANSION: CAMSHAFT END HOLE	EA		1	*	*	*	*	*	1	12
0040	X2	O	5340-276-5843	PLUG, EXPANSION: CAMSHAFT END HOLE	EA		2	*	*	*	*	*	1	9
0041	O		4730-585-2359	PLUG, PIPE: CRANKCASE OIL HOLES	EA		3	*	*	*	*	*	1	26
0042	O		5305-068-0502	SCREW, CAP, HEXAGON HEAD: FUEL PUMP MOUNTING	EA		2	SEE GRP 0302						
0043	X2	O	2910-776-7903	SHAFT ASSEMBLY, PRIMING	EA		1	SEE GRP 0311						
0044	X2	O	2910-347-5613	SPRING, HELICAL, TORSION: PRIMER HANDLE	EA		1	*	*	*	*	*	1	30
0045	H		5307-207-7377	STUD, PLAIN: CYLINDER BLOCK TO CRANKCASE	EA		6	*	*	*	*	*	1	5
0046	X1	O	5310-637-2400	TUBE, HEADER: CRANKCASE OIL WASHER, FLAT: CYLINDER HEAD MTG	EA		17	*	*	*	*	*	2	27
0048	H		5310-586-6696	WASHER, LOCK: CYLINDER BLOCK TO CRANKCASE	EA		6	*	*	*	*	*	6	6
0049	O		5310-261-7341	WASHER, LOCK: FUEL PUMP MTG	EA		2	SEE GRP 0302						
0050	F		5310-582-9926	WASHER, LOCK: OIL SPRAY NOZZLE	EA		1	*	*	*	*	*	1	8
0051	X2	O	2805-718-6972	CYLINDER HEAD	EA		1	*	*	*	*	*	2	8
0052	X1		5340-582-3078	INSERT, SPARK PLUG	EA		2	*	*	*	*	*	2	7
0053				0102 - CRANKSHAFT										
0054	O		5305-206-1071	BOLT, MACHINE: BLOWER DRIVE SHEAVE	EA		3	*	*	*	*	*	4	2
0055	X2	O		BUSHING, FLANGED: BLOWER DRIVE SHEAVE, 1 7/16 IN. ID	EA		1	*	*	*	*	*	4	3
0056	X2	H	2805-695-2181	CRANKSHAFT, ENGINE	EA		1	*	*	*	*	*	3	3
0057	A	H	3110-100-3904	BEARING, ROLLER, TAPERED: FLYWHEEL END	EA		1							
0058	P	H	3110-100-0802	CONE AND ROLLERS, TAPERED ROLLER BEARING: FLYWHEEL END	EA		1	*	*	*	*	*	3	4
0059	P	H	3110-554-3559	CUP, TAPERED ROLLER BEARING: FLYWHEEL END	EA		1	*	*	*	*	*	3	3

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTYCY	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.						(c) RECOV.	(a) 1-20	(b) 21-50			(c) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
0060	A	H		BEARING ASSEMBLY, ROLLER: TAKE-OFF END	EA		1								
0061	P	H	3110-100-3552	CONE AND ROLLERS, TAPERED ROLLER BEARING: TAKE-OFF END	EA		1	*	2	2	15	15	3	6	
0062	P	H	3110-293-8819	CUP, TAPERED ROLLER BEARING: TAKE-OFF END	EA		1	*	2	2	15	15	3	7	
0063	X2	F	5315-616-5523	GEAR, HELICAL: CRANKSHAFT, TIMING KEY, WOODRUFF: CRANKSHAFT GEAR, No. 8	EA		1	*	*	*	*	*	3	9	
0064	X2	F	2805-360-8345	SLINGER: CRANKSHAFT OIL, FLYWHEEL END	EA		1	*	*	*	*	*	3	1	
0065	X2	F	2805-366-9740	GASKET: MAIN BEARING RETAINER PLATE (AS REQUIRED) (2) (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, SEE GROUP 0100)	EA		1	*	*	*	*	*	3	20	
0066	X1			GASKET SET, Stock No. 2805-720-4773, SEE GROUP 0100	EA		2						1		
0067	X1		5330-292-1503	GASKET: MAIN BEARING RETAINER PLATE, 0.003 IN. THK (AS REQUIRED) (1) (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, SEE GROUP 0100)	EA		1						1	15	
0068		O	5315-952-3107	KEY, MACHINE: CLOVER DRIVE SHEAVE	EA		1	*	*	*	*	*	3	8	
0069	X2	F	5315-619-7342	KEY, WOODRUFF: FLYWHEEL, No. 23	EA		1	*	*	*	*	*	3	10	
0070	X2	O		NUT ASSEMBLY, CRANK	EA		1	*	*	*	*	*	4	14	
0071		F	5310-584-8731	NUT, PLAIN, HEXAGON: MAIN BEARING PLATE MTG	EA		4	*	*	*	*	*	1	19	
0072	X1		5310-692-8335	NUT, CRANK	EA		1	*	*	*	*	*	4	13	
0073		O	5315-276-5762	PIN, SPRING: CRANK NUT	EA		1	*	*	*	*	*	4	12	
0074		O	5315-271-3012	PIN, SPRING: SPRAY PUMP SHEAVE	EA		1	*	*	*	*	*	4	21	
0075	X2	H	2805-695-2180	PLATE ASSEMBLY, MAIN BEARING (INCLUDES CUP, Stock No. 3110-100-0556)	EA		1	*	*	*	*	*	1	18	
0076	X1		2805-695-2179	PLATE, BEARING RETAINER: MAIN BEARING	EA		1						1		
0077	P	H	2805-366-6238	RETAINER, PACKING: CRANKSHAFT MAIN BEARING	EA		1	*	2	2	20	100	1	16	
0078	P	H	2805-366-6240	SEAL: CRANKSHAFT MAIN BEARING	EA		1	*	2	2	20	100	1	17	
0079	X2	H	2805-366-6231	RETAINER, BEARING: FLYWHEEL END	EA		1	*	*	*	*	*	1	3	
0080		H	5305-958-5252	SCREW, MACHINE: GEAR END BEARING PLATE MOUNTING	EA		4	*	*	*	*	*	1	1	
0081	P	F	5330-641-2087	SEAL, PLAIN, ENCASED: CRANKSHAFT FRONT SHEAVE, CRANKSHAFT: SPRAY PUMP	EA		1	*	2	2	20	100	8	14	
0082	X2	O	2805-715-5327	SHIM: MAIN BEARING PLATE (AS REQUIRED)	EA		1	*	*	*	*	50	1	21	
0083	P	H	2805-715-5326	SHIM: MAIN BEARING RETAINER PLATE (AS REQUIRED)	EA		4	*	*	*	10	50	1	21	
0084	P	H	5307-207-7376	STUD, PLAIN: MAIN BEARING PLATE, TAKE-OFF	EA		2	*	*	*	10	50	1	14	
0085	P	H	5310-641-9308	WASHER, LOCK: CRANK NUT	EA		4	*	*	*	*	*	1	13	
0086	H		5310-596-4908	WASHER, LOCK: GEAR END BEARING PLATE MTG	EA		4	*	*	*	*	*	4	18	
0087	O		5310-261-7340	WASHER, LOCK: MAIN BEARING PLATE MTG	EA		4	*	*	*	*	*	1	2	
0088	H				EA		1	*	*	*	*	*	1	11	
0089	F				EA		4	*	*	*	*	*	1	11	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS.GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING 100 EQUIP. CTYGCY.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION				
	(a)	(b)	(c)						(a)	(b)	(c)			(a)	(b)			
																RECORD	MAIN	RECORD
0090					0103 - FLYWHEEL ASSEMBLY													
0091		O	5305-206-1071	BOLT, MACHINE: GENERATOR PULLEY TO FLYWHEEL	EA													
0092	X2	F	2805-767-9386	FLYWHEEL ENGINE	EA	4	*	*	*	*	*	*	4	2				
0093	X2	H	5305-017-9117	GEAR, SPUR	EA	1	*	*	*	*	*	*	4	7				
0094	X2	H	5305-017-9117	SETSCREW: RING GEAR	EA	3	*	*	*	*	*	*	4	4				
0095	X2	O	5310-012-0214	PULLEY, GENERATOR DRIVE	EA	1	*	*	*	*	*	*	4	5				
0096		O		WASHER, LOCK: GENERATOR PULLEY TO FLYWHEEL SCREW	EA	4	*	*	*	*	*	*	4	20				
0097				0104 - PISTONS, CONNECTING RODS										8				
0098	P	H	2805-715-0424	PISTON: STD (INCLUDES 2 EACH RING, Stock No. 5340-374-9707)	EA	2	*	*	2	10	20	5	4					
0099	X1		2805-554-1005	PIN, PISTON	EA	2	*	*	*	*	*	5	5					
0100	X2	H	2805-839-5276	PISTON ASSEMBLY: 0.020 IN. OVERSIZE (INCLUDES 2 EACH RING, Stock No. 5340-374-9707)	EA	2	*	*	*	*	*							
0101	X1		2805-554-1005	PIN, PISTON	EA	2	*	*	*	*	*							
0102	X2	H	2805-839-5275	PISTON ASSEMBLY: 0.040 IN. OVERSIZE (INCLUDES 2 EACH RING, Stock No. 5340-374-9707)	EA	2	*	*	*	*	*							
0103	X1		2805-554-1005	PIN, PISTON	EA	2	*	*	*	*	*							
0104	P	H	5340-374-9707	RING, RETAINING: PISTON PIN	EA	4	2	2	3	40	40	5	6					
0105	P	H	2805-608-4998	RING SET, PISTON: STANDARD	EA	2	2	3	5	60	20	5	1					
0106	X1		2805-529-8379	RING, PISTON: COMPRESSION, STANDARD	EA	2	*	*	*	*	*	5	3					
0107	X1			RING, PISTON: OIL STANDARD	EA	2	*	*	*	*	*	5	2					
0108	X1		2805-517-9809	RING, PISTON: SCRAPER, STANDARD	EA	2	*	*	*	*	*							
0109	X2	H	2805-388-6660	RING, SET: PISTON, 0.020 IN. OVERSIZE	EA	2	*	*	*	*	*							
0110	X1		2805-517-9810	RING, PISTON: COMPRESSION, 0.020 IN. OVERSIZE	EA	2	*	*	*	*	*							
0111	X1			RING, PISTON: OIL, 0.020 IN. OVERSIZE	EA	2	*	*	*	*	*							
0112	X1			RING, PISTON: SCRAPER, 0.020 IN. OVERSIZE	EA	2	*	*	*	*	*							
0113	X2	H	2805-388-6661	RING SET, PISTON: 0.040 IN. OVERSIZE	EA	2	*	*	*	*	*							
0114	X1		2805-528-5799	RING, PISTON: COMPRESSION, 0.040 IN. OVERSIZE	EA	2	*	*	*	*	*							
0115	X1			RING, PISTON: OIL, 0.040 IN. OVERSIZE	EA	2	*	*	*	*	*							
0116	X1			RING, PISTON: SCRAPER, 0.040 IN. OVERSIZE	EA	2	*	*	*	*	*							
0117	P	H	2805-339-5595	ROD ASSEMBLY, CONNECTING	EA	2	*	*	2	10	20	5	10					
0118	P	H	2805-571-1100	BEARING, SLEEVE	EA	4	3	5	10	120	400	5						

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.	
0119	P	H		2805-374-9710	BEARING, SLEEVE: PISTON PIN	EA		2	2	3	5	60	200	5	7	
0120	P	H		5306-514-8458	BOLT, SHOULDER: CONNECTING ROD	EA		4	*	*	2	8	10	5	8	
0121		H		5310-265-9214	NUT, PLAIN, HEXAGON: CONNECTING ROD BOLT	EA		4	*	*	*	*	*	*	5	11
0122	P	H		5310-514-7091	NUT, STAMPED: CONNECTING ROD BOLT	EA		4	3	5	10	120	120	5	12	
0123	X1				ROD, CONNECTING	EA		2						5	9	
0124					0105 - VALVES, CAMSHAFTS AND TIMING SYSTEM											
0125		F		5305-206-1071	BOLT, MACHINE: CAMSHAFT GEAR MTG	EA		3	*	*	*	*	*	*	7	3
0126	F	F		5305-049-9608	BOLT, MACHINE: GEAR COVER	EA		8	*	*	*	*	*	*	8	13
0127	F	F		5306-543-4308	BOLT, MACHINE: GEAR COVER TO SPACER PLATE	EA		2	*	*	*	*	*	*	8	8
0128		O		5306-206-9166	BOLT, MACHINE: VALVE INSPECTION PLATE MOUNTING	EA		1	*	*	*	*	*	*	2	12
0129	X2	H		2805-627-3467	CAMSHAFT, ENGINE	EA		1	*	*	*	*	*	*	7	10
0130	P	F		2805-374-9746	CAP, VALVE STEM	EA		4	2	2	3	40	40	6	11	
0131	X2	F			COVER, GEAR	EA		1	*	*	*	*	*	*	8	8
0132	X1	H			COVER	EA		1	*	*	*	*	*	*	8	3
0133		H		5340-050-1591	PLUG, EXPANSION: BREATHING HOLE	EA		1	*	*	*	*	*	*	8	12
0134		O		4730-278-3395	PLUG, PIPE: TIMING HOLE	EA		1	SEE QRP 0102							
0135	P	F		5330-641-2087	SEAL, PLAIN, ENCASED: CRANKSHAFT FRONT SHAFT, GOVERNOR DRIVE	EA		1	SEE QRP 0308							
0136	X2	F		2990-603-4775	GASKET: GEAR COVER SPACER TO CRANKCASE (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	EA		1						8	9	
0137	X1			2805-776-8017	GASKET: GEAR COVER TO SPACER (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	EA		1						8	5	
0138	X1			2805-776-8016	GASKET: GEAR COVER TO SPACER (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	EA		1						8		
0139	X1			1650-663-4816	GASKET: VALVE INSPECTION PLATE (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	EA		2						2	14	
0140	X2	F		2805-739-9927	GEAR, BEVEL: CAMSHAFT	EA		1	*	*	*	*	*	*	7	7
0141	X2	F		2805-574-9029	GEAR, HELICAL: CAMSHAFT	EA		1	*	*	2	20	120	3	2	
0142	P	F		2805-652-9757	GUIDE, ENGINE POPPET	EA		4	*	2	2	12	80	6	2	
0143	P	F		2805-309-8040	SEAT, VALVE	EA		4	*	*	*	*	*	7	3	
0145	F	F		5315-366-6242	PIN, STRAIGHT HEADED: CAMSHAFT	EA		1	*	*	*	*	*	*	1	4
0146	H			5315-251-9984	PIN, STRAIGHT, HEADLESS: GEAR COVER BOWEL	EA		2	*	*	*	*	*	*	1	
0147	X2	O		2805-708-9195	PIN, SUPPORT: GOVERNOR ADJUSTING SCREW AND VALVE INSPECTION PLATE	EA		1	*	*	*	*	*	*	2	17
0148	X2	F			PLATE, RETAINING: CAMSHAFT GEAR	EA		1	*	*	*	*	*	*	7	6
0149	X2	O		2805-360-8334	PLATE, VALVE, INSPECTION	EA		2	*	*	*	*	*	*	2	15

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING CTYGCY.	(9) DEPOT MAINT. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.				(c) 1-20	(b) 21-50			(c) 51-100	(a) FIG. NO.	(b) ITEM GR. NO.				
		(c) RECOV.	(b) MAINT.													
															MANUFACTURER'S	
						CODE	PART NUMBER									
0150	X2	F	F	2805-366-6248	PLUNGER, CAMSHAFT, THRUST	66289 PF101	EA	1	*	*	*	*	*	7	2	
0152	P	F	H	2805-528-6097	RETAINER, VALVE SPRING SEAT	96906 NS13997-1	EA	8	2	2	3	40	80	6	10	
0153				5305-068-0500	SCREW, CAP, NERACON HEAD: GEAR COVER											
0154	P	F	F	2805-339-5589	SPACER TO CRANKCASE	66289 XD4	EA	4	*	*	*	*	*	8	11	
0155	X2	H	H		SEAT, VALVE SPRING	65289 AG30	EA	4	*	*	2	8	40	6	9	
0156	X2	F	F	2805-366-6249	SPACER, GEAR COVER	65289 VE293151	EA	1	*	*	*	*	*	8	6	
0157	P	F	F	2805-730-6327	SPRING, HELICAL, COMPRESSION: CAMSHAFT	66289 PM108	EA	1	*	*	*	*	*	7	5	
0158	P	F	F	2805-528-6396	PLUNGER	65289 AF49C	EA	4	2	3	7	80	60	6	8	
0159	O	O	O	5310-221-3129	VALVE, POPPET, ENGINE: INTAKE AND EXHAUST	96906 NS13999-2	EA	4	2	2	3	40	60	6	1	
0160	F	F	F	5310-582-5926	WASHER, FLAT: VALVE INSPECTION PLATE	65289 PH14	EA	2	*	*	*	*	*	2	16	
0161	F	F	F	5310-012-0214	WASHER, LOCK: CAMSHAFT GEAR W/O, SCREW	66289 PE46	EA	3	*	*	*	*	*	7	4	
0162	H	H	H	5310-261-7341	WASHER, LOCK: GEAR COVER AND SPACER TO CRANKCASE SCREW		EA	10	*	*	*	*	*	8	7	
0163					CRANKCASE SCREW	66289 PE3	EA	4	*	*	*	*	*	8	10	
0165	X2	F	F	3110-100-6180	0105 - ENGINE LUBRICATION SYSTEM											
0166	X2	F	F		BALL, BEARING: CHECK	65289 ME38	EA	1	*	*	*	*	*	9	6	
0167	P	F	F	2805-695-2183	BASE, ENGINE: OIL PAN	65289 EB12604	EA	1	*	*	*	*	*	11	2	
0168	X1	X1	X1	3110-100-6180	BODY ASSEMBLY, OIL PUMP	65289 KA52151	EA	1	*	*	*	5	25	9		
0169	X1	X1	X1	2805-695-2186	BALL, BEARING: CHECK	65289 ME38	EA	1	*	*	*	*	*	9		
0170	X1	X1	X1	5340-570-5535	BODY, OIL PUMP	65289 KA5281	EA	1	*	*	*	*	*			
0171	X1	X1	X1	5340-570-5535	WASHER, BODY	65289 NF30	EA	1	*	*	*	*	*			
0172	X1	X1	X1	2805-741-0380	PLUG, EXHAUSTION: OIL PUMP	65289 SA91	EA	1	*	*	*	*	*			
0173	X1	X1	X1	5340-741-0246	RETAINER, BALL: PUMP OUTLET	65289 NF28	EA	1	*	*	*	*	*			
0175	X2	O	O	2805-560-9300	SPRING, HELICAL, COMPRESSION: CHECK	65289 PM165-1	EA	1	*	*	*	*	*	12	13	
0176	X2	F	F	2805-776-8114	BALL	65289 LO44C	EA	1	*	*	*	*	*	9		
0177	X2	F	F		BREATHER ASSEMBLY	65289 NF25	EA	1	*	*	*	*	*	9		
0178	O	O	O	4730-068-9388	CAP, PUSH ROD, PLUNGER	65289 NK178	EA	1	*	*	*	*	*	10	17	
0179	O	O	O	4730-640-5832	CUP, STRAINER	04255 J40022	EA	1	*	*	*	*	*	10	17	
0180	X2	H	H	4730-692-8775	ELEOD, PIPE: RETURN LINE TO BASE		EA	1	*	*	*	*	*	10	19	
0181	X2	O	O	2805-708-9194	ELBOW, PIPE TO TUBE: OIL FILTER	70170 49X4	EA	1	*	*	*	*	*	14	18	
0182	X1	X1	X1	4510-919-3101	OUTLET	65289 NF270-1	EA	1	*	*	*	*	*	1	24	
0183	X1	X1	X1	6680-718-7016	FILLER AND GAGE ASSEMBLY: LUBE OIL	65289 RI23	EA	1	*	*	*	*	*	1	22	
0184	X1	X1	X1	2805-919-3602	BODY, FILLER	65289 RS88	EA	1	*	*	*	*	*	1	23	
					GAGE AND CAP ASSEMBLY	66289 RJ15281	EA	1	*	*	*	*	*	1		
					GASNET: OIL FILLER CAP	65289 09715	EA	1	*	*	*	*	*	1		
					(COMPONENT OF GASNET SET, Stock No. 2805-720-4773, See Group 0100)											
0185	X2	O	O		NIPPLE, PIPE: FILLER GAGE	66289 LU310	EA	1	*	*	*	*	*	1	25	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTY. PLANNING	(9) DEPOT MAINT. 100 EQUIP.	(10) ILLUSTRATION	
	SOURCE	RECOV.						(a)	(b)	(c)			(a)	(b)
					MANUFACTURER'S									
					CODE	PART NUMBER								
0186	M	O		GASKET: CREATHER MTO MANUFACTURE FROM: PAPER, GASKET (2 IN. X 2 IN. REQUIRED)	EA		1						12	12
0202A	P	O	5330-270-8469	GASKET: ENGINE BASE TO CRANKCASE (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	YD		1	SEE GRP 950					11	1
0204	X1			GASKET: OIL PUMP TO CRANKCASE (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	EA		1						9	7
0205	X1		2805-776-8115	LINE ASSEMBLY, OIL: RETURN PLUG, PIPE: OIL DRAIN PLUNGER, OIL PUMP RETAINER, CHECK BALL ROD, PUSH, PLUNGER SCREW, CAP, HEXAGON HEAD: BASE TO CRANKCASE	EA		1			2	10		10	18
0211	P	O	2940-542-3807	SCREW, CAP, HEXAGON HEAD: OIL PUMP MTO	EA		1			*	*		11	5
0212	O		5340-147-3745	SPRING, HELICAL, COMPRESSION: PLUNGER STRAINER, OIL	EA		1			*	25		9	3
0213	P	F	2805-741-0242	WASHER, FLAT: BASE TO CRANKCASE SCREW	EA		1			*	10		9	3
0214	P	F	2805-741-0243	WASHER, LOCK: OIL PUMP MTO	EA		1			*	*		9	2
0215	X2	F	2805-536-8776	WASHER, STRAINER SPACER	EA		1			*	*		9	2
0216	X2	F		0107 - ENGINE STARTING SYSTEM	EA		2			*	*		11	6
0217	F		5305-068-0510	CRANK, WAD	EA		8			*	*		1	10
0218	F		5306-270-9734	GIC - MANIFOLDS	EA		3			*	*		9	12
0219	P	F	5340-147-3745	CLAMP WASHER: INTAKE AND EXHAUST MANIFOLD MTO	EA		1			*	*		9	4
0220	X2	F	2940-593-2293	GASKET: EXHAUST MANIFOLD MTO (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	EA		1			*	5		9	11
0222	X2	F	5310-530-9636	GASKET: INTAKE MANIFOLD MTO (COMPONENT OF GASKET SET, Stock No. 2805-720-4773, See Group 0100)	EA		2			*	*		11	7
0223	P	F	5310-261-7340	MANIFOLD, EXHAUST	EA		8			*	*		1	11
0225	P	F	5310-261-7341	MANIFOLD, INTAKE	EA		3			*	*		9	13
0226	X2	F	5330-684-7734	NUT, FLAIN, HEXAGON: INTAKE AND EXHAUST MANIFOLD MTO	EA		1			*	*		9	10
0227														
0228	X2	O			EA		1			*	*		4	17
0229														
0230		O	5310-776-8112		EA					*	*		16	3
0231	X1		2805-366-6270		EA		2			*	*		17	7
0232	X1		2805-366-6270		EA		1			*	*		16	6
0233	X2	O	2805-353-5889		EA		1			*	*		17	6
0234	X2	O	2805-776-8111		EA		1			*	*		16	5
0235		O	5310-012-6189		EA		2			*	*		16	1

LINE NO.	(1) SOURCE MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTY GCY. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.					(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
D236		0	4730-187-1200	PLUG, PIPE: INTAKE MANIFOLD	EA	1	*	*	*	*	*	16	28
D236A		0	5307-011-2572	STUD, PLAIN: MANIFOLD MTG	EA	2	*	*	*	*	*	6	12
D237		0	5310-637-9541	WASHER, LOCK: INTAKE AND EXHAUST MANIFOLD MTG	EA	2	*	*	*	*	*	16	2
D238				GROUP 03 - FUEL SYSTEM									
D238A				0301 - CARBURETOR									
D239		0	5306-018-0078	BOLT, MACHINE: CARBURETOR MTG	EA	2	*	*	*	*	*	16	4
D240	P	0	2910-715-5328	CARBURETOR, FLOAT (INCLUDES COMPONENTS OF GASKET SET, STOCK No. 2910-807-7153)	EA	1	*	*	2	10	15	16	23
D241		0	4730-287-3281	PLUG, PIPE: CARBURETOR BOWL DRAIN	EA	1	*	*	*	*	*	16	22
D242	X1		2910-358-4787	GASKET: CARBURETOR MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5847)	EA	1	*	*	*	*	*	16	26
D243		0	2910-807-7153	GASKET SET, CARBURETOR	EA	1			8	100	50	16	24
D244	X1		5330-362-1447	GASKET: BOWL TO BODY	EA	1	2	4					
D245	X1		5330-362-1447	WASHER, ADJUSTMENT: MAIN JET	EA	1							
D246	X1		5330-291-9873	WASHER, NONMETALLIC: DISCHARGE JET	EA	1							
D247	X1		5330-358-5683	WASHER, NONMETALLIC: MAIN JET	EA	1							
D248	X1		5330-729-5106	WASHER, SEAT: FUEL VALVE	EA	1							
D249		0	5310-596-4911	WASHER, LOCK: CARBURETOR MTG	EA	2	*	*	*	*	*	16	29
D250				0302 - FUEL PUMPS									
D251	X1		2910-776-7900	GASKET: FUEL PUMP MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5845)	EA	1						16	10
D252	P	0	2910-776-7902	PUMP, FUEL	EA	1	2	2	3	30	75	16	9
D253		0	5305-068-0502	SCREW, CAP, HEXAGON HEAD: FUEL PUMP MTG	EA	2	*	*	*	*	*	16	12
D254		0	5310-261-7341	WASHER, LOCK: FUEL PUMP MTG	EA	2	*	*	*	*	*	16	14
D255				0304 - AIR CLEANER									
D256	X2	0	2940-695-8797	AIR, CLEANER	EA	1	*	*	*	*	*	12	7
D257	X1			CUP ASSEMBLY, OIL	EA	1						12	5
D258	X1			FILTER AND CAP	EA	1						12	3
D259	P	0	5330-292-0320	GASKET: CAP AND FILTER MTG, FIBER	EA	1	*	*	2	10	100	12	4
D260	P	0	2940-366-9747	GASKET: FILTER MTG, CORK	EA	1	*	*	2	10	100	12	6

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. EN CTY GCV. 100 EQUIP.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAIN	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. NO.
0261		0		5306-531-1798	BOLT, MACHINE: BRACKET MTG	EA		2	*	*	*		*	12	10
0262	X2	0		2940-374-3084	BRACKET ASSEMBLY, AIR CLEANER	EA		1	*	*	*		*	12	9
0263	X2	0		4730-202-7160	CLAMP, HOSE: HOSE TO CARBURETOR RETAINING	EA		2	*	*	*		*	12	15
0264	X1			2940-774-4747	GASKET: AIR CLEANER BRACKET MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5846)	EA		1	*	*	*		*	12	14
0265	M	0			HOSE, PREFORMED, RUBBER: AIR CLEANER TO CARBURETOR MANUFACTURE FROM: HOSE, RUBBER (12 IN. REQUIRED)	EA		1	SEE GRP 9501					12	16
0265A	P	0		4720-218-5644	NUT, PLAIN, WING: AIR CLEANER COVER, SELF-LOCKING	FT		1	*	*	*		*	12	1
0266	0	0		5,10-366-6163	STUD: AIR CLEANER MTG STEEL	EA		1	*	*	*		*	12	8
0267	0	0		5307-025-7993	WASHER, LOCK: AIR CLEANER COVER MTG	EA		1	*	*	*		*	12	2
0268	0	0		5310-543-2705	WASHER, LOCK: BRACKET MTG	EA		2	*	*	*		*	12	11
0269	0	0		5310-596-4911	0306 - TANKS, LINES, FITTINGS										
0270					ADAPTER, STRAIGHT, PIPE TO TUBE: CARBURETOR TO FUEL LINE	EA		1	*	*	*		*	16	13
0271	0	0		4730-278-4323	ELBOW, PIPE TO TUBE: FUEL LINE TO FUEL PUMP	EA		1	*	*	*		*	16	11
0272	0	0		4730-640-5832	ELBOW, PIPE TO TUBE: TANK TO STARTER	EA		1	*	*	*		*	16	7
0273	0	0		4730-814-4132	LINE, FUEL: FUEL PUMP TO CARBURETOR MANUFACTURE FROM: NUT, TUBE COUPLING	EA		1	*	*	*		*	16	12
0274	M	0			TUBE, COPPER (8 IN. REQUIRED)	EA		2	SEE GRP 9501				*		
0274A	X2	0		4730-011-0452	LINE, FUEL, PLASTIC: TEFLON, 3/16 IN. ID, 1/4 IN. OD, 1/32 WALL THICK, 53 IN. LG	EA		1	*	*	*		*	13	2
0274B	P	0		4710-277-5525	MOUNT, FUEL TANK	EA		1	*	*	*		*	13	11
0275	P	0		4710-872-1781	NIPPLE, PIPE: FUEL STRAINER TO FUEL PUMP	EA		1	*	*	*		*	16	8
0276	X2	0		4730-277-5575	NUT, PLAIN, HEXAGON: STRAP CLAMPING AND TANK MTG	EA		6	*	*	*		*	13	9
0277	0	0		5310-584-5005	SCREW, CAP, HEXAGON HEAD: TANK MOUNT TO FRAME	EA		4	*	*	*		*	13	10
0278	0	0		5305-068-0502	SCREW, MACHINE: FUEL TANK STRAP CLAMPING	EA		2	*	*	*		*	13	7
0280	0	0		5305-988-1170	STRAP, STEEL: FUEL TANK HOLD DOWN TANK, FUEL: GASOLINE	EA		1	*	*	*		*	13	5
0281	X2	0		2910-816-4057	CAP, FUEL TANK	EA		1	*	*	*		*	13	3
0282	X2	0		2910-580-0607	WASHER, NONMETALLIC: FUEL TANK CAP	EA		1	*	*	*		*	13	4
0283	X2	0		2330-582-4084	PLUG, PIPE: TANK DRAIN	EA		1	*	*	*		*	13	12
0284	P	0		4730-011-8831		EA		1	*	*	*		*	13	

LINE NO.	(1) SOURCE, MAINT AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. AL W.			(8) 1-YR ALW. PLANNING 100 EQUIP. CLTSCY	(9) DEPT MAINT. 100 EQUIP. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION		
								(a) SOURCE	(b) MAINT	(c) RECOV			(a) FIG. NO.	(b) SYM. NO.	
	CODE	PART NUMBER													
0286	M	O		TUBE, SYPHON: FUEL TANK MANUFACTURE FROM: ELBOW, PIPE TO TUBE TUBE, COPPER (12 IN. REQUIRED) WASHER, LOCK: TANK MOUNT TO FRAME AND STRAP CLAMP SCREW	EA		1						13	1	
0286A		O	4730-814-4132		EA		1	*	*	*	*	*			
0286B	P	O	4710-277-5525		FT		1	SEE GRP 9501							
0287	O	O	5310-527-3289		EA		6	*	*	*	*	*		13	8
0288				0308 - ENGINE SPEED GOVERNOR AND CONTROLS											
0289	X2	O	2990-374-3163	CONTROL ASSEMBLY, GOVERNOR CHAIN, SINGLE JACK	EA		1	*	*	*	*	*	15	12	
0290	M	O		MANUFACTURE FROM: CHAIN, WELDLESS (10 IN. REQUIRED)	EA		1						15		
0290A	P	O	2990-085-9035	COLLAR ASSEMBLY	EA		1	*	*	*	*	*	15	14	
0291	X2	O	3750-678-6664	CONTROL, GOVERNOR	EA		1	*	*	*	*	*	15	17	
0292	X2	O	2805-536-8835	LEVER GOVERNOR CONTROL	EA		1	*	*	*	*	*	15	8	
0293	X2	O	5310-353-5895	NUT, SLEEVE: ADJUSTING	EA		1	*	*	*	*	*	15	7	
0294	O	O	5315-839-2325	PIN, COTTER: CHAIN CONTROL, LEVER PIN	EA		3	*	*	*	*	*	15	2	
0296	O	O	5315-012-1224	SCREW PIN	EA		1	*	*	*	*	*	15	11	
0297	O	O	5315-012-1224	PIN, COTTER: IN LEVER CHAIN END	EA		1	*	*	*	*	*	15	6	
0297	O	O	5315-366-6291	PIN, STRAIGHT, HEADLESS: GOVERNOR	EA		1	*	*	*	*	*	15	3	
0298	O	O	5315-272-6827	CONTROL LEVER	EA		1	*	*	*	*	*	15	5	
0299	X2	O		ADJUSTING	EA		1	*	*	*	*	*	15	10	
0300	O	O	5305-012-2159	RETAINER, SPRING	EA		1	*	*	*	*	*	15	13	
0301	O	O	5305-407-9163	SCREW, MACHINE: FOR COTTER PIN IN LEVER	EA		1	*	*	*	*	*	15	4	
0302	X2	O	2995-197-5863	SETSCREW: COLLAR STOP	EA		1	*	*	*	*	*	15	9	
0303	O	O	5310-366-6294	SPRING, HELICAL, COMPRESSION: SCREW	EA		1	*	*	*	*	*	15	12	
0304	P	O	2990-732-1179	ADJUSTING	EA		1	*	*	*	*	*	15	3	
0305	C	H	2990-366-6277	WASHER, FLAT	EA		1	*	*	*	*	*	15	4	
0306	C	H	5340-353-5960	GOVERNOR ASSEMBLY	EA		1	*	*	*	*	*	15	9	
0307	C	H	4730-692-8775	BUSHING, GOVERNOR GEAR	EA		1	*	*	*	*	*	15	12	
0308	C	H	2990-677-1771	CLEVIS, ROD END	EA		1	*	*	*	*	*	15	3	
0308A	X1		5315-663-1215	ELBOW, TUBE: GOVERNOR BODY TO OIL LINE	EA		1	SEE GRP 0106				*	14	8	
0309	X1		2805-527-7732	FLYWEIGHT ASSEMBLY: GOVERNOR	EA		2	*	*	*	*	*	14	5	
				PIN, STRAIGHT, HEADED: FLYWEIGHT	EA		2	*	*	*	*	*	14	8	
				GASKET: GOVERNOR MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, See Group 0100)	EA		1	*	*	*	*	*	14	5	
0310	C	H	2990-464-3619	GEAR, GOVERNOR: DRIVE	EA		1	*	*	*	*	*	14	13	
0311	C	H		HOUSING, GOVERNOR	EA		1	*	*	*	*	*	14	2	
0312	C	H	5330-640-9612	PACKING, PREFORMED: CROSS SHAFT AND LEVER	EA		1	*	*	*	*	*	14	16	
0314	H		5315-141-1651	PIN, SPRING: TO GOVERNOR FLYWEIGHT	EA		2	*	*	*	*	*	14	10	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTGY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT	(c) RECOV						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR SYM. NO.
0315	C	H		5315-221-6005	PIN, TAPERED, PLAIN: GOVERNOR YOKE	EA			*	*	*	*	*	14	4
0316	C	H		5340-276-5813	PLUG, EXPANSION: HOUSING	EA			*	*	*	*	*	14	1
0317	C	O		4730-585-2359	PLUG, PIPE: GOVERNOR HOUSING	EA			*	*	*	*	*	14	19
0318	C	H		2990-657-4467	SHAFT AND LEVER: CONTROL TO CARBURETOR	EA			*	*	*	*	*	14	15
0319	C	H		5310-276-2821	SLEEVE AND BEARING ASSEMBLY	EA			*	*	*	*	*	14	14
0320	C	H		5305-071-2237	WASHER, FLAT	EA			*	*	*	*	*	14	11
0321	O			5305-068-0502	SCREW, CAP, HEXAGON HEAD: GOVERNOR MTG	EA			*	*	*	*	*	14	7
0322	O			2990-603-4775	SCREW, CAP, HEXAGON HEAD: GOVERNOR MTG	EA			*	*	*	*	*	14	17
0323	X2	F		5330-187-3635	SHAFT, GOVERNOR DRIVE	EA			*	*	*	*	*	14	2
0324	X2	F		2990-739-9930	PACKING, PREFORMED: GOVERNOR SHAFT	EA			*	*	*	*	*	15	1
0325	X2	O		5310-543-2705	SPRING, GOVERNOR CONTROL	EA			*	*	*	*	*	14	1
0326	O				WASHER, LOCK: GOVERNOR MTG	EA			*	*	*	*	*	14	6
0335					0311 - ENGINE STARTING AIDS										
0336	X2	O		2910-776-7903	SHAFT ASSEMBLY, PRIMING	EA			*	*	*	*	*	1	32
0337	X2	O		5330-542-1420	PACKING, PREFORMED: FUEL PUMP PRIMING SHAFT	EA			*	*	*	*	*	1	31
0338					0312 - THROTTLE OR CHOKE CONTROLS										
0339	X2	O		2990-294-6749	CONTROL ASSEMBLY, PUSH-PULL: CHOKE	EA			*	*	*	*	*	15	16
0340	O			5310-010-7823	NUT, STAMPED: PUSHING RETAINER	EA			*	*	*	*	*	15	15
0341	O			5315-828-8190	PIN, COTTER: GOVERNOR CONTROL ROD TO CARBURETOR	EA			*	*	*	*	*	16	27
0342	X2	O			ROD, THROTTLE: CARBURETOR TO GOVERNOR	EA			*	*	*	*	*	16	25
0343					GROUP 04 - EXHAUST SYSTEM										
0343					0401 - MUFFLER AND PIPES										
0344	X2	O		5306-012-6078	BRACKET, MUFFLER	EA			*	*	*	*	*	17	8
0345	O				BOLT, MACHINE: LOWER SUPPORT TO MUFFLER BRACKET	EA			*	*	*	*	*	17	9
0346	X2	O			CAP, SPRING: LOWER SUPPORT CLAMP TO MUFFLER BRACKET	EA			*	*	*	*	*	17	17
0347	X1				CLAMP, SUPPORT: LOWER	EA			*	*	*	*	*	17	1
0348	X1				CLAMP, SUPPORT: UPPER	EA			*	*	*	*	*	17	1
0349	O			5310-584-5005	NUT, PLAIN, HEXAGON: UPPER CLAMP TO LOWER CLAMP	EA			*	*	*	*	*	17	14
0350	O			5310-045-1005	NUT, SELF-LOCKING, HEXAGON: LOWER SUPPORT TO MUFFLER BRACKET	EA			*	*	*	*	*	17	16
0351	O			5305-068-0500	SCREW, CAP, HEXAGON HEAD: UPPER CLAMP TO LOWER CLAMP	EA			*	*	*	*	*	17	2
0352	X2	O			SPRING, HELICAL, COMPRESSION: LOWER SUPPORT TO MUFFLER BRACKET	EA			*	*	*	*	*	17	10

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PLANNING CTYGCY. 100 EQUIP.	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	SOURCE	MAINT	RECOV			CODE	PART NUMBER			(a)	(b)	(c)			(a)	(b)
0353	X1	O		5310-527-3289	SUPPORT, MUFFLER BRACKET	EA			1						17	11
0354					WASHER, LOCK: UPPER CLAMP TO LOWER CLAMP	EA			2						17	15
0355		O		4730-221-3928	ELBOW, PIPE: EXHAUST PIPE TO MUFFLER	EA			1						17	14
0356	P	O		2990-141-9229	MUFFLER, EXHAUST	EA			1						17	3
0357	O			4730-278-3358	PIPE, PIPE: MUFFLER DRAIN	EA			1						17	18
0358	M	O			PIPE, EXHAUST	EA			1						17	5
0359	P	O		4710-162-0991	MANUFACTURE FROM:	EA										
0359	O			5305-063-0502	PIPE, STEEL (1 1/4 IN. REQUIRED)	EA										
0360		O		5310-595-5599	SCREW, CAP, HEXAGON HEAD: MUFFLER SUPPORT TO CANOPY	EA			2						17	13
0361					WASHER, FLAT: SUPPORT TO CANOPY MTG	EA			2						17	12
0361A					SUPPORT TO CANOPY	EA										
0361					GROUP 05 - COOLING SYSTEM											
0361					0502 - DEFLECTORS, SHROUDS											
0363	X2	O			CLIP, CABLE: SHIELD BOX TO AMMETER LEAD	EA			1						4	9
0364	X2	O		2990-776-8106	COVER, AIR SHROUD	EA			1						18	3
0365	X2	O			DEFLECTOR, HEAT	EA			1						18	4
0366	X2	O			SCREEN, FLYWHEEL	EA			1						18	19
0367	O			5305-988-1723	SCREW, MACHINE: AIR SHROUD TO BLOCK	EA			2						18	7
0368	O			5305-988-1726	SCREW, MACHINE: FLYWHEEL SCREEN MTG	EA			4						18	11
0369	O			5305-988-1721	SCREW, MACHINE: SHROUD MTG	EA			11						18	2
0370	O			5305-988-1725	SCREW, MACHINE: SHROUD TO BLOCK	EA			1						18	5
0371	X2	O			SHROUD, CYLINDER	EA			1						18	1
0373	O			5310-543-2705	WASHER, LOCK: FLYWHEEL SCREEN MTG	EA			4						18	10
0374	O			5310-261-7341	WASHER, LOCK: SHROUD MTG	EA			13						18	4
0376					GROUP 06 - ELECTRICAL SYSTEM											
0376A					0601 - GENERATOR											
0377	X2	O			ARM, STABILIZER: GENERATOR ADJUSTING	EA			1						19	26
0378	P	O		3030-528-4261	BELT, V: GENERATOR DRIVE	EA			1						19	20
0379	O			5306-680-6004	BOLT, MACHINE: ADJUSTING ARM TO GENERATOR AND FRAME	EA									19	27
0380	O			5305-206-1071	BOLT, MACHINE: GENERATOR MTG	EA			2						19	1
0381	P	O	R	2920-861-1320	GENERATOR, BATTERY CHARGING (INCLUDES COMPONENTS OF REPAIR, STOCK No. 2920-843-6741)	EA			2						19	1
0382	X1				ARMATURE, GENERATOR	EA			1						19	9
0383	X1			3110-144-8505	BEARING, BALL, ANNULAR: ARMATURE SHAFT DRIVE END HEAD	EA			1						19	15

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS.GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. PLANNING CTYGCY.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
									MANUFACTURER'S						
									CODE	PART NUMBER					
0384	X1				FAN, GENERATOR	EA		1	19728 PU2178					19	24
0385	X1				FRAME AND FIELD ASSEMBLY	EA		1	19728 GJP2001D					20	2
0386	X1				ARM, BRUSH HOLDER	EA		2	19728 GJC35A					19	3
0387	X1				BOLT, THRU; DRIVE HEAD TO COMMUTATOR END MTG	EA		2	19728 GY20C						
0388	X1				BUSHING; BRUSHHOLDER STUD	EA		1	19728 MGF25						
0389	X1				FIELD AND COIL ASSEMBLY	EA		1	19728 GJP1005D						
0390	X1				COIL, FIELD: LEFT SIDE	EA		1	19728 GJP1008B						
0391	X1				COIL, FIELD: RIGHT SIDE	EA		1	19728 GJP1007A						
0392	X1				STUD, TERMINAL: FIELD	EA		1	19728 GGU27A						
0393	X1				HOLDER AND TERMINAL, POSITIVE	EA		1	19728 GJC1034A						
0394	X1				HOLDER, BRUSH: GROUND BRUSH	EA		1	19728 GJC1033A						
0395	X1				INSULATION, BRUSH HOLDER	EA		1	19728 GJC39A						
0396	X1			5970-353-7172	INSULATOR, BUSHING; FIBER, TERMINAL STUD	EA		1	19728 GGU32						
0397	X1				NUT, PLAIN, HEXAGON; FIELD TERMINAL STUD	EA		2	19728 20X1377						
0398	X1				NUT, PLAIN, HEXAGON; POSITIVE TERMINAL STUD	EA		2	19728 20X1063						
0399	X1			5305-012-2159	RIVET, BRUSH HOLDER BRACKET MOUNTING	EA		2	19728 20X3389						
0400	X1			5305-272-4103	RIVET; BRUSH HOLDER MTG	EA		1	19728 20X3284						
0401	X1				SCREW, MACHINE: BRUSH LEAD ATTACHING	EA		2	19728 GK380					20	3
0402	X1				SCREW, MACHINE: POLE SHOE	EA		2	19728 XA928						
0403	X1				SHIELD ASSEMBLY: FIELD TERMINAL	EA		2							
0404	X1				SHIELD ASSEMBLY: POSITIVE BRUSH HOLDER TERMINAL	EA		1							
0405	X1				WASHER, FLAT; TERMINAL STUD, BRASS	EA		1	19728 XA929						
0406	X1			5310-013-8530	WASHER, LOCK; BRUSH LEAD ATTACHING	EA		1	19728 SW634D						
0407	X1			5310-209-1975	WASHER, LOCK; FIELD TERMINAL	EA		2	19728 12X195					20	4
0408	X1			5310-013-8542	WASHER, LOCK; POSITIVE TERMINAL STUD	EA		2	19728 12X196					19	18
0409	X1			5310-013-8542	WASHER, LOCK; THROUGH BOLT	EA		2	19728 12X199					19	4
0410	X1				WASHER, PLAIN; FIELD TERMINAL STUD, BRASS	EA		2	19728 12X199					19	4
0411	X1				HEAD ASSEMBLY; COMMUTATOR END	EA		1	19728 GGU31B						
0412	X1				COVER, BEARING	EA		1	19728 GJP2044A					19	5
0413	X1				OILER, COMMUTATOR END	EA		1	19728 GJC49B					19	31
0414	X1			5315-248-0003	PIN, STRAIGHT, HEADLESS; COMMUTATOR END, HEAD ALIGNING	EA		1	19728 X3279A					19	34
0415	X1				RETAINER, OIL	EA		1	19728 MN21B					19	6
0416	X1				WICK, OILER	EA		1	19728 GART5A					19	35
0417	X1				HEAD ASSEMBLY; DRIVE END	EA		1	19728 GJC46					19	33
0418	X1				HEAD: DRIVE END	EA		1	19728 GJP1102A						
0419	X1				GASKET; BEARING RETAINER	EA		1	19728 GJP102A					19	30
0420	X1			5315-248-0003	PIN, STRAIGHT, HEADLESS; HEAD, DRIVE END	EA		1	19728 GEE27					19	14
						EA		1	19728 MN21B					19	6

LINE NO.	(1) SOURCE MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT	(6) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. P. 100 EQUIP. CTY. PLANING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.					(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. OR NO.
0421	X1			RETAINER, BEARING	EA	1						19	13
0422	X1		5310-030-2007	RETAINER, FELT	EA	1						19	16
0423	X1		5305-208-6244	SCREW, MACHINE: BEARING RETAINER	EA	3						19	19
0424	X1		5310-043-2226	CADMIUM OR ZINC CHROMATE WASHER, LOCK: BEARING RETAINER, CADMIUM OR ZINC CHROMATE	EA	3						19	18
0425	X1		5315-616-5526	KEY, WOODRUFF: GENERATOR PULLEY No. 5	EA	1						19	10
0426	X1		5310-358-7423	NUT, PLAIN, HEXAGON: ARMATURE SHAFT	EA	1						19	21
0427	X1			OILER, DRIVE HEAD	EA	1						19	29
0428	X1		2920-778-6315	PULLEY, GENERATOR DRIVE	EA	1						19	23
0429	X1		6105-925-4976	RETAINER, ARMATURE	EA	1						19	12
0430	X1			SPACER, FAN	EA	1						19	25
0431	X1		5310-582-6520	WASHER, LOCK: PULLEY MTG	EA	1						19	22
0432	X1	0	5310-045-1005	NUT, SELF-LOCKING, HEXAGON: GENERATOR MOUNTING	EA	2	*	*	*	*	*	19	8
0433	P	F	2920-843-6741	REPAIR KIT, GENERATOR	EA	1	2	2	4	50	50	19	32
0434	X2	F	3120-774-4607	BEARING, BRONZE	EA	1	*	*	*	*	*	20	5
0435	X1		5977-710-2044	BRUSH SET	EA	1						19	11
0436	X1		5340-282-5560	RING, RETAINING	EA	1						20	1
0437	X1		5340-776-9921	SPRING, BRUSH	EA	2						19	17
0438	X1		5330-143-5192	WASHER, NONMETALLIC	EA	1						19	28
0439	X2	0		WASHER, CLAMP: GENERATOR TENSION ADJUSTING	EA	1	*	*	*	*	*	19	7
0440	X2	0		WASHER, FLAT: GENERATOR MTG	EA	1	*	*	*	*	*	19	2
0441	X2	0	5310-639-8061	WASHER, LOCK: GENERATOR MTG	EA	4	*	*	*	*	*	19	
0442				0602 - GENERATOR REGULATOR									
0443		0	5310-800-5282	NUT, PLAIN, HEXAGON: REGULATOR MTG	EA	2	*	*	*	*	*	26	17
0444	P	0	2920-785-6393	REGULATOR, VOLTAGE	EA	1	2	2	3	30	20	26	4
0445		0	5305-044-3507	SCREW, MACHINE: REGULATOR	EA	2	*	*	*	*	*	26	14
0446		0	5305-988-1725	SCREW, MACHINE: REGULATOR AND BOX MTG	EA	2	*	*	*	*	*	26	19
0447		0	5310-527-3289	WASHER, LOCK: REGULATOR MTG	EA	4	*	*	*	*	*	26	18
0448		0	5310-655-6314	WASHER, LOCK: REGULATOR MTG	EA	4	*	*	*	*	*	26	16
0449				0603 - STARTING MOTOR									
0450	X2	0		BRACKET, STARTER SUPPORT	EA	1	*	*	*	*	*	21	3
0451	X2	0		CABLE, ELECTRICAL: STARTER TO STARTER SWITCH	EA	1	*	*	*	*	*	21	9
0452	P	0	1015-298-8702	GASKET: BRACKET MTG, COPPER	EA	2	*	*	2	20	10	21	2
0453	P	0	2920-555-6315	MOTOR ASSEMBLY, STARTING 12 VOLT (INCLUDES COMPONENTS OF PARTS KIT, Stock No. 2920-710-6107)	EA	1	*	*	2	10	2	21	
0454	X1		2920-505-5108	ARMATURE, STARTER	EA	1						21	14

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30 DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTY GCSY.	(9) DEPT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR SYM. NO.
0455	X1		2920-353-7422	BAND, COVER ELECTRICAL BRUSH:	EA		1						21	11
0456	X1		2920-604-7773	STARTING MOTOR	EA		1						21	17
0457	X1		5305-353-7448	BEARING, SLEEVE: INTERMEDIATE	EA		1						21	21
0458	X1		2920-547-4335	BOLT, MACHINE: PINION HOUSING	EA		1						21	34
0459	X1		5306-286-1491	DRIVE, ENGINE, BENDIX	EA		1						21	31
0460	X1		2920-075-8025	BOLT, MACHINE	EA		1						21	33
0461	X1		5305-276-8864	HEAD, DRIVE	EA		1						21	29
0462	X1		2920-182-8527	SETScrew: SPRING TO DRIVE HEAD MTG	EA		1						21	30
0463	X1		5340-664-9187	SHAFT AND PINION ASSEMBLY	EA		1						21	32
0464	X1		5310-282-0483	SLEEVE: SERVICE	EA		1						21	4
0465	X1		5310-282-0483	SPRING, HELICAL, TORSION: DRIVE	EA		2						21	38
0466	X1		2920-353-7425	WASHER, KEY	EA		1						21	24
0467	X1			END BELL, ELECTRICAL ROTATING EQUIPMENT:	EA		1						21	18
0468	X1		2920-604-7774	COMMUTATOR END	EA		1						21	23
0469	X1		5330-559-6862	FRAME AND FIELD ASSEMBLY	EA		1						21	19
0470	X1		2920-604-7776	CAP, BEARING	EA		1						21	7
0471	X1		5315-012-4546	GASKET: INTERNAL BEARING	EA		1						21	12
0472	X1		5310-208-6994	HOUSING ASSEMBLY, PINION	EA		1						21	35
0473	X1		5310-012-0611	KEY, WOODRUFF: DRIVE END, No. 6	EA		1						21	8
0474	X1		5305-276-7956	NUT, PLAIN, HEXAGON: TERMINAL STUD	EA		2						21	20
0475	X1		5310-012-0611	NUT, PLAIN, SQUARE: COVER BAND	EA		1						21	15
0476	X1		5305-428-4750	SCREW, MACHINE: COMMUTATOR END HEAD	EA		1						21	25
0477	X1		5305-208-8263	SCREW, MACHINE: COVER BAND	EA		1						21	6
0478	X1		5319-596-4745	WASHER, LOCK: INTERNAL BEARING CAP	EA		2						21	5
0479	X1		5310-043-2226	WASHER, LOCK: PINION HOUSING HEAD SCREW, COMMUTATOR END	EA		8						21	36
0480	P	0	5310-701-6068	WASHER, SPRING TENSION	EA		1						21	26
0481	X1		2920-710-6107	PARTS KIT, ELECTRICAL ENGINE STARTER	EA		1						21	37
0482	X1		2920-294-4115	BEARING, SLEEVE: PINION HOUSING BRONZE	EA		1						21	16
0483	X1		5977-696-0221	BRUSH SET	EA		2						21	13
0484	X1		5977-391-4031	BRUSH	EA		2						21	1
0485	X1		5977-627-3579	BRUSH, GROUND	EA		2						21	28
0486	X1		2920-143-5298	DISK, SOLID, PLAIN: COMMUTATOR END	EA		1						21	21
0487	X1		5330-508-1111	HEAD ASSEMBLY	EA		1						21	36
0488	X1		5977-695-7139	SEAL, PLAIN, ENCASED: PINION HOUSING	EA		1						21	26
0489	X1		5310-514-8416	SPRING, SPIRAL, TORSION: BRUSH	EA		1						21	37
0490	X1		5305-291-5921	WASHER, FLAT: INTERNAL	EA		2						21	16
0491	X1		5305-068-0502	WASHER, NONMETALLIC: COMMUTATOR END	EA		2						21	13
0492	X2		5305-269-2804	SCREW, CAP, HEXAGON HEAD: BRACKET MTG	EA		3						21	1
				SCREW, CAP, HEXAGON HEAD: STARTER MTG	EA		3						21	28
				WASHER, LOCK: STARTER MTG	EA		3						21	27
				66289 TE5										

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. CTYCY. 100 EQUIP. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. RECOV.						(c) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. NO. OR
0565				0606 - ENGINE SAFETY CONTROLS										
0566	P	O	5930-797-0462	SWITCH, THERMOSTATIC: ENGINE SHUTOFF	EA		1	*	*	2	10	5	2	11
0567	M	O	2920-971-1451	WIRE, ASSEMBLY: IGNITION SWITCH TO TEMPERATURE SAFETY SWITCH	EA		1	*	*				23	4
0567A		O	5940-323-1459	MANUFACTURE FROM: TERMINAL, LUG: WIRE ATTACHING TO IGNITION SWITCH	EA		1	*	*	*	*	*		
0567B	P	O	5940-323-1459	TERMINAL, LUG: WIRE ATTACHING, TO TEMPERATURE SAFETY SWITCH, No. 14-18 AWG WIRE SIZE	EA		1	*	*					
0567C	P	O	6145-164-7023	WIRE, ELECTRICAL (3/4 IN. REQUIRED)	EA FT		1	*	*	2	10	10		
0568				0607 - INSTRUMENT OR ENGINE CONTROL PANEL					SEE GRP 950					
0569	P	O	6625-252-5545	AMMETER	EA		1	*	*	2	6	10	24	4
0570	X2	O		BOX, SWITCH, IGNITION	EA		1	*	*	*			23	6
0571	X2	O		CABLE, SHIELD: STARTER SWITCH TO AMMETER	EA		1	*	*	*				
0572	X2	O		COVER, SWITCH BOX	EA		1	*	*	*			24	5
0573	X2	O	5325-539-7143	GROMMET, RUBBER	EA		1	*	*	*			23	1
0574	X2	O	5970-656-7524	INSULATION: SWITCH BOX COVER	EA		1	*	*	*			23	5
0575	X2	O	2920-626-8302	LEAD ASSEMBLY, MAGNETO	EA		1	*	*	*			23	2
0576	X2	O	5310-584-5005	NUT, PLAIN, HEXAGON: STARTER SWITCH MTG	EA		1	*	*	*			24	3
0577	X2	O	5310-012-0622	NUT, PLAIN, HEXAGON: SWITCH BOX MTG	EA		2	*	*	*			23	8
0578	X2	O		PANEL, CONTROL	EA		1	*	*	*			24	3
0579		O	5305-068-0502	SCREW, CAP, HEXAGON HEAD: STARTER SWITCH MTG	EA		2	*	*	*			24	8
0580		O	5305-276-7951	SCREW, MACHINE: SWITCH BOX MTG	EA		2	*	*	*			23	10
0581		O	5305-959-4159	SCREW, TAPPING, THREAD FORMING: CONTROL PANEL MTG	EA		3	*	*	*			24	1
0582	P	O	2920-876-8346	SWITCH, IGNITION: PUSH AND PULL	EA		1	*	*	2	10	3	23	9
0583	X2	O	2920-444-8605	SWITCH, STARTER	EA		1	*	*	*			24	7
0584		O	5310-428-2137	WASHER, LOCK: MAGNETO LEAD TO SWITCH ATTACHING	EA		1	*	*	*			23	11
0585		O	5310-655-6314	WASHER, LOCK: STARTER SWITCH AND CONTROL PANEL MTG	EA		9	*	*	*			24	2
0586		O	5310-826-3773	WASHER, LOCK: SWITCH BOX MTG	EA		4	*	*	*			23	7
0587				0612 - BATTERIES, STORAGE										
0588	P	O	6140-057-2553	BATTERY, STORAGE: 6 CELL, 12V, 45 AMP	EA		1	*	*	*			25	4
0589	X2	O		CABLE, BATTERY, NEGATIVE	EA		1	*	*	*			25	1
0590	X2	O		CABLE, BATTERY, POSITIVE	EA		1	*	*	*			25	1
0591	X2	O		CLAMP, BATTERY HOLD DOWN	EA		1	*	*	*			25	5

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY IN UNIT PACK	(6) QTY IN UNIT	(7) 30-DAY DS-GS MAINT. ALW.			(8) 1-YR. ALW. PLANNING CTRY. 100 EQUIP. PER	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUS. TRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a)	(b)	(c)			(a) FIG. NO.	(b) ITEM OR SYM.
0592		O			NUT, PLAIN, HEXAGON: CLAMP MTG	EA		2	*	*	*	*	*	25	2
0593	P	O		5310-012-0377 6810-249-9354	SULFURIC ACID, ELECTROLYTE (As required)	GA			*	*	*	*	*	25	
0594		O		5310-595-7237	WASHER, LOCK: HOLD DOWN CLAMP MTG	EA		2	*	*	*	*	*	25	3
0595					0615 - RADIO INTERFERENCE SUPPRESSION										
0596	P	O		5910-127-7252	CAPACITOR: ARMATURE TERMINAL ON REGULATOR TO SHIELD BOX	EA		1	*	2	2	12	30	26	15
0597	M	O			LEAD, ELECTRICAL: AMMETER TO FEED THRU CAPACITOR	EA		1						26	10
0597A	P	O		2920-986-9691	MANUFACTURE FROM:	EA		2	SEE GRP 9501						
0597B	P	O		6145-164-7033	TERMINAL, LUG	EA		1	SEE GRP 9501						
0598	X2	O			WIRE, ELECTRICAL (14 IN. REQUIRED)	EA		1	*	*	*	*	*	26	11
0599	X2	O			LEAD ASSEMBLY, ELECTRICAL, SHIELDED: SHIELD BOX TO GENERATOR	EA		1	*	*	*	*	*	26	12
0600	M	O			LEAD ASSEMBLY, ELECTRICAL, SHIELDED: SHIELD BOX TO GENERATOR	EA		1	*	*	*	*	*	26	22
0600A	P	O		5940-321-9299	LEAD, ELECTRICAL: CAPACITOR TO ARMATURE TERMINAL ON VOLTAGE REGULATOR	EA		1							
0600B	P	O		6145-164-7033	MANUFACTURE FROM:	EA		2	SEE GRP 9501						
0601	O			5310-800-5282	TERMINAL, LUG	EA		1	*	*	*	*	*	26	17
0602	O			5305-044-3507	WIRE, ELECTRICAL (6 IN. REQUIRED)	EA		1	*	*	*	*	*	26	14
0603	O			5305-988-1725	NUT, PLAIN, HEXAGON: CAPACITOR MTG	EA		2	*	*	*	*	*	26	19
0604	X2	O		2920-627-0946	SCREW, MACHINE: CAPACITOR MTG	EA		1	*	*	*	*	*	26	
0605	X2	O		2920-627-0946	SHIELDING KIT: VOLTAGE REGULATOR	EA		1	*	*	*	*	*	26	
0606	X1			2920-654-3703	ADAPTER INSULATOR: BUSHING, LEAD ENTRANCE TO BOX	EA		2	*	*	*	*	*	26	13
0607	P	O		5910-677-5348	BASE ASSEMBLY	EA		1						26	6
0608	X1			2920-962-4598	CAPACITOR ASSEMBLY: FEED THRU, FIXED, PAPER DIELECTRIC, 2 UF, 50 AMP, 100 VOLT, DC	EA		1	2	2	2	12	30	26	7
0609	M	O		2920-986-9691	COVER, SHIELDING BOX	EA		1						26	1
0609A	P	O		2920-986-9691	LEAD ASSEMBLY: REGULATOR TO FEED THRU CAPACITOR	EA		1						26	5
0609B	P	O		6145-295-0804	MANUFACTURE FROM:	EA		2	SEE GRP 9501						
0610	X2			5310-333-6117	TERMINAL LUG	EA		2	SEE GRP 9501					26	21
0611					WIRE, ELECTRICAL (5 1/2 IN. REQUIRED)	EA		2	*	*	*	*	*	26	
0612	O			5305-012-0687	NUT, LOCK: ADAPTER MTG	EA		4	*	*	*	*	*	26	20
0613	O			5305-013-1899	NUT, PLAIN, HEXAGON: FEED THRU CAPACITOR MTG	EA		4	*	*	*	*	*	26	2
0614				5310-655-6314	SCREW, MACHINE: COVER TO BOX MTG	EA		4	*	*	*	*	*	26	9
					SCREW, MACHINE: FEED THRU CAPACITOR MOUNTING	EA		2	*	*	*	*	*	26	16
					WASHER, LOCK: CAPACITOR MTG	EA		2	*	*	*	*	*	26	

LINE NO.	SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	MANUFACTURER'S		(4) UNIT OF ISSUE	(5) QTY IN UNIT PACK	(6) QTY IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. P. 100 EQUIP. CTYGCY.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a)	(b)			CODE	PART NUMBER				(a)	(b)	(c)			(a)	(b)
0615		0	5310-527-3288	WASHER, LOCK: COVER TO BOX MTG	95875	616	EA		4	*	*	*	*	*	26	3
0616		0	5310-013-8526	WASHER, LOCK: FEED THRU CAPACITOR MTG	95875	617	EA		8	*	*	*	*	*	26	8
0617		0	5310-527-3289	WASHER, LOCK: REGULATOR BOX MTG	96906	MS35333-23	EA		2	*	*	*	*	*	26	18
0618				GROUP 15 - FRAME												
0618A				1501 - FRAME ASSEMBLY												
0619	X2	F		CHASSIS ASSEMBLY	82254	CFR40419	EA		1	*	*	*	*	*	27	20
0620	X2	F		BOLT, EYE: LIFTING, 1/2-13 THD SIZE	82254	CFR40423	EA		1	*	*	*	*	*	28	
0621	X2	F		BRACKET, CRANK BODY: SUPPORT FOR CRANK	82254	CFR40004	EA		1	*	*	*	*	*	4	15
0622	X1	F		CHASSIS, WELDMENT	82254	CFR40419-1	EA		1	*	*	*	*	*	27	8
0623	X2	F		RECEPTACLE: PANEL FASTENER, FRONT AND REAR	82254	CFR40421	EA		3	SEE GRP 990			*	*	27	9
0624		F	5320-118-1759	RIVET, SOLID: FASTENER AND RECEPTACLE MTG	82254	CFR40422	EA		8	*	*	*	*	*	27	6
0625		F	5325-281-3993	STUD, SNAP FASTENER: CURTAIN HOLD DOWN	82254	CFR40420	EA		6	*	*	*	*	*	27	7
0626	X2	F	5305-068-0500	FASTENER: HOSE STRAP MTG	81336	D13200E5370-20	EA		1	*	*	*	*	*	27	5
0627	F	F		SCREW, CAP, HEXAGON HEAD: BRACKET MTG	96906	MS35291-3	EA		3	*	*	*	*	*	4	16
0628	F	F	5310-013-8542	WASHER, LOCK: BRACKET MTG	96906	MS35338-25	EA		3	*	*	*	*	*	4	10
0629				GROUP 18 - BODY, CAB, HOOD AND HULL												
0629A				1801 - BODY, CAB, HOOD												
0630	X2	0		CANOPY ASSEMBLY	81336	D13200E5402	EA		1	*	*	*	*	*	28	17
0631	X2	0		DECK PLATE	81336	B13200E5417	EA		1	*	*	*	*	*	28	22
0632	X2	0		FLANGE, MUFFLER	81336	A13200E5427	EA		4	*	*	*	*	*	28	26
0633		0	5310-584-5005	NUT, PLAIN, HEXAGON: FLANGE MTG					4	*	*	*	*	*	28	21
0634		0	5305-068-0502	SCREW, MACHINE: FLANGE MTG					4	*	*	*	*	*	28	25
0635		0	5310-527-3289	WASHER, LOCK: FLANGE MTG					4	*	*	*	*	*	28	14
0636	X2	0		PANEL, FRONT	81336	B13200E5413	EA		1	*	*	*	*	*	28	12
0637	X2	0		GROMMET, FRONT PANEL	81336	B13200E5413-5	EA		8	*	*	*	*	*	28	11
0638	X2	0		RETAINER, FRONT PANEL	81336	B13200E5413-6	EA		8	*	*	*	*	*	28	13
0639	X2	0		STUD, FRONT PANEL	81336	B13200E5413-4	EA		8	*	*	*	*	*	28	4
0640	X2	0		PANEL, REAR	81336	B13200E5415	EA		8	*	*	*	*	*	28	3
0641	X2	0		GROMMET, REAR PANEL	81336	B13200E5415-5	EA		8	*	*	*	*	*	28	5
0642	X2	0		RETAINER, REAR PANEL	81336	B13200E5415-6	EA		8	*	*	*	*	*	28	3
0643	X2	0		STUD, REAR PANEL	81336	B13200E5415-4	EA		8	*	*	*	*	*	28	5
0644	X2	0		RECEPTACLE: PANEL LATCHING	82254	CFR40421	EA		14	SEE GRP 990			*	*	28	12
0645	X2	0	5320-118-1759	RIVET, SOLID: RECEPTACLE MTG	82254	CFR40422	EA		28	*	*	*	*	*	28	15
0646	X2	0		STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	81336	A13200E5423	EA		5	SEE GRP 1808			*	*	28	16
0647	X2	0		STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	81336	A13200E5424	EA		1	SEE GRP 1808			*	*	28	

LINE NO.	(1) SOURCE, MAINT AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTYCY. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) (c) MAINT. RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM NO.
0648	X2	0	5325-281-3993	STRAP, HOLD DOWN: MANIFOLD SUPPORT	EA		1	SEE GRP 1808		*	*	*	28	10
0649	0	0	5305-639-8115	STUD, SNAP, FASTENER: CURTAIN	EA		18	*	*	*	*	*	28	9
0650	0	0	5305-639-8115	SCREW, CAP, HEXAGON HEAD: CANOPY TO FRAME	EA		8	*	*	*	*	*	28	
0651	0	0	5305-012-0697	SCREW, MACHINE: CANOPY TO FRAME	EA		4	*	*	*	*	*	28	
0652				1808 - STRAPS										
0653	X2	0		STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	EA		2	*	*	*	*	*	28	1
0654	X2	0		STRAP, HOLD DOWN: ELBOW TO CANOPY MTG	EA		1	*	*	*	*	*	28	19
0655	X2	0		STRAP, HOLD DOWN: MANIFOLD TO CANOPY	EA		1	*	*	*	*	*	28	2
0656				GROUP 22 - BODY, CHASSIS OR HULL, AND ACCESSORY ITEMS										
0656A				2201 - CANVAS ITEMS										
0657	X2	0		CURTAIN ASSEMBLY	EA		2	*	*	*	*	*	28	8
0658	M	0	9320-771-1512	SHIM: CURTAIN STRIP TO DECK PLATE	EA		2	*	*	*	*	*	28	23
0658A	P	0	5330-505-6611	MANUFACTURE FROM: RUBBER SHEET, SOLID (16 IN. REQUIRED FOR EACH SHIM)	FT			SEE GRP 950						
0659	M	0	9320-771-1513	SHIM: CURTAIN STRIP TO DECK PLATE	EA		4	SEE GRP 950					28	24
0659A	P	0	5330-505-6611	MANUFACTURE FROM: RUBBER SHEET, SOLID (9 IN. REQUIRED FOR EACH SHIM)	FT			SEE GRP 950						
0660	M	0	3740-971-1418	STRIP, CURTAIN	EA		2						28	7
0660A	P	0	9515-554-0893	MANUFACTURE FROM: STEEL, STRIP, CARBON, HOT ROLLED (3 FT 1 IN. REQUIRED FOR EACH STRIP)	FT			SEE GRP 950						
0661	0	0	5310-584-5005	NUT, PLAIN, HEXAGON: CURTAIN MTG	EA		26	*	*	*	*	*	28	26
0662	X2	0		RECEPTACLE: CURTAIN HOLD DOWN STRAP	EA		13	*	*	*	*	*	28	18
0663	0	0	5320-118-1759	RIVET, SOLID: RECEPTACLE MTG	EA		26	*	*	*	*	*	28	16
0664	0	0	5305-068-0510	SCREW, CAP, HEXAGON HEAD: CURTAIN MTG	EA		26	*	*	*	*	*	28	9
0665	0	0	5310-327-3289	WASHER, LOCK: CURTAIN MTG	EA		26	*	*	*	*	*	28	25
0666				2210 - DATA PLATES										
0667	X2	0		LABEL SET, IDENTIFICATION	EA		1	*	*	*	*	*		
0668	X2	0		PLATE, IDENTIFICATION: AIR PRESSURE VALVE	EA		1	*	*	*	*	*		
0669	X2	0		PLATE, IDENTIFICATION: BY-PASS	EA		2	*	*	*	*	*		
0670	F		5310-616-6949	NUT, PLAIN, HEXAGON: CORPS OF ENGINEERS PLATE MTG	EA		4	*	*	*	*	*		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PLANNING CTY. 100 EQUIP. PER 20	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAIN	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR
0671	X2	F		9905-807-3712	PLATE, IDENTIFICATION: CORPS OF ENGINEERS, TYPE A	EA		1	*	*	*	*	*		
0672	X2	O			PLATE, IDENTIFICATION: FLOW CONTROL	EA		1	*	*	*	*	*		
0673	X2	O			PLATE, IDENTIFICATION: INSECTICIDE	EA		1	*	*	*	*	*		
0674	X2	O			PLATE, IDENTIFICATION: INTAKE	EA		1	*	*	*	*	*		
0675	X2	O		2920-447-9295	PLATE, IDENTIFICATION: NOZZLE	EA		1	*	*	*	*	*		
0676	X2	O			PLATE, INSTRUCTION: ON AND OFF	EA		1	*	*	*	*	*		
0679	X2	O			PLATE, NAME: BLOWER	EA		1	*	*	*	*	*		
0681	X2	O		5320-117-7106	RIVET, SOLID: IDENTIFICATION PLATES MTO	EA		14	*	*	*	*	*		
0682	X2	O			SCREW, DRIVE: BLOWER NAMEPLATE MTO	EA		6	*	*	*	*	*		
0684	X2	F		5305-010-0959	SCREW, MACHINE: CORPS OF ENGINEERS PLATE MOUNTING	EA		4	*	*	*	*	*		
0685	O				SCREW, TAPPING, THREAD CUTTING: PLATE MOUNTING	EA		4	*	*	*	*	*		
0686	F			5310-316-8887	WASHER, LOCK: CORPS OF ENGINEERS PLATE MOUNTING	EA		4	*	*	*	*	*		
0687					GROUP 47 - GAGES (NON-ELECTRICAL), WEIGHING AND MEASURING DEVICES										
0687A					4702 - GAGES, LINES AND FITTINGS										
0688	M	O			BRACKET, HOSE CLIP	EA		1						21	22
0688A	P	O		9515-529-0429	MANUFACTURE FROM: STEEL STRIP, CARBON, HOT ROLLED (3/4 IN. REQUIRED)	FT			SEE CRP 9501						
0689	X2	O		6690-704-1862	FLOWMETER	EA		1	*	*	*	*	*	33	39
0690	X1				BODY, METER	EA		1						33	71
0691	X1				FITTING, INLET	EA		1						33	34
0692	X1				FLOAT, OUT	EA		1	*	*	*	*	*	33	67
0693	X1	O		4730-044-4704	PLUG, PIPE: FLOWMETER BODY	EA		1						33	70
0694	X1				RING, O: INLET FITTING	EA		1						33	69
0695	X1				RING, O: INLET FITTING	EA		1						33	68
0696	X1			5330-806-7624	RING, O: INLET FITTING	EA		2						33	36
0697	X1				RING, O: OUT ADAPTER	EA		1						33	37
0698	X1				RING, OUT ADAPTING: BRASS	EA		1						33	38
0699	X1				STOP, FLAT	EA		1						33	35
0700	X1				TUBE, METER	EA		1						33	36
0701	X2	O		6685-855-7226	GAGE, PRESSURE: SCALE MARK 0 TO 100	EA		1	*	*	*	*	*	33	65
0702	X2	O			MANOMETER	EA		1						33	41
0703	X1				CLIP, SCALE	EA		1	*	*	*	*	*	33	
0704	X1				CLIP, SCALE	EA		1	*	*	*	*	*	33	
0705	X1				PLUG, VALVE, RING	EA		2	*	*	*	*	*	33	

LINE NO.	(1) SOURCE MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. PLANNING CTRYCY.	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. AND RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
0706	X1			SCALE TRAP, SAFETY	EA		1							
0707	X1			WELL AND TUBE	EA		2							
0708	X1			NUT, PLAIN, HEXAGON: MANOMETER MTG	EA		1					*	33	10
0709	O		5310-011-3102	NUT, PLAIN, HEXAGON: MANOMETER MTG	EA		1					*	33	24
0710	O		5310-012-0361	SCREW, MACHINE: MANOMETER MTG	EA		2					*	33	40
0711	O		5305-013-3648	SCREW, MACHINE: MANOMETER MTG	EA		2					*	33	42
0712	O		5305-043-6667	TUBE: AIR PRESSURE LINE FROM PRESSURE VALVE TO MANOMETER	EA		1					*	33	
0713	M			MANUFACTURE FROM:	EA									
0714	P		4710-809-8149	PLASTIC TUBING (8 IN. REQUIRED)	FT		1	SEE GRP 950						25
0715	M		3740-971-1419	MANUFACTURE FROM:	EA									
0716	P		4710-809-8149	PLASTIC TUBING (2 1/2 IN. REQUIRED)	FT									27
0717	X2			VALVE, NEEDLE: AIR PRESSURE, BOTH ENDS	EA		1					*	33	62
0718	O		5310-527-3288	WASHER, LOCK: MANOMETER MTG	EA		2					*	33	26
0719	O		5310-595-7235	WASHER, LOCK: MANOMETER MTG	EA		1					*	33	9
0720				GROUP 55 - PUMPS										
0721				5500 - PUMP ASSEMBLY										
0722	X2	F		CAP, PLUG	EA		1					*	29	25
0723	X2	F		CAP, PUMP	EA		1					*	29	29
0724	X2	F	4730-084-0469	DOWEL, HOUSING: CAP AND STAND LOCATING	EA		4					*	29	33
0725	X2	F	2805-641-7404	FITTING, LUBRICATION: CAP AND STAND	EA		3					*	29	13
0726	X2	F		GASKET: PLUG CAP	EA		1					*	29	26
0727	X2	F		HOUSING, PUMP	EA		1	SEE GRP 9901				*	29	32
0728	X2	F		NUT, PLAIN, HEXAGON: CAP TO HOUSING MTG, THD SIZE	EA		4					*	29	12
0729	X2	F	5310-012-0377	NUT, PLAIN, HEXAGON: PUMP AND SHIM MTG	EA		4					*	29	23
0730	X2	F	4730-044-4688	PLUG, PIPE: PUMP STAND	EA		2					*	29	19
0731	X2	F	5305-055-6314	PUMP ASSEMBLY, WATER	EA		1					*	29	40
0732	X2	F	5305-012-2181	SCREW, CAP, HEXAGON HEAD: CAP TO HOUSING MOUNTING	EA		6					*	29	
0733	X2	F		SCREW, CAP, HEXAGON HEAD: PUMP AND SHIM MOUNTING	EA		4					*	29	20
0734	X2	F		SHIM: PUMP MTG	EA		1					*	29	21
0735	X2	F	5310-595-7237	STAND, PUMP	EA		1					*	29	14
0736	X1	F		WASHER, LOCK: PUMP AND SHIM MTG	EA		4					*	29	22
0737				5501 - SHAFTS, ROTORS										
0738				BUSHING, GEAR: DRIVE AND DRIVEN GEAR, DRIVE	EA		4					*	29	15
0739					EA		1					*	29	16

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PM. CTY. 100 EQUIP. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.					(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. NO.
0737	X1	F	4320-972-8724	GEAR, DRIVEN	EA	1						29	17
0738	X2	F		GEAR SET, PUMP	EA	1						29	18
0739	X2	F		GLAND, PACKING: DRIVE GEAR	EA	1						29	5
0740	P	F	5330-793-1058	PACKING, PREFORMED: DRIVE GEAR	EA	1						29	5
0741	X2	F		RING, RETAINER: DRIVE GEAR	EA	1	2	2	3	30	30	29	7
0742	X2	F		RING, SEAL: DRIVE GEAR	EA	1						29	11
0743	F	F	5305-055-6313	SCREW, CAP, HEXAGON HEAD: GLAND TO STAND MOUNTING	EA	1						29	6
0744	X2	F		SEAL, PACK CUP: DRIVE GEAR	EA	2						29	4
0745	X2	F		SPRING, SEAL: DRIVE GEAR	EA	1						29	8
0746	X2	F		STOP, SEAL: DRIVE GEAR	EA	1						29	9
0747				5505 - SUCTION OR DISCHARGE SYSTEM	EA	1						29	10
0748	P	O	5330-793-1057	GASKET: RELIEF VALVE NUT	EA	1	SEE GRP 9901					29	26
0749	X2	O	4320-167-8216	PLUNGER, RELIEF VALVE	EA	1						29	28
0750	X2	O		SCREW, ADJUSTING: RELIEF VALVE, W/NUT	EA	1						29	24
0751	X2	O		SPRING, HELICAL, COMPRESSION: RELIEF PLUNGER	EA	1						29	27
0752				5507 - PUMP DRIVE									
0753	P	O	3030-542-3702	BELT, V: PUMP DRIVE	EA	1	2	2	3	30	100	29	39
0754	O	O	5306-207-9782	BOLT, MACHINE: BUSHING TO SHEAVE	EA	3						29	38
0755	X2	O		BUSHING, DRIVE SHEAVE	EA	1						29	2
0756	F	F	5315-050-5654	KEY, MACHINE: DRIVE GEAR SHAFT TO SHEAVE	EA	1						29	1
0757	X2	O		BUSHING SHEAVE, PUMP DRIVE	EA	1						29	3
0758				GROUP 57 - SPRAY EQUIPMENT									
0758A				5703 - AIR BLOWER ASSEMBLY									
0759	X2	O		AIR BLOWER ASSEMBLY	EA	1							8
0760	X2	H		BEARING, BALL: GEAR END	EA	3						31	8
0761	X2	H		BEARING, ROLLER: ROTOR SHAFT	EA	2						30	23
0762	P	O	3030-246-0152	BELT, V: BLOWER DRIVE, MATCHED SET OF 3	EA	1	2	2	3	30	100	31	8
0763	O	H	5306-639-8860	BOLT, MACHINE: BEARING RETAINER	EA	8						31	10
0764	O	O	5306-207-9782	BOLT, MACHINE: BUSHING TO SHEAVE	EA	3						31	22
0765	O	H	5306-576-0537	BOLT, MACHINE: END PLATE MTG	EA	14						30	11
0766	X2	F	5306-021-7004	BOLT, MACHINE: GEAR END COVER MTG	EA	14						31	28
0767	X2	O		BREATHER ASSEMBLY, VENTILATION	EA	1							
0768	X1	O		BASE, BREATHER	EA	1						31	37
0769	X2	O		ELEMENT, BREATHER	EA	1						31	38
0770			5305-013-2768	SCREW, MACHINE: SHIELD TO BASE MTG	EA	1						31	41

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION		(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS-GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUS-TRATION	
	(a) SOURCE	(b) MAINT.							(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR SM. NO.
									MANUFACTURER'S						
									CODE	PART NUMBER					
0771	X1	O	5310-013-0530	SHIELD, BREATHER	01510 568702B	EA		1	*	*	*	*	*	31	39
0772	X2	O		WASHER, LOCK: SHIELD TO BASE MTG	71176 P1-1-1-8	EA		1	*	*	*	*	*	31	40
0773	X1	O		BUSHING, PULLEY SHEAVE	01510 11703	EA		1	*	*	*	*	*	31	21
0774	X1	H		CAP, BEARING: FREE END PLATE	01510 11701	EA		1	*	*	*	*	*	31	26
0775	X2	H		COVER, GEAR END											
0776	X2	H		DOMEL, GEAR: LOCKPLATE AND SHIM											
0777	X2	O		ALIGNING	01510 6036	EA		2	*	*	*	*	*	31	13
0778	X2	O		FITTING, LUBRICATING: END PLATE	01510 90265	EA		2	*	*	*	*	*	30	13
0779	X2	F		FITTING, RELIEF	01510 90102	EA		2	*	*	*	*	*	30	3
0780	X2	F		GASKET: BEARING CAP, FREE END PLATE	01510 11705	EA		1	*	*	*	*	*	30	5
0781	P	O	3740-542-3717	GASKET: GEAR END COVER	01510 11322	EA		1	*	*	*	*	*	31	31
0782	X2	H		GASKET: INTAKE AND EXHAUST FLANGE	01510 7932	EA		2	2	3	5	60	30	28	
0783	X1	H		GEAR ASSEMBLY: TIMING	01510 60169	EA		1	*	*	*	*	*	31	11
0784	X2	H		HOUSING, ROTOR	01510 11512	EA		1	*	*	*	*	*	30	32
0785				KEY, GEAR: DRIVE GEAR AND DRIVEN GEAR, 1/4 IN. THK, 5/16 IN. WIDE, 7/8 IN. LONG	01510 11150	EA		2	*	*	*	*	*	30	19
0786	F	H	5315-050-5753	KEY, MACHINE: DRIVE SHAFT	01510 5871	EA		1	*	*	*	*	*	31	20
0787	H	H	5315-014-1244	NUT, PLAIN, HEXAGON: LOCK GEAR		EA		2	*	*	*	*	*	31	14
0788	H	H	5315-014-1242	PIN, STRAIGHT, HEADLESS: GEAR END COVER		EA		2	*	*	*	*	*	31	3
0789	X1	H		PIN, STRAIGHT, HEADLESS: HOUSING	01510 11429R	EA		1	*	*	*	*	*	30	27
0790	X1	F		PLATE, FREE END: BLOWER MTG	01510 11772R	EA		1	*	*	*	*	*	30	12
0791	X2	F		PLATE: GEAR END AND BLOWER MTG	01510 11739	EA		2	*	*	*	*	*	31	1
0792	X2	H		PLATE, LOCK: OIL RETAINER	01510 6038	EA		4	*	*	*	*	*	31	18
0793	X2	H		PLATE, LOCK: TIMING GEAR SCREW	01510 40325	EA		2	*	*	*	*	*	31	9
0794	X2	O		PLATE, NAME: BLOWER	01510 6459	EA		1	SEE CRP 221D	*	*	*	*	31	15
0795	X2	O		PLUG, MAGNETIC: OIL DRAIN, STEEL, 3/8-18 TMD SIZE	01510 90209	EA		1	*	*	*	*	*	31	27
0796	O	O	4730-044-4688	PLUG, PIPE: BEARING CAP		EA		2	*	*	*	*	*	30	10
0797	O	O	4730-044-4698	PLUG, PIPE: GEAR END PLATE		EA		6	*	*	*	*	*	31	5
0798	O	O	4730-044-5686	PLUG, PIPE: PLATE		EA		2	*	*	*	*	*	31	4
0799	X2	H		RETAINER, BEARING: GEAR END	01510 11140	EA		2	*	*	*	*	*	31	35
0800	X2	F		RING, BEARING RETAINER	01510 90259	EA		1	*	*	*	*	*	31	30
0801	X2	H		ROTOR, BLOWER	01510 11255	EA		2	*	*	*	*	*	30	18
0802	F	F	5305-543-2271	SCREW, CAP, HEXAGON HEAD: DRIVE SHAFT TO DRIVE GEAR		EA		4	*	*	*	*	*	31	19
0803	H	H	5305-018-1629	SCREW, CAP, HEXAGON HEAD: DRIVEN GEAR TO HUB	01510 1120	EA		4	*	*	*	*	*	31	16
0804	X2	O		SCREW, DRIVE: BLOWER NAMEPLATE MTG		EA		6	SEE CRP 221D	*	*	*	*	30	1
0805	F	F	5305-013-3098	SCREW, MACHINE: BEARING CAP MTG		EA		8	*	*	*	*	*	30	6
0806	H	H	5305-042-0699	SCREW, MACHINE: TO ROTOR SHAFT	01510 11600	EA		2	*	*	*	*	*	31	25
0807	X2	F		SEAL: DRIVE SHAFT GEAR END COVER		EA		1	*	*	*	*	*	31	9
0808	X2	H		SEAL: ROTOR SHAFT	01510 11443	EA		2	*	*	*	*	*	30	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM NO. OR SYM.
0809	X2	H		SEAL: ROTOR SHAFT	EA		2	*	*	*	*	*	31	7
0810	X2	F		SHAFT, DRIVE	EA		1	*	*	*	*	*	31	17
0811	X2	O	3020-877-1194	PULLEY, THREE GROOVE: BLOWER DRIVE	EA		1	*	*	*	*	*	31	24
0812	X2	H		SHIM; TIMING GEAR, BRASS	EA		1	*	*	*	*	*	31	12
0813	X1			SPACER, DOWEL: PLATE GEAR	EA		2	*	*	*	*	*	31	2
0814	X1			SPACER, RETAINER RING	EA		2	*	*	*	*	*	31	6
0815		H	5310-637-9541	WASHER, LOCK: BEARING CAP, END PLATE DRIVE AND COVER MTG	EA		22	*	*	*	*	*	30	2
0816		H		WASHER, LOCK: COVER MTG	EA		14	*	*	*	*	*	31	29
0817	X2	H	5310-637-9541	WASHER, LOCK: GEAR	EA		2	*	*	*	*	*	31	36
0818	X2	H		WASHER, ROTOR SHAFT	EA		2	*	*	*	*	*	30	7
0819	X2	O		BRACKET, BELT TENSION: BLOWER ALIGNMENT AND BELT ADJUSTING	EA		1	*	*	*	*	*	30	17
0820	O		5310-584-5005	NUT, PLAIN, HEXAGON: BELT TENSION	EA		2	*	*	*	*	*	30	16
0821	O		5305-637-4034	BRACKET	EA			*	*	*	*	*	30	15
0831	X2	O		SCREW, CAP, HEXAGON HEAD: BELT TENSION	EA		2	*	*	*	*	*	30	26
0832	X2	O		BRACKET	EA		1	*	*	*	*	*	30	3
0833	O		5305-637-4028	FLANGE: MANIFOLD MTG	EA		6	*	*	*	*	*	27	1
0834	O		5305-639-8115	GUARD ASSEMBLY, BELT	EA		1	*	*	*	*	*	27	4
0835	O		5310-011-5547	SCREW, CAP, HEXAGON HEAD: BELT GUARD	EA		7	*	*	*	*	*	27	2
0836	X2	O		SCREW, CAP, HEXAGON HEAD: BELT GUARD	EA		1	*	*	*	*	*	30	31
0837	O		5310-012-0377	MANIFOLD ASSEMBLY, INTAKE	EA		2	*	*	*	*	*	31	32
0838	O		5310-012-0377	NUT, PLAIN, HEXAGON: BLOWER TO FRAME	EA		2	*	*	*	*	*	30	33
0839	O		5305-639-8118	MOUNTING	EA		2	*	*	*	*	*	31	34
0840	O		5305-639-8118	SCREW, CAP, HEXAGON HEAD: BLOWER TO FRAME MTG	EA		2	*	*	*	*	*	30	14
0841	O		5305-638-9082	SCREW, CAP, HEXAGON HEAD: FLANGE	EA		2	*	*	*	*	*	30	24
0842	O		5305-550-1310	MANIFOLD MTG	EA		12	*	*	*	*	*	30	29
0843	O		5310-013-8542	SCREW, CAP, HEXAGON HEAD: INTAKE	EA		12	*	*	*	*	*	30	25
0844	O		5310-013-8542	WASHER, LOCK: BLOWER TO FRAME AND FLANGE TO HOUSING MTG	EA		16	*	*	*	*	*	30	33
0845	O		5310-595-7237	WASHER, LOCK: BLOWER TO FRAME MTG	EA		12	*	*	*	*	*	30	30
0855				WASHER, LOCK: INTAKE MANIFOLD MTG	EA		12	*	*	*	*	*	30	

5707 - INSTRUMENT PANEL

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. P. 100 EQUIP. CTY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
0886		0	4730-814-4132	ELBOW, PIPE TO TUBE: PRESSURE TUBE TO EXHAUST FLANGE	EA		1	*	*	*	*	*	30	20
0887	X2	0		ELBOW, PIPE TO TUBE: SPRAY NOZZLE, BRASS, ONE END FEMALE, 5/16-24 THD SIZE, OTHER END MALE, 1/8-27 THD SIZE	EA		2	*	*	*	*	*	34	19
0888		0	4730-814-4132	ELBOW, PIPE TO TUBE: SPRAY TO CROSS HOSE: BY-PASS TO SUPPLY TANK, PLASTIC, 10 FT LG	EA		2	*	*	*	*	*	34	13
0889	X2	0		HOSE: INTAKE, SUCTION MANUFACTURE FROM:	EA		1	*	*	*	*	*	33	72
0890	M	0		HOSE, RUBBER (10 FT REQUIRED)	EA		1	*	*	*	*	*	33	54
08904	P	0	4730-289-4869	LOCKNUT, PIPE: AIR PRESSURE VALVE TO MANOMETER	FT			SEE CRP 9500						
0992		0	4730-014-4574	LOCKNUT, PIPE: CLOSE NIPPLE TO SPRAY MANIFOLD	EA		2	*	*	*	*	*	33	4
0993		0	4730-014-4574	LOCKNUT, PIPE: NIPPLE LOCKING	EA		2	*	*	*	*	*	34	18
0994		0	4730-014-4574	LOCKNUT, PIPE: SUCTION HOSE CONNECTOR AT LINE STRAINER	EA		2	*	*	*	*	*	30	22
0995		0	4730-390-0138	LOCKNUT, PIPE: THREE-WAY VALVE, BY-PASS, FLOW CONTROL	EA		1	*	*	*	*	*	33	55
0996		0	4730-014-4575	NIPPLE, PIPE: FLOW CONTROL ELBOW	EA		5	*	*	*	*	*	33	28
0997		0	4730-188-1854	NIPPLE, PIPE: FLOW CONTROL VALVE TO TEE	EA		1	*	*	*	*	*	33	56
0998		0	4730-196-1974	NIPPLE, PIPE: FLOW METER	EA		1	*	*	*	*	*	33	66
0999		0	4730-293-3593	NIPPLE, PIPE: PRESSURE TUBE ELBOW TO EXHAUST FLANGE	EA		2	*	*	*	*	*	33	33
1000		0	4730-230-1996	EXHAUST FLANGE	EA		1	*	*	*	*	*	30	23
1001		0	4730-230-1996	NIPPLE, PIPE: SPRAY MANIFOLD	EA		2	*	*	*	*	*	34	17
1002	X2	0		NIPPLE, PIPE: TEE TO BUSHING	EA		1	*	*	*	*	*	29	34
1003	X2	0		NIPPLE, PIPE: THREE WAY VALVE, 1/4-18 THD SIZE, 1 5/8 IN. LG, SPECIAL	EA		2	*	*	*	*	*	33	60
1004		0	5305-276-7951	SCREW, MACHINE: TO HOSE CLIP	EA		1	*	*	*	*	*	33	20
1005	X2	0		STRAINER ASSEMBLY, HOSE	EA		1	*	*	*	*	*	33	51
1006	X1	0		BODY, STRAINER	EA		1	*	*	*	*	*	33	47
1007	X2	0		CAP, END	EA		1	*	*	*	*	*	33	49
1008	X2	0		SCREEN, STRAINER	EA		1	*	*	*	*	*	33	46
1009	X2	0	5305-011-3975	SCREW, MACHINE: CAP TO BODY MTG	EA		1	*	*	*	*	*	33	50
1010	X2	0		SPRING, INNER	EA		1	*	*	*	*	*	33	48
1011	X2	0		SPRING, OUTER	EA		1	*	*	*	*	*	33	16
1012	X2	0		STRAINER ASSEMBLY, LINE	EA		1	*	*	*	*	*	33	12
1013	X1	0		BODY, STRAINER	EA		1	*	*	*	*	*	33	14
1014	X2	0		CAP, STRAINER	EA		1	*	*	*	*	*	33	13
1015	X2	0	4730-044-4693	GASKET: STRAINER SCREEN TO BODY	EA		1	*	*	*	*	*	33	11
1016	X2	0		PLUG, PIPE: STRAINER BODY CAP	EA		1	*	*	*	*	*	33	58
1017	X2	0		SCREEN, STRAINER	EA		1	*	*	*	*	*	33	36
1018	X2	0	4730-278-4034	TEE, PIPE: FLOW CONTROL VALVE	EA		1	*	*	*	*	*	29	
1019	X2	0		TEE, PIPE: PUMP OUTLET LINE	EA		1	*	*	*	*	*		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS-GS MAINT. ALW.			(8) 1-YR. ALW. PER. CTYG. 100 EQUIP. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1020	X2	0		TEE, PIPE: SPRAY NOZZLE TUBE CONNECTION, BRASS, ONE END, MALE, 1/8-27 THD SIZE, OTHER ENDS, PLASTIC TUBE CONNECTION, 1/4 IN. OD TUBE, 5/16-24 THD SIZE	EA		4	*	*		*	*	34	14
1021	X2	0		TEE, PIPE TO TUBE: INSECTICIDE TUBE, BRASS, ONE END MALE, 1/8-27 THD SIZE, OTHER ENDS MALE, 5/16-24 THD SIZE	EA		1	*	*		*	*	34	5
1022	X2	0		TUBE ASSEMBLY: ELBOW TO SPRAY NOZZLE, TEFLON, 13 IN. LG	EA		10	*	*		*	*	34	15
1023	M	0		TUBE ASSEMBLY: INSECTICIDE MANUFACTURE FROM:	EA		2	*	*		*	*	34	9
1023A		0	4730-278-8265	NUT, TUBE COUPLING	EA		2	*	*		*	*		
1023B		0	4730-278-8859	NUT, TUBE COUPLING	EA		2	*	*		*	*		
1023C	P	0	5330-362-1562	PACKING, PREFORMED	EA		2	*	*		*	*		
1023D	X2	0	4730-200-0273	SLEEVE, COMPRESSION	EA		2	*	*		*	*		
1023E	P	0	4710-277-5526	TUBE, COPPER (10 3/4 IN. REQUIRED FOR EACH TUBE ASSEMBLY)	FT		2	SEE GRP 9501			*	*	34	8
1024	X2	0		TUBE, FLUID: PUMP TO STRAINER AND PANEL, TEFLON, 3/8 IN. OD, 1/4 IN. ID, 3 FT 7 IN. LG	EA		2	*	*		*	*	33	18
1025	X2	0		TUBE, FLUID: THREE WAY VALVE TO SUPPLY OD, 13 1/2 IN. LG	EA		1	*	*		*	*	33	22
1026	X2	0		TUBE, TEFLON: THREE-WAY VALVE TO MANIFOLD HEAD, 1/4 IN. ID, 3/8 IN. OD, 5 FT LG	EA		1	*	*		*	*	33	21
1027	M	0		TUBE, VINYL: AIR PRESSURE LINE FROM PRESSURE VALVE TO AIR FLOWER	EA		1	*	*		*	*	33	23
1027A	P	0	4710-809-8149	MANUFACTURE FROM:	EA		1	SEE GRP 9501			*	*	33	23
1028	X2	0		PLASTIC, TUBING (22 IN. REQUIRED)	FT		1	SEE GRP 9501			*	*	33	57
1029	X2	0		UNION, HALF: BY-PASS HOSE	EA		1	SEE GRP 9501			*	*	29	30
1030	X2	0		UNION, HALF: INLET LINE	EA		1	SEE GRP 9501			*	*	33	44
1031		0		VALVE, NEEDLE: FLOW CONTROL, 1/4-18 THD SIZE	EA		1	*	*		*	*	33	24
1032	X1	0	5310-012-0361	NUT, PLAIN, HEXAGON: WHEEL MTG	EA		1	*	*		*	*	33	43
1033	X2	0		WHEEL, FLOW VALVE	EA		1	*	*		*	*	33	63
1034		0	5305-206-8263	VALVE, THREE WAY: FLOW CONTROL, BRASS, 1/4-18 THD SIZE	EA		1	*	*		*	*	33	64
				SCREW, MACHINE: POINTER TO VALVE	EA		1	*	*		*	*	33	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS GS MAINT. ALW.			(8) 1-YR. ALW. DS GS MAINT. ALW. PER. 100 EQUIP. CITYCITY PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a)	(b)	(c)						(a)	(b)	(c)			(a) FIG. NO.	(b) SYM. OR NO.
1035					GROUP 95 - GENERAL USE STANDARDIZED PARTS										
1036					9501 - BULK MATERIAL										
1037	P	O		2990-085-9035	CHAIN, WELDLESS: PHOSPHATE FINISH, 0.062 IN. ID, 23 LINKS PER FIT										
1039	P	O		4720-289-4869	HOSE, RUBBER: 3/8 IN. ID, 50 FT LG (GE)	FT			*	*	*	15	3		
1040	P	O		4720-218-5644	HOSE, RUBBER: 1 1/2 IN. ID	FT			*	*	*	15	3		
1041	P	O		5330-270-8169	PAPER, GASKET: 36 IN. W, 1/32 IN. THK	YD			*	*	*	5	1		
1042	P	O		4710-162-0991	PIPE, STEEL: 1 1/4 IN. ID	FT			*	*	*	25	5		
1043	P	O		4710-809-8149	PLASTIC TUBING: 1/4 IN. DIA	FT			*	*	*	125	25		
1044	P	O		5330-505-6611	RUBBER SHEET, SOLID: 1/16 IN. THK, 24 IN. W	FT			*	*	*	5	1		
1045	P	O		9515-554-0893	STEEL STRIP, CARBON, HOT ROLLED: 1/8 IN. THK, 1 1/4 IN. W	FT			*	*	*	5	1		
1046	P	O		9515-529-0429	STEEL STRIP, CARBON, HOT ROLLED: 1/8 IN. THK, 2 IN. W	FT			*	*	*	5	1		
1047	P	O		4710-277-5525	TUBE, COPPER: 0.250 IN. DIA	FT			*	*	*	5	1		
1048	P	O		4710-277-5526	TUBE, COPPER: 5/16 IN. DIA	FT			*	*	*	50	10		
1049	P	O		6145-295-0804	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 12 AWG, 19 STRANDS OF No. 25 AWG, 0.175 IN. DIA	FT			*	*	*	50	10		
1050	P	O		6145-164-7033	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 14 AWG, 19 STRANDS OF No. 27 AWG, 0.115 IN. DIA	FT			*	*	*	50	10		
1051	P	O		6145-164-7023	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 16 AWG, 19 STRANDS, 0.102 IN. DIA	FT			*	*	*	50	10		
1052					GROUP 99 - PARTS PECULIAR				*	*	*	50	10		
1052A					9901 - MULTI-LISTED PARTS										
1053	X2	O			CONNECTOR, HOSE, PIPE: 3/8-24 THD SIZE ONE END OTHER END, 1/2-18 THD SIZE	EA		2	*	*	*	*	*		
1054	X2	O			ELBOW, HOSE: ONE END, 3/8-24 THD SIZE, OTHER END, 1/4-18 THD SIZE	EA		5	*	*	*	*	*		
1055	P	O		2805-641-7404	GASKET	EA		2	*	*	*	60	200		
1056	X2	F			RECEPTACLE	EA		17	*	*	*	*	*		
1057	X2	O			UNION, HALF: BRASS, ONE END, 1/4-18 THD SIZE, OTHER END 3/8-24 THD SIZE	EA		2	*	*	*	*	*		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. RECOV. (c)						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. OR NO.
1058				PART II										
1058A				GROUP 01 - ENGINE										
1058B				0100 - ENGINE ASSEMBLY										
1059	X2	F		ENGINE, GASOLINE: WISCONSIN MODEL MTHD, SPECIFICATION No. 188809, 3 1/4 x 3 1/4 size, 2 CYLINDER										
1060		F	5305-527-4195	SCREW, CAP, HEXAGON HEAD: ENGINE MTG	EA		1	*	*	*	*	*	11	3
1061		F	5310-011-5551	WASHER, LOCK: ENGINE MTG SCREW	EA		4	*	*	*	*	*	11	4
1062				0101 - CRANKCASE, BLOCK, CYLINDER HEAD										
1063	X2	H		BLOCK ASSEMBLY, CYLINDER	EA		1	*	*	*	*	*	6	4
1064	P	F	2805-309-8040	SEAT, VALVE	EA		4	SEE ERP 0105 PART I						
1065		O	5307-011-2572	STUD, PLAIN: MANIFOLD MTG	EA		2	SEE ERP 0108 PART I						
1066				0102 - CRANKSHAFT										
1067	X2	O		SHEAVE, CRANKSHAFT: BLOWER DRIVE	EA		1	*	*	*	*	*	4	4
1068				0105 - VALVES, CAMSHAFTS AND TIMING SYSTEM										
1068A	P	H	2805-339-5598	LIFTER, VALVE	EA		4	*	*	*	*	20	7	9
1069		H	5306-038-4416	SCREW, SELF-LOCKING: TAPPET ADJUSTING	EA		4	*	*	*	*	*	7	8
1070				0106 - ENGINE LUBRICATION SYSTEM										
1072		O	4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA		1	*	*	*	*	*	10	16
1073		O	5306-543-4308	BOLT, MACHINE: FILTER MTG	EA		4	*	*	*	*	*	10	22
1074	X2	O		FILTER ASSEMBLY, OIL	EA		1	*	*	*	*	*	10	10
1075	X1	O		BODY ASSEMBLY	EA		1	*	*	*	*	*	10	20
1076	X2	O		COVER ASSEMBLY	EA		1	*	*	*	*	*	10	14
1077	X1	O		COVER, FILTER	EA		1	*	*	*	*	*	10	10
1078	X1	O	5330-056-9588	GASKET: FIBER	EA		1	*	*	*	*	*	10	9
1079	X1	O		HANDLE ASSEMBLY	EA		1	*	*	*	*	*	10	7
1080	X2	O		RING, SNAP	EA		1	*	*	*	*	*	10	11
1081	X2	O	5310-417-8620	WASHER, SHOULDERS	EA		1	*	*	*	*	*	10	13
1082	X2	O		SPRING, COMPRESSION	EA		1	*	*	*	*	*	10	12
1083	P	O	5330-298-0776	WASHER, NONMETALLIC: COVER SCREW	EA		1	*	*	*	*	100	10	8
1084	P	O	2940-529-2738	FILTER ELEMENT, FLUID, PRESSURE: oil	EA		1	13	25	50	600	100	10	23

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION			(4) UNIT OR ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT	(c) RECOV								(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1085		O		5310-368-1908	NUT, PLAIN, SQUARE: OIL FILTER STRAP	73370 13446	EA		1		*	*	*	*	*	10	5
1086		O		5305-013-3083	SCREW, MACHINE: OIL FILTER STRAP	73370 12398	EA		1		*	*	*	*	*	10	21
1087	X2	O			STRAP, BODY	73370 10757	EA		1		*	*	*	*	*	10	3
1088		O		5310-368-1911	WASHER, LOCK: OIL FILTER STRAP	73370 10124	EA		1		*	*	*	*	*	10	4
1089	P	O		5330-291-3405	WASHER, NONMETALLIC: COVER	73370 10611	EA		1		13	25	50	600	100	10	6
1090	P	O		2940-606-6816	HOSE ASSEMBLY, RUBBER: OIL LINE, PRESSURE	66289 RM1299	EA		1		*	*	2	6	10	10	24
1091	M	O			LINE ASSEMBLY, OIL: CRANKCASE TO GOVERNOR	66289 RM796	EA		1							10	25
1092		O		4730-011-6452	MANUFACTURE FROM:		EA		2		*	*	*	*	*		
1092A		O		4710-277-5525	NUT, TUBE COUPLING	79470 1110X4	EA		4		SEE CRP 9504			*	*	10	1
1093	P	O		5310-176-8160	TUBE, COPPER (6 1/2 IN. REQUIRED)		FT		1		*	*	*	*	*	10	15
1094		O		4730-603-4470	NUT, PLAIN HEXAGON: FILTER MTG	66289 RF1301	EA		1		*	*	*	*	*	10	2
1095		O		5310-596-4911	TEE, PIPE: OIL FILTER INLET	66289 PE4	EA		4		*	*	*	*	*	10	
1096					WASHER, LOCK: FILTER MTG												
1096A					GROUP 03 - FUEL SYSTEM												
1097	X2	O		4730-639-9638	STRAINER ASSEMBLY	78480 04480T	EA		1		*	*	*	*	*	16	20
1098	X1	O			BAIL ASSEMBLY	78480 07766	EA		1		2	2	3	30	10	16	19
1099	P	O		2910-358-4317	BOWL, SEDIMENT, FUEL: GLASS	78480 07759	EA		1		*	*	*	*	*	16	16
1100	X1	O		2910-305-5749	COVER, STRAINER	78480 07770	EA		1		*	*	*	*	*	16	17
1101	P	O		2910-358-5327	SCREEN, FUEL STRAINER	78480 07762	EA		1		*	*	*	10	20	16	21
1102	X1	O		2910-368-6657	VALVE, FUEL REGULATING: SHUT OFF	78480 07769	EA		1		4	8	17	200	100	16	18
1103	P	O		2910-282-7557	WASHER, NONMETALLIC: BOWL MTG	78480 08227	EA		1							16	
1104					GROUP 05 - COOLING SYSTEM												
1104A					0502 - DEFLECTORS, SHROUDS												
1105	F	F		5306-019-3988	BOLT, MACHINE: FLYWHEEL SHROUD MTG	66289 XD13	EA		3		*	*	*	*	*	18	10
1106	X2	F			SHROUD, FLYWHEEL	66289 SE135Y	EA		1		*	*	*	*	*	18	8
1107	F	F		5310-596-4911	WASHER, LOCK: FLYWHEEL SHROUD MTG	66289 PE4	EA		3		*	*	*	*	*	18	9
1108					GROUP 06 - ELECTRICAL SYSTEM												
1108A					0605 - IGNITION COMPONENTS												
1109	P	O		2920-566-7806	CABLE, SPECIAL PURPOSE	66289 YD212D	EA		2		*	*	*	10	10	2	4
1110	X2	O		5340-447-9222	CLAMP, CABLE: SPARK PLUG WIRES	66289 PG314	EA		1		*	*	*	*	*	2	1
1111	P	O	R	2920-800-8156	MAGNETO ASSEMBLY	79575 XHS2484	EA		1		*	*	*	10	2	22	
					(Includes components of REPAIR KIT, Stock No. 2920-712-1267)												
1112	X1			2930-353-6609	BEARING, SLEEVE: DRIVE CUP	79575 5518	EA		1							22	4

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAIN						(a)	(b)	(c)			(a) FIG. NO.	(b) ITEM OR NO.
1113	X1		2920-374-3481	BEARING UNIT, BALL, CYLINDRICAL	EA		1						22	6
1114	X1		3110-144-8882	CARTRIDGE: ROTOR SHAFT	EA		1						22	5
1115	X1		2920-353-6611	BEARING, BALL ANNUAL: ROTOR	EA		1						22	57
1116	X1			RETAINER, BALL BEARING	EA		1						22	19
1117	X1		2920-367-7985	BRACKET, TERMINAL	EA		2						22	21
1118	X1		2920-335-4178	CLAMP, ELECTRICAL: COIL CORE	EA		1						22	22
1119	X1		4920-428-3751	COIL, MAGNETO	EA		1						22	33
1120	X1		2920-607-1324	CORE ASSEMBLY: MAGNETO COIL	EA		1						22	35
1121	X1		2920-366-6296	COUPLING, MAGNETO: IMPULSE	EA		1						22	38
1122	X1		2920-368-6715	ARM, TRIP	EA		1						22	31
1123	X1		2920-740-2845	CUP, MAGNETO DRIVE	EA		1						22	24
1124	X1			FLANGE, DRIVEN GROUP	EA		1						22	34
1125	X1		2920-366-6306	NUT, IMPULSE LOCK	EA		1						22	27
1126	X1		2920-367-7999	RETAINER, DRIVE SPRING	EA		1						22	32
				RING, LOCK: RETAINING, IMPULSE	EA		1						22	30
				COUPLING	EA		1						22	25
1127	X1		2920-662-9135	SPACER, DRIVE FLANGE	EA		1						22	16
1128	X1		5340-353-6606	SPRING, SPIRAL, TENSION: IMPULSE	EA		1						22	48
				COUPLING	EA		1						22	50
1129	X1		5340-740-2871	SPRING, TRIP ARM	EA		1						22	13
1130	X1		2920-740-2846	WASHER: DRIVE CUP SPACER	EA		1						22	15
1131	X1		5310-187-3458	WASHER, FLAT: DRIVE FLANGE	EA		1						22	14
1132	X1		5310-323-6620	WASHER, KEY	EA		1						22	58
1133	X1		2920-767-0480	COVER, UNIT	EA		1						22	42
1134	X1			ROD GROUP, GROUND	EA		2						22	3
1135	X1		2920-598-9432	SPRING, HELICAL, COMPRESSION	EA		3						22	
1136	X1		5305-276-7951	SCREW, MACHINE: TERMINAL BLOCK MTG	EA		1						22	
1137	X1		5940-314-0255	TERMINAL BLOCK: HIGH TENSION	EA		3						22	
1138	X1		5310-013-5830	WASHER, LOCK: TERMINAL BLOCK MTG	EA		1						22	
1139	X1		8305-740-2859	FELT, STRIP: BREAKER ARM	EA		1						22	
1140	X1		5330-297-4578	GASKET: IMPULSE STOP	EA		1						22	
1141	X1		2920-360-8381	GASKET: MAGNETO MTG (COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100 PART 1) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5846)	EA		1						22	
1142	X1			GEAR, DRIVE	EA		1						22	
1143	X1			HOUSING, MAIN: MAGNETO	EA		1						22	
1144	X1			LEAD, ELECTRICAL: BREAKER TO CAPACITOR	EA		1						22	
1145	X1		5310-012-0614	NUT, PLAIN, HEXAGON: IMPULSE STOP SET	EA		1						22	
1146	X1			SCREW LOCKING	EA		1						22	
1147	X1		2510-039-7699	PLATE, IMPULSE STOP	EA		1						22	
1148	X1			PLATE, NAME: MAGNETO	EA		1						22	
1149	X1		2920-740-2873	ROTOR	EA		1						22	
			5305-281-8308	SCREW, ASSEMBLED WASHER: BREAKER CLAMP, CONTACT MTG, CORE CLAMP MTG	EA		4						22	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1150	X1		5305-639-6026	SCREW, ASSEMBLED WASHER: TERMINAL BRACKET MTG	EA		1						22	56
1151	X1		5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA		2	SEE GRP 2210					22	18
1152	X1		5305-424-2999	SCREW, MACHINE: COVER MTG	EA		3						22	41
1153	X1		5305-022-5561	SCREW, MACHINE: IMPULSE STOP CLAMP	EA		4						22	39
1154	X1		5305-638-6834	SETSCREW: IMPULSE STOP	EA		1						22	8
1155	X1		5305-353-6614	SHIELD, BALL BEARING	EA		1						22	9
1156	X1		2920-353-6610	SPLACER, SLEEVE: BEARING GAGE	EA		1						22	17
1157	X1		5310-275-1353	WASHER: COVER MTG	EA		3						22	52
1158	X1		5310-188-4185	WASHER, FLAT: BREAKER ARM PIVOT	EA		1						22	59
1159	X1		5310-188-4185	WASHER, FLAT: BREAKER POINT ALIGNING	EA		1						22	
1160	X1		5310-351-0698	WASHER, FLAT: POINT ALIGNMENT STEEL, CADMIUM OR ZINC PLATED, 3/16 ID, 5/16 OD, 0.004 IN. THK	EA		1						22	51
1161	X1		5310-012-1744	WASHER, LOCK: IMPULSE STOP CLAMP	EA		4						22	40
1162	X1		5330-262-3306	WICK: CAM WIPER, FELT	EA		1						22	54
1163		O	5310-012-0377	NUT, PLAIN, HEXAGON: MAGNETO MTG	EA		1						22	44
1164	P	O	2920-712-1267	REPAIR KIT, MAGNETO	EA		1						22	
1165	X1		2920-662-9133	BEARING, SLEEVE: BREAKER PLATE	EA		1						22	46
1166	X1		5910-740-2855	CONDENSER, CAP	EA		1						22	49
1167	X1		2920-740-2882	CONTACT SET, DISTRIBUTOR	EA		1						22	47
1168	X1		2920-740-2830	DEFLECTOR, DIRT AND OIL	EA		1						22	36
1169	X1		2920-428-3830	GASKET: COVER, LEAD	EA		1						22	12
1170	X1		2920-740-2852	PIN, LOCK: BREAKER ARM	EA		1						22	53
1171	X1		5315-367-7994	RING, RETAINING: ROTARY BEARINGS	EA		1						22	7
1172	X1		5340-281-6688	SEAL, PLAIN: OIL	EA		1						22	43
1173		O	2920-353-6618	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG	EA		2						22	1
1174		O	5305-289-3217	SCREW, MACHINE: CABLE CLAMP ATTACHMENT	EA		1						22	3
1175		O	5305-584-8736	SPARK PLUG: 18 MM	EA		2						22	6
1176	P	O	2920-293-5212	GASKET: SPARK PLUG	EA		2						22	5
1177	P	O	5330-599-5356	WASHER, LOCK: CABLE CLAMP ATTACHMENT	EA		2						22	2
1178		O	5310-543-2705	WASHER, LOCK: MAGNETO MTG	EA		2						22	2
1179		O	5310-582-9930	WASHER, LOCK: MAGNETO MTG	EA		2						22	2
1180			5310-627-6128	GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS	EA		1						22	45
1180A				2210 - DATA PLATES										
1181	X2	O	2805-685-6019	PLATE, INSTRUCTION: ENGINE OPERATION	EA		1							
1182	X2	O		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1							
1183	X2	O	5305-335-4180	PLATE, NAME: MAGNETO	EA		1							
1184		O		SCREW, DRIVE: NAMEPLATE MTG	EA		2							

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTYGY. PLANNING	(9) DEPT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a)	(b)	(c)						(a)	(b)	(c)			(a)	(b)
1185					GROUP 57 - SPRAY EQUIPMENT COMPONENTS										
1185A					5703 - AIR BLOWER ASSEMBLY										
1186	X2	O			FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	*	32	5
1187	X1				BODY, FILTER	EA		1	*	*	*	*	*	32	6
1188	X2	O			ELEMENT, FILTER SILENCER	EA		1	*	*	*	*	*	32	4
1189	P	O		3740-542-3716	GASKET: ELEMENT TO BODY AND TOP	EA		2	*	2	2	20	10	32	1
1190	O	O		5310-010-3129	NUT, PLAIN, WING: TOP TO BODY	EA		1	*	*	*	*	*	32	8
1191	X2	O			TOP ASSEMBLY	EA		1	*	*	*	*	*	32	7
1192	M	O			FELT: TOP ASSEMBLY	EA		1	*	*	*	*	*	32	
					MANUFACTURE FROM:										
					FELT SHEET	SH			SEE GRP 9501						
1192A	P	O		5330-191-1096	(7 IN. X 7 IN. REQUIRED)	EA		1	*	*	*	*	*	32	3
1193		O		5310-366-6294	WASHER, FLAT: TOP TO BODY	EA		1	*	*	*	*	*	32	2
1194		O		5310-013-8542	WASHER, LOCK: TOP TO BODY	EA									
1195					5704 - SPRAY DUCTS AND MANIFOLDS										
1196	X2	O			MANIFOLD SPRAY ASSEMBLY	EA		1	*	*	*	*	*	32	2
1197	X2	O			CLAMP, DRUM	EA		5	*	*	*	*	*	32	10
1198	X2	O			ELBOW, LONG	EA		1	*	*	*	*	*	32	11
1199	X2	O			ELBOW, SHORT	EA		1	*	*	*	*	*	32	1
1200	X2	O			END CAP	EA		2	*	*	*	*	*	32	4
1201	X2	O			NOZZLE HEAD	EA		1	*	*	*	*	*	32	3
1202	X2	O			SCREW, TOGGLE: CLAMP DRUM CLAMPING	EA		5	*	*	*	*	*	32	16
1203	X2	O			NOZZLE ASSEMBLY: SPRAY	EA		10	*	*	*	*	*	32	
1204				3440-977-8672	GROUP 95 - GENERAL USE STANDARDIZED PARTS										
					9501 - BULK MATERIAL										
1204A					FELT SHEET: 1/4 IN. THK, 30 IN. W, 36 IN. LG	SH			*	*	*	*	*		
1205	P	O		5330-191-1096	00736 540-16										

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS.GS MAINT. ALW.			(8) 1-YR. ALW. PLANNING 100 EQUIP. CTYCY.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR SYM. NO.
1206					PART III										
1206A					GROUP 01 - ENGINE										
1206B					0100 - ENGINE ASSEMBLY										
1207	X2	F			ENGINE, GASOLINE	EA		1	*	*	*	*	*	11	3
1208	F	F		5305-527-4195	SCREW, CAP, HEXAGON HEAD: ENGINE MTG	EA		4	*	*	*	*	*	11	4
1209	F	F		5310-011-5551	WASHER, LOCK: ENGINE MTG	EA		4	*	*	*	*	*		
1210					0101 - CRANKCASE, BLOCK, CYLINDER HEAD										
1211	X2	H	R		BLOCK ASSEMBLY, CYLINDER	EA		1	*	*	*	*	*	6	4
1212	X2	O			EXTENSION, OIL DRAIN	EA		1	*	*	*	*	*		
1213	P	F		2805-309-8040	SEAT, VALVE	EA		4	SEL CRP 0105						
1214		O		5307-011-2572	STUD, PLAIN: MANIFOLD MTG	EA		2	PART I SEE CRP 0103						
1215					0102 - CRANKSHAFT										
1216	X2	O			SHEAVE, CRANKSHAFT: BLOWER DRIVE	EA		1	*	*	*	*	*	4	4
1217					0105 - VALVES, CAMSHAFTS AND TIMING SYSTEM										
1218	P	H		2805-526-8753	LIFTER, VALVE	EA		4	*	*	*	*	*	7	9
1219					0106 - ENGINE LUBRICATION SYSTEM										
1220		O		4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA		1	*	*	*	*	*	10	16
1221		O		5306-542-4308	BOLT, MACHINE: FILTER MTG	EA		4	*	*	*	*	*	10	22
1223	X2	O		2940-358-2536	FILTER, FLUID, PRESSURE: OIL	EA		1	*	*	*	*	*	10	10
1224	X1				BODY ASSEMBLY	EA		1	*	*	*	*	*	10	20
1225	X2	O		2940-393-5988	COVER ASSEMBLY	EA		1	*	*	*	*	*	10	14
1226	X1				GASKET: FIBER	EA		1	*	*	*	*	*	10	10
1227	X2	O		5330-056-9588	RANDLE ASSEMBLY	EA		1	*	*	*	*	*	10	9
1228	X1				RING, SNAP	EA		1	*	*	*	*	*	10	7
1229	X2	O			WASHER, SHOULDERS	EA		1	*	*	*	*	*	10	11
1230	X2	O		5310-417-8620	SPRING, COMPRESSION	EA		1	*	*	*	*	*	10	13
1231	X2	O			WASHER, NONMETALLIC: COVER SCREW	EA		1	*	*	*	*	*	10	12
1232	P	O		5330-298-0776	FILTER ELEMENT	EA		1	13	25	2	15	100	10	8
1233	P	O		2940-141-9025	GASKET, COVER WASHER, NONMETALLIC	EA		1	13	25	50	600	100	10	23
1234	P	O		5330-599-1285		EA		1	13	25	50	600	100	10	6

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS-GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTY-GC. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
								(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. NO.
	MANUFACTURER'S CODE	PART NUMBER												
1235		0	5310-368-1908	NUT, PLAIN, SQUARE: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	5
1236		0	5305-013-3083	SCREW, MACHINE: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	21
1237	X2	0	2940-732-4214	STRAP: OIL FILTER MTG	EA		1	*	*	*	*	*	10	3
1238		0	5310-013-8542	WASHER, LOCK: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	4
1239		0	5310-176-8160	NUT, PLAIN, HEXAGON: FILTER MTG	EA		4	*	*	*	*	*	10	1
1240		0	4730-603-4470	TEE, PIPE: OIL FILTER INLET	EA		1	*	*	*	*	*	10	15
1241	X2	0	2940-512-3807	TUBE ASSEMBLY, OIL	EA		1	*	*	*	*	*	10	25
1242		0	5310-596-4911	WASHER, LOCK: FILTER MTG	EA		4	*	*	*	*	*	10	2
1243				GROUP 03 - FUEL SYSTEM										
1243A				0306 - TANKS, LINES, FITTINGS										
1244	X2	0		CLIP, FUEL LINE	EA		1	*	*	*	*	*	*	*
1245	X2	0		NUT: CLIP SCREW	EA		1	*	*	*	*	*	*	*
1246	X2	0		SCREW: CLIP MTG	EA		1	*	*	*	*	*	*	*
1247		0	5310-595-7235	WASHER, LOCK: CLIP MTG	EA		1	*	*	*	*	*	*	*
1248				0309 - FUEL FILTERS										
1249	X2	0	4730-639-9638	STRAINER ASSEMBLY	EA		1	*	*	*	*	*	16	20
1250	X1	0	2910-382-8768	BAIL ASSEMBLY	EA		1	*	*	*	*	*	16	19
1251	P	0	2910-354-3834	BOWL, SEDIMENT, FUEL: GLASS	EA		1	2	2	3	30	10	16	16
1252	X1	0	2910-305-5749	COVER, STRAINER	EA		1	*	*	*	*	*	16	16
1253	P	0	2910-142-2738	STRAINER ELEMENT, SEDIMENT	EA		1	*	*	2	10	20	16	17
1254	X1	0	2910-368-6657	VALVE, FUEL REGULATING: SHUTOFF	EA		1	*	*	*	*	*	16	21
1255	P	0	5330-187-2962	WASHER, NONMETALLIC: BOWL MTG	EA		1	4	8	17	200	100	16	18
1256				GROUP 04 - EXHAUST SYSTEM										
1256A				0401 - MUFFLER AND PIPES										
1257	X2	0		GUARD, MUFFLER	EA		1	*	*	*	*	*	*	*
1258		0	5310-584-5005	NUT, PLAIN, HEXAGON: MUFFLER GUARD TO CANOPY	EA		4	*	*	*	*	*	*	*
1259		0	5305-637-4028	SCREW, CAP, HEXAGON HEAD: MUFFLER GUARD TO CANOPY	EA		4	*	*	*	*	*	*	*
1260		0	5310-011-5544	WASHER, LOCK: MUFFLER GUARD TO CANOPY	EA		8	*	*	*	*	*	*	*
1261				GROUP 05 - COOLING SYSTEM										
1261A				0502 - DEFLECTORS, SHROUDS										
1262		F	5306-019-3988	BOLT, MACHINE: FLYWHEEL SHROUD MTG	EA		3	*	*	*	*	*	18	10
1263	X2	F		SHROUD, FLYWHEEL	EA		1	*	*	*	*	*	18	8

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTGY. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.	(c) RECOV.					(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.	
1264		F		5310-596-4911	WASHER, LOCK: FLYWHEEL SHROUD MTS	EA		3	*	*	*	*	*	18	9
1265					GROUP 06 - ELECTRICAL SYSTEM	EA		1	*	*	*	10	2		
1265A					0605 - IGNITION COMPONENTS										
1266	P	O	R	2920-979-3504	MAGNETO (INCLUDES COMPONENTS OF REPAIR KIT, Stock No. 2920-344-2035) CAP, END: MAGNETO COIL, MAGNETO FERRULE HOUSING: MAGNETO OUTLET, CABLE PLATE, NAME: MAGNETO ROTOR, MAGNETIC SCREW: CONDENSER TERMINAL SCREW: CONTACT SUPPORT SCREW, MACHINE: BREAKER ARM TERMINAL SCREW, MACHINE: CABLE OUTLET, No. 8-32 x 7/16 IN.	EA									
1267	X1				82796 NY2430A	EA		1						36	7
1268	X1				82796 QT2477C	EA		1						35	16
1269	X1				82796 M1077	EA		1							
1270	X1				82796 HU2425	EA		1							
1271	X1				82796 Z2474	EA		1						35	1
1272	X2				82796 A195	EA		1						36	6
1273	X1				82796 X32480	EA		1							
1274	X1			5305-042-0450	SCREW: CONTACT SUPPORT	EA		1						35	30
1275	X1				82796 656U	EA		1							
1276	X1			5305-010-0749	SCREW, MACHINE: BREAKER ARM TERMINAL	EA		2						36	18
1277	X1				82796 854U	EA		1						36	21
1278	X1			5305-012-1832	SCREW, MACHINE: CONDENSER MTS	EA		1						35	29
1279	X1				82796 656D	EA		2						36	17
1280	X1			5305-543-2281	SETSCREW: WASHER RETAINING, 8-32 x 3/8 IN.	EA		1							
1281	X1				SWITCH, COMPLETE GROUND	EA		2							
1282	X1			5310-794-8554	WASHER, LOCK: RETAINING WASHER SCREW	EA		1						35	26
1283	X1				NUT, GROUND SWITCH	EA		1						36	14
1284	X1				PLUNGER, GROUND SWITCH	EA		1						35	28
1285	X1				SPRING, GROUND SWITCH	EA		1						36	13
1286	X1				COUPLING, IMPULSE	EA		1						36	11
1287	X1				COUPLING, HUB ASSEMBLY	EA		1						35	
1288	X1				SHELL, COUPLING	EA		1						35	7
1289	X1				SPRING, COUPLING DRIVE	EA		1						35	8
1290	X1			2920-428-7583	SPRING, PAWL	EA		1						35	
1291	X1			2920-428-7572	BEARING, CAM END	EA		1						35	27
1292	X1			2920-602-4258	BEARING, DRIVE END	EA		1						35	19
1293	X1			3110-144-8998	BUSHING: GEAR COUPLING	EA		1						35	13
1294	X1			2920-286-2712	BUTTON, GROUND SWITCH	EA		1						35	11
1295	X1				COVER, VENT	EA		1						35	
1296	X1			2920-831-1171	KEY: ROTOR SHAFT TO IMPULSE COUPLING	EA		2						35	24
1297	X1			5315-715-1699	NUT, CASTELLATED, HEXAGON: COUPLING	EA		1						35	15
1298	X1			5310-366-7158	SCREW, MACHINE: BEARING SUPPORT	EA		1						35	12
1299	X1			5305-206-8263	SCREW, VENT: No. 6-32 x 1/4 IN.	EA		4						35	21
1300	X1			5305-206-0169	SETSCREW: COUPLING PAWL STOP	EA		2						35	23
					82696 A2568	EA		1						35	2

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTY/GCY. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1301	X1		2920-537-1330	SPRING, COIL LEAD	EA		2						35	17
1302	X1		2920-354-0766	SUPPORT, BEARING	EA		1						35	20
1303	X1		5310-186-7410	WASHER: COUPLING PLATE	EA		1						35	10
1305	X1		2920-354-0750	WASHER, FLAT: CONTACT SUPPORT MTG	EA		2						36	19
1306	X1		5335-830-9983	WICK AND HOLDER, CAM	EA		1						35	22
1307	X1		2920-360-8381	WIRE FABRIC, VENT	EA		2						35	25
				GASKET: MAGNETO MTG	EA		1						36	3
				(COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, SEE GROUP 0100, PART 1) (CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5846)										
1308	X2	0	2990-603-4773	GEAR, HELICAL: DRIVE	EA		1	*	*	*	*	*	36	4
1309		0	5310-012-0377	NUT, PLAIN, HEXAGON: MAGNETO MTG	EA		1	*	*	*	*	*	36	24
1310		0	5315-011-2726	PIN, COTTER: DRIVE GEAR	EA		1	*	*	*	*	*	36	23
1311		0	5305-514-9662	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG	EA		2	*	*	*	*	*	36	1
1312		0	5310-582-9930	WASHER, LOCK: MAGNETO MTG	EA		2	*	*	*	*	*	36	2
1313		0	5310-595-7237	WASHER, LOCK: MAGNETO MTG	EA		1	*	*	*	*	*	36	22
1314	P	0	2920-844-2035	REPAIR KIT, MAGNETO	EA		1	*	*	*	*	*	36	
1315	X1		2920-142-1888	ARM, CONTACT SET, DISTRIBUTOR	EA		1	2	3	5	60	2	36	20
1316	X1		5340-598-3180	CLIP, RETAINING: ROTOR DRIVE SHAFT	EA		1						35	3
1317	X1		5340-675-5253	CLIP, RETAINING: SWITCH	EA		1						36	9
1318	X1		2920-217-3489	CONDENSER	EA		1						36	16
1319	X1		5305-281-6387	GASKET: END CAP	EA		1						36	8
1320	X1			SCREW, CAP END	EA		4						36	
1321	X1			SEAL, CONDENSER	EA		1						36	
1322	X1		2920-356-1221	SEAL: ROTOR SHAFT	EA		1						36	15
1323	X1			SPACER, GROUND SW/ITCH	EA		1						35	5
1324	X1		5310-794-8555	WASHER, FLAT: RETAINING DRIVE END BEARING	EA		1						36	10
1325	X1		5310-205-7981	WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA		1						35	14
1326	X1		5310-205-7981	WASHER: GREASE RETAINING INNER BEARING SUPPORT	EA		1						35	4
1327	X1			WASHER: GREASE RETAINING, OUTER BEARING SUPPORT	EA		1						35	4
1328	X1		5310-285-1591	WASHER: ROTOR SHAFT OUTER SEAL	EA		1						35	18
1329	P	0	2920-887-1269	CABLE, IGNITION: SPARK PLUG	EA		2	*	*	2	10	10	35	6
1330	X2	0		CLAMP, CABLE: SPARK PLUG WIRES	EA		2	*	*	*	*	*	2	4
1331		0	5305-013-1238	SCREW, MACHINE: CABLE CLAMP MTG	EA		2	*	*	*	*	*	2	1
1332	P	0	2920-841-1890	SPARK PLUG	EA		2	*	*	*	*	*	2	3
1333		0	5310-013-8542	WASHER, LOCK: CABLE CLAMP MTG	EA		1	5	10	20	240	200	2	6
1334	P	0	5330-599-5356	GASKET: SPARK PLUG	EA		2	*	3	5	60	200	2	5
				82796 B3967										
				82796 B74631										
				82796 B2665K										
				82796 B5969										
				82796 G2788										
				82796 C6032B										
				66289 QD616										
				66289 QD93C3										
				66289 PE76A										
				66289 PE56A										
				82796 SK72										
				82796 Q2437A										
				82796 D14980										
				82796 C1498G										
				82796 QX2433										
				82796 N2498										
				82796 1CS100										
				82796 P2473										
				82796 G3861										
				82796 F4373										
				82796 A2492D										
				82796 A2492C										
				82796 A2492C										
				82796 E2493										
				82796 A2492A										
				66289 YD300-23										
				66289 PG559										
				66289 XA33										
				11583 XMD18										
				11583 A676										

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE		(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PR. 100 EQUIP. CITY GY. PLANNING	(9) DEPT MAINT. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT	(c) RECOV							(a) 1-20	(b) 21-50	(c) 51-100			(g) FIG. NO.	(h) ITEM OR
1335					GROUP 22 - BODY CHASSIS OR HULL, AND ACCESSORY ITEMS											
1335A					2210 - DATA PLATES											
1336	X2	O			PLATE, INSTRUCTION: ENGINE OPERATING	EA		1		*	*	*	*	*		
1337	X2	O			PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1		*	*	*	*	*		
1338	X2	O			PLATE, NAME: MAGNETO	EA		1		*	*	*	*	*		
1339	X2	O		5305-335-4180	SCREW, DRIVE: NAMEPLATE-MTG	EA		2		*	*	*	*	*		
1340					GROUP 57 - SPRAY EQUIPMENT COMPONENTS											
1340A					5703 - AIR BLOWER ASSEMBLY											
1341	X2	O			ADAPTER: OVERBOARD OIL DRAIN	EA		1		*	*	*	*	*	32	2
1342	X2	O			ELBOW: OVERBOARD OIL DRAIN	EA		1		*	*	*	*	*	32	6
1343	X2	O			FILTER, SILENCER: AIR BLOWER	EA		1		*	*	*	*	*	32	4
1344	X1				BODY, FILTER	EA		1		*	*	*	*	*	32	1
1345	X2	O			ELEMENT, FILTER SILENCER	EA		1		*	*	*	*	*	32	8
1346	P	O			GASKET: ELEMENT TO BODY AND TOP	EA		2		*	2	2	20	10	32	7
1347	X2	O		3740-542-3716	NUT, PLAIN, WING: TOP TO BODY	EA		1		*	*	*	*	*	32	1
1348	X2	O		5310-010-3129	TOP ASSEMBLY	EA		1		*	*	*	*	*	32	1
1349	M	O			FELT: TOP ASSEMBLY	EA		1		*	*	*	*	*	32	1
1349A					MANUFACTURE FROM:											
1350	P	O		5330-191-1096	FELT SHEET (7 IN BY 7 IN. REQUIRED)	SH		1		SEE GRP 9501	*	*	*	*	32	3
1351	O			5310-366-6294	WASHER, FLAT: TOP TO BODY	EA									32	2
1351	O			5310-013-8542	WASHER, LOCK: TOP TO BODY	EA										
1352					5704 - SPRAY DUCTS AND MANIFOLDS											
1353	X2	O			MANIFOLD SPRAY ASSEMBLY	EA		1		*	*	*	*	*	34	2
1354	X2	O			CLAMP, DRUM	EA		5		*	*	*	*	*	34	10
1355	X2	O			ELBOW, LONG	EA		1		*	*	*	*	*	34	11
1356	X2	O			ELBOW, SHORT	EA		1		*	*	*	*	*	34	1
1357	X2	O			END CAP	EA		2		*	*	*	*	*	34	4
1358	X2	O			NOZZLE HEAD	EA		1		*	*	*	*	*	34	4
1359	X2	O			SCREW, TOGGLE: CLAMP DRUM CLAMPING	EA		5		*	*	*	*	*	34	3
1360	X2	O			NOZZLE ASSEMBLY: SPRAY	EA		10		*	*	*	*	*	34	16
1361	X1				HUB ASSEMBLY	EA		10		*	*	*	*	*	34	
1362	X1				IMPELLER: SPRAY NOZZLE	EA		10		*	*	*	*	*	34	
1363	X1				NUT, SELF-LOCKING, HEXAGON: FACE PLATE	EA		10		*	*	*	*	*	34	
1364	X1				SCREW, No. 4-40 TWO SIZE	EA		20		*	*	*	*	*	34	
1364	X1				PLATE, FACE	EA		10		*	*	*	*	*	34	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION		(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS, GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. PLANNING CTY GCSY.	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.							(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1365	X1				SCREW, MACHINE: FACE PLATE TO NOZZLE, No. 4-NO TWO SIZE, 3/4 IN. LG	82254 CFA40962	EA		20							
1366					5708 - TANKS, VALVES, LINES, HOSES, FITTINGS, AND LIQUID STRAINERS											
1367	X2	0			CLIP, HOSE	82254 CFA40971	EA		2	*	*	*	*	*		
1368	X2	0			NUT, PLAIN, HEXAGON: CLIP MTG	82254 CFA40974	EA		2	*	*	*	*	*		
1369	X2	0			SCREW, MACHINE: CLIP MTG, 6-32 x 1/2, RHD	82254 CFA40972	EA		2	*	*	*	*	*		
1370		0			WASHER, LOCK: CLIP MTG	96906 MS35333-20	EA		2	*	*	*	*	*		
1371					GROUP 95 - GENERAL USE STANDARDIZED PARTS											
1371A					9501 - BULK MATERIAL											
1372	P	0			FELT SHEET		SH			*	*	*	5	1		

[illegible]

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS.GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING 100 EQUIP.	(9) DEPOT MAINT. 100 EQUIP.	(10) ILLUSTRATION		
	(a) SOURCE	(b) MAINT. RECOV.						(c) RECOV.	(a) 1-20	(b) 21-50			(c) 51-100	(a) FIG. NO.	(b) ITEM OR FIG. NO.
1401	X2	O	5305-013-3080	SCREW, MACHINE: OIL FILTER STRAP STRAP, BODY	EA		1	*	*	*	*	*	10	21	
1402		O		WASHER, LOCK: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	3	
1403		O	5310-013-8542	WASHER, NONMETALLIC: COVER	EA		1	*	*	*	*	*	10	4	
1404	P	O	5330-291-3405	HOSE ASSEMBLY, RUBBER: OIL LINE, PRESSURE	EA		1	13	25	50	600	100	10	6	
1405	P	O	2910-506-6816	LINE ASSEMBLY, OIL: CRANKCASE TO GOVERNOR	EA		1	*	*	2	6	10	10	24	
1406	M	O		MANUFACTURE FROM:	EA		1						10	25	
1407		O	4730-011-6452	NUT, TUBE COUPLING	EA		2	*	*	*	*	*	10	1	
1408		O	5310-176-8160	NUT, PLAIN, HEXAGON: FILTER MTG	EA		4	*	*	*	*	*	10	15	
1409		O	4730-603-4470	TEE, PIPE: OIL FILTER INLET	EA		1	*	*	*	*	*	10	15	
1410	P	O	4710-277-5525	TUBE, COPPER (6 1/2 IN. REQUIRED)	FT		4	SEE DRP 950	*	*	*	*	10	2	
1411		O	5-10-596-4911	WASHER, LOCK: FILTER MTG	EA		4	*	*	*	*	*	10	2	
1412				GROUP 03 - FUEL SYSTEM											
1413	X2	G	4730-639-9638	GROUP 03 - FUEL FILTERS											
1414	X1	P		STRAINER ASSEMBLY	EA		1	*	*	*	*	*	16	20	
1415	X1	O	2910-358-4317	BAIL ASSEMBLY	EA		1	*	*	*	*	*	16	19	
1416	X1	O	2910-305-5749	BOWL, SEDIMENT, FUEL: GLASS	EA		1	2	2	3	30	10	16	16	
1417	P	O	2910-358-5327	COVER, STRAINER	EA		1	*	*	*	*	*	16	16	
1418	X1	O	2910-368-6657	SCREEN, FUEL STRAINER	EA		1	*	*	*	*	20	16	17	
1419	P	O	2910-202-7557	VALVE, FUEL REGULATING: SHUT OFF	EA		1	4	8	17	200	100	16	21	
1420				WASHER, NONMETALLIC: BOWL MTG	EA		1						16	18	
1421	X2	F	5306-019-3988	GROUP 05 - COOLING SYSTEM	EA		3	*	*	*	*	*	18	10	
1422	F	F	5310-596-4911	GROUP 05 - DEFLECTORS, SHROUDS	EA		1	*	*	*	*	*	18	8	
1423				BOLT, MACHINE: FLYWHEEL SHROUD MTG	EA		3	*	*	*	*	*	18	9	
1424	P	O	2920-566-7806	SHROUD, FLYWHEEL	EA		2	*	*	*	*	*	2	4	
1425	X2	O	5340-447-9222	WASHER, LOCK: FLYWHEEL SHROUD MTG	EA		1	*	*	*	*	*	2	1	
1426	P	O	2920-800-8156	GROUP 06 - ELECTRICAL SYSTEM	EA		1	*	*	*	*	2	22	4	
1427	X1		2930-353-6609	GROUP 06 - ELECTRICAL SYSTEM	EA		1	*	*	*	*	22	4		
1428	X1		2920-374-3481	GROUP 06 - ELECTRICAL SYSTEM	EA		1	*	*	*	*	22	4		
				(INCLUDES COMPONENTS OF REPAIR KIT, STOCK No. 2920-712-1267)											
				CABLE, SPECIAL PURPOSE											
				CLAMP, CABLE: SPARK PLUG WIRES											
				MAGNETO ASSEMBLY											
				BEARING, SLEEVE: DRIVE CUP											
				BEARING UNIT, BALL, CYLINDRICAL											
				CARTRIDGE: ROTOR SHAFT											

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS. MAINT. AL. W.			(8) 1-18. AL. W. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. AL. W. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM NO.
1429	X1		3110-144-8882	BEARING, BALL ANNUAL: ROTOR	EA		1						22	6
1430	X1		2920-353-6611	RETAINER, BALL BLANKING	EA		1						22	5
1431	X1		2920-367-7845	BRACKET, TERMINAL	EA		1						22	57
1432	X1		2920-335-4170	CLAMP, ELECTRICAL: COIL CORE	EA		2						22	21
1433	X1		4920-428-3751	COIL, MAGNETO	EA		1						22	22
1434	X1		2420-607-1324	CORE ASSEMBLY: MAGNETO COIL	EA		1						22	33
1435	X1		2920-366-6269	COUPLING, MAGNETO: IMPULSE	EA		1						22	26
1436	X1		2920-366-6269	ARM, TRIP	EA		1						22	35
1437	X1		2920-366-6269	CIP, MAGNETO DRIVE	EA		1						22	28
1438	X1		2920-366-6269	FLANGE, DRIVE GROUP	EA		1						22	31
1439	X1		2920-740-2845	NUT, IMPULSE LOCK	EA		1						22	24
1440	X1		2920-366-6306	RETAINER, DRIVE SPRING	EA		1						22	34
1441	X1		2920-367-7999	RING, LOCK: RETAINING, IMPULSE	EA		1						22	27
1442	X1		2920-662-9135	COUPLING	EA		1						22	32
1443	X1		5340-353-6606	SPACER, DRIVE FLANGE	EA		1						22	29
1444	X1		5340-740-2871	SPRING, SPIRAL, TENSION: IMPULSE	EA		1						22	30
1445	X1		5340-740-2871	COUPLING	EA		1						22	25
1446	X1		5310-187-3458	WASHER, DRIVE CUP SPACER	EA		1						22	16
1447	X1		5310-187-3458	WASHER, FLAT: DRIVE FLANGE	EA		1						22	48
1448	X1		5310-353-6620	WASHER, THRUST	EA		1						22	13
1449	X1		2920-737-0480	COVER, UNIT	EA		1						22	15
1450	X1		5305-276-7951	ROD GROUP, GROUND	EA		1						22	58
1451	X1		2920-593-9432	SCREW, MACHINE: TERMINAL BLOCK MTG	EA		3						22	42
1452	X1		5940-314-0255	SPRING, HELICAL, COMPRESSION	EA		2						22	3
1453	X1		5310-013-5830	TERMINAL BLOCK: HIGH-TENSION	EA		1						22	
1454	X1		8305-740-2859	WASHER, LOCK: TERMINAL BLOCK MTG	EA		3						22	
1455	X1		5330-297-4576	FELT, STRIP: BREAKER ARM	EA		1						22	
1456	X1		2920-360-8381	GASKET: IMPULSE STOP	EA		1						22	
				GASKET: MAGNETO MTG	EA		1						22	
				(COMPONENT OF GASKET SET, Stock No. 2805-720-4773, Group 0100, Part 1)										
				(CAN BE MANUFACTURED FROM PAPER, Stock No. 5330-233-5846)										
1457	X1			GLAR, DRIVE	EA		1						22	23
1458	X1			HOUSING, MAIN: MAGNETO	EA		1						22	11
1459	X1			LEAD, ELECTRICAL: BREAKER TO CAPACITOR	EA		1						22	55
1460	X1		5310-012-0614	NUT, PLAIN, HEXAGON: IMPULSE STOP	EA		1						22	38
1461	X1			SETSCREW LOCKING	EA		1						22	37
1462	X1		2510-037-7699	PLATE, IMPULSE STOP	EA		1						22	10
1463	X1		2920-740-2873	PLATE, NAME: MAGNETO	EA		1						22	20
1464	X1		5305-281-8308	ROTOR	EA		1						22	
				SCREW, ASSEMBLED WASHER: BREAKER CLAMP, CONTACT MTG, CORE CLAMP MTG	EA		4						22	

SEE QRP 2210

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. P. 200 EQUIP. CTY GCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1465	X1		5305-639-6026	SCREW, ASSEMBLED WASHER: TERMINAL BRACKET MTG	EA		1						22	56
1466	X1		5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA		2	SEE GRP 2210					22	18
1467	X1		5305-421-2999	SCREW, MACHINE: COVER MTG	EA		3						22	41
1468	X1		5305-022-5561	SCREW, MACHINE: IMPULSE STOP CLAMP	EA		1						22	39
1469	X1		5305-638-6834	SETSCREW: IMPULSE STOP	EA		1						22	8
1470	X1		2920-353-6614	SHIELD, BALL BEARING	EA		1						22	9
1471	X1		2920-353-6610	SPACER, SLEEVE: BEARING CAGE	EA		1						22	17
1472	X1		5310-275-1353	WASHER: COVER MTG	EA		3						22	52
1473	X1		5310-188-4185	WASHER, FLAT: BREAKER ARM PIVOT	EA		1						22	59
1474	X1		5310-351-0698	WASHER, FLAT: BREAKER POINT	EA		1						22	51
1475	X1			ALIGNING	EA		1						22	40
1476	X1		5310-012-1744	WASHER, FLAT: POINT ALIGNMENT	EA		4						22	54
1477	X1		5330-262-3306	WASHER, LOCK: IMPULSE STOP CLAMP	EA		1						22	44
1478	X1		5310-012-0377	WICK: CAM WIPER, FELT	EA		1						22	46
1479	P	O	2920-712-1267	NUT, PLAIN, HEXAGON: MAGNETO MTG	EA		1	*	*	5	60	*	22	49
1480	X1		2920-662-9133	REPAIR KIT, MAGNETO	EA		1						22	47
1481	X1		5910-740-2855	BEARING, SLEEVE: BREAKER PLATE	EA		1						22	36
1482	X1		2920-740-2882	CONDENSER, CAP	EA		1						22	12
1483	X1		2920-428-3830	CONTACT SET, DISTRIBUTOR	EA		1						22	53
1484	X1		2920-740-2852	DEFLECTOR, DIRT AND OIL	EA		1						22	7
1485	X1		5315-367-7944	GASKET: COVER, LEAD	EA		1						22	43
1486	X1		5310-281-6688	PIN, LOCK: BREAKER ARM	EA		1						22	1
1487	X1		2920-353-6618	RING, RETAINING: ROTARY BEARINGS	EA		1						22	3
1488	X1		5305-514-9662	SEAL, PLAIN: OIL	EA		2	*	*	*	*	*	2	6
1489		O	5305-013-1238	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG	EA		1						2	3
1490	P	O	2920-013-1238	SCREW, MACHINE: CABLE CLAMP ATTACHMENT	EA		2	5	10	20	240	200	2	5
1491	P	O	2920-293-5212	SPARK PLUG: 18 MM	EA		2	3	3	5	60	200	2	2
1492		O	5330-509-5356	GASKET: SPARK PLUG	EA		1	*	*	*	*	*	2	2
1493		O	5310-013-8542	WASHER, LOCK: CABLE CLAMP ATTACHMENT	EA		2	*	*	*	*	*	22	45
1494		O	5310-582-9930	WASHER, LOCK: MAGNETO MTG	EA		2	*	*	*	*	*	22	
1495		O	5310-595-7237	WASHER, LOCK: MAGNETO MTG	EA		2	*	*	*	*	*	22	
1495				GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS										
1495				2210 - DATA PLATES										
1496	X2	O	2805-685-6019	PLATE, INSTRUCTION: ENGINE OPERATION	EA		1	*	*	*	*	*	*	*
1497	X2	O		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*	*	*	*
1498	X2	O		PLATE, NAME: MAGNETO	EA		1	*	*	*	*	*	*	*
1499		O	5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA		2	*	*	*	*	*	*	*

LINE NO.	SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING 100 EQUIP. CTYCY.	(9) DEPT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUS-TRATION	
								(a) 1-20	(b) 21-50	(c) 51-100			(g) FIG. NO.	(h) ITEM NO. OR
1500				GROUP 57 - SPRAY EQUIPMENT COMPONENTS										
1500A				5703 - AIR BLOWER ASSEMBLY										
1501	X2	O		FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	*	32	5
1502	X1	O		BODY, FILTER	EA		1	*	*	*	*	*	32	6
1503	X2	O		ELEMENT, FILTER SILENCER	EA		1	*	*	*	*	*	32	4
1504	P	O	3740-542-3716	GASKET: ELEMENT TO BODY AND TOP	EA		2	*	2	2	20	10	32	4
1505	X2	O	5310-010-3129	NUT, PLAIN, WING: TOP TO BODY	EA		1	*	*	*	*	*	32	1
1506	X2	O		TOP ASSEMBLY	EA		1	*	*	*	*	*	32	8
1507	M	O		FELT: TOP ASSEMBLY	EA		1	*	*	*	*	*	32	7
1507A	P	O	5330-191-1096	MANUFACTURE FROM: FELT SHEET	SH			SEE DRP 9501					32	
1508	O	O	5310-366-6294	(7 IN. BY 7 IN. REQUIRED)	EA		1	*	*	*	*	*	32	3
1509	O	O	5310-013-8542	WASHER, FLAT: TOP TO BODY	EA		1	*	*	*	*	*	32	2
1510				WASHER, LOCK: TOP TO BODY	EA									
1511	X2	O		5704 - SPRAY DUCTS AND MANIFOLDS										
1512	X2	O		MANIFOLD SPRAY ASSEMBLY	EA		1	*	*	*	*	*	34	2
1513	X2	O		CLAMP, DRUM	EA		5	*	*	*	*	*	34	10
1514	X2	O		ELBOW, LONG	EA		1	*	*	*	*	*	34	11
1515	X2	O		ELBOW, SHORT	EA		1	*	*	*	*	*	34	1
1516	X2	O		END CAP	EA		2	*	*	*	*	*	34	4
1517	X2	O		NOZZLE HEAD	EA		1	*	*	*	*	*	34	3
1518	X2	O	3440-977-8672	SCREW, TOGGLE: CLAMP DRUM CLAMPING	EA		5	*	*	*	*	*	34	16
1519	X2	O		NOZZLE ASSEMBLY: SPRAY	EA		10	*	*	*	*	*	34	
1520	X2	O		GROUP 76 - FIRE FIGHTING EQUIPMENT COMPONENTS										
1521	X2	O		7603 - FIRE EXTINGUISHERS										
1522	X2	O		BRACKET, MOUNTING: EXTINGUISHER	EA		1	*	*	*	*	*		
1523	X2	O	5310-616-6949	EXTINGUISHER, FIRE	EA		1	*	*	*	*	*		
1524	X2	O	5305-010-0959	NUT, PLAIN, HEXAGON: BRACKET MTG	EA		4	*	*	*	*	*		
1525	X2	O		SCREW, MACHINE: BRACKET MTG	EA		4	*	*	*	*	*		
1526	X2	O		WASHER, LOCK: BRACKET MTG	EA		8	*	*	*	*	*		
1527				GROUP 95 - GENERAL USE STANDARDIZED PARTS										
1528				9501 - BULK MATERIAL										
1529	P	O	5330-191-1096	FELT SHEET	SH			*	*	*	5	1		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING 100 EQUIP. CTYGY.	(9) DEPOT MAINT. 100 EQUIP. ALW. PER. PLANNING	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAIN						(a)	(b)	(c)			(a) FIG. NO.	(b) ITEM OR FIG. NO.
1527				PART V										
1527A				GROUP 01 - ENGINE										
1527B				0100 - ENGINE ASSEMBLY										
1528	X2	F	5305-527-1195	ENGINE, GASOLINE	EA		1	*	*	*	*	*	11	3
1529	F	F	5310-011-5551	SCREW, CAP, HEXAGON HEAD: ENGINE MTO	EA		4	*	*	*	*	*	11	4
1530	F	F		WASHER, LOCK: ENGINE MTO	EA		4	*	*	*	*	*	11	
1531				0101 - CRANKCASE, BLOCK, CYLINDER HEAD										
1532	X2	H		BLOCK ASSEMBLY, CYLINDER	EA		1	*	*	*	*	*	6	4
1533	P	F	2805-309-8040	SEAT, VALVE	EA		4	*	*	*	*	*		
1534		O	5307-011-2572	STUD, PLAIN: MANIFOLD MTO	EA		2	SEE GRP 0105 PART I			*	*		
1535	X2	O		EXTENSION, OIL DRAIN	EA		1	SEE GRP 0103 PART I	*	*	*	*		
1536				0102 - CRANKSHAFT										
1537	X2	O		SHEAVE, CRANKSHAFT: BLOWER DRIVE	EA		1	*	*	*	*	*	4	4
1538				0105 - VALVES, CAMSHAFTS AND TIMING SYSTEM										
1539	P	H	2805-536-9753	LIFTER, VALVE	EA		4	*	*	2	8	20	7	9
1540				0106 - ENGINE LUBRICATION SYSTEM										
1541		O	4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA		1	*	*	*	*	*	10	16
1542	X2	O	5306-543-4308	BOLT, MACHINE: FILTER MTO	EA		4	*	*	*	*	*	10	22
1543	X1	O	2940-358-2536	FILTER, FLUID, PRESSURE	EA		1	*	*	*	*	*	10	
1544	X2	O	2940-393-5988	COVER, ASSEMBLY	EA		1	*	*	*	*	*	10	20
1545	X1	O	5330-056-9588	COVER ASSEMBLY	EA		1	*	*	*	*	*	10	14
1546	X2	O		GASKET: FIBER	EA		1	*	*	*	*	*	10	10
1547	X1	O		HANDLE ASSEMBLY	EA		1	*	*	*	*	*	10	9
1548	X1	O		RING, SNAP	EA		1	*	*	*	*	*	10	7
1549	X2	O	5310-417-8620	WASHER, SHOULDERED, HELICAL SPRING	EA		1	*	*	*	*	*	10	11
1550	X2	O		SPRING, COMPRESSION	EA		1	*	*	*	*	*	10	13
1551	X2	O	5330-298-0776	WASHER, NONMETALLIC: COVER SCREW	EA		1	*	*	*	*	*	10	12
1552	P	O	5330-592-1285	FILTER ELEMENT	EA		1	13	25	2	15	100	10	8
1553	P	O	5330-592-1285	GASKET, COVER WASHER, NONMETALLIC	EA		1	13	25	50	600	100	10	23
1554	P	O	5310-368-1908	NUT, PLAIN, SQUARE: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	6
1555					EA		1	*	*	*	*	*	10	5

LINE NO.	(1) SOURCE MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY. IN UNIT	(6) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING	(9) DEPT. MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.					(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1556	X2	0		5305-013-3083	SCREW, MACHINE: OIL FILTER STRAP	EA	1	*	*	*	*	*	10	21
1557		0		2940-732-4214	STRAP: OIL FILTER MTG	EA	1	*	*	*	*	*	10	3
1558		0		5310-013-8542	WASHER, LOCK: OIL FILTER STRAP	EA	1	*	*	*	*	*	10	4
1559		0		5310-013-8542	NUT, PLAIN, HEXAGON: FILTER MTG	EA	4	*	*	*	*	*	10	1
1560		0		4730-603-1470	TEE, PIPE: OIL FILTER INLET	EA	1	*	*	*	*	*	10	15
1561	X2	0		2940-542-3807	TUBE ASSEMBLY, OIL	EA	1	*	*	*	*	*	10	25
1562		0		5310-596-4911	WASHER, LOCK: FILTER MTG	EA	4	*	*	*	*	*	10	2
1562A					GROUP 03 - FUEL SYSTEM									
1563					0306 - TANKS, LINES, FITTINGS									
1564	X2	0			CLIP, FUEL LINE	EA	1	*	*	*	*	*		
1565	X2	0			NUT: CLIP SCREW	EA	1	*	*	*	*	*		
1566	X2	0			SCREW: CLIP MTG	EA	1	*	*	*	*	*		
1567		0		5310-595-7235	WASHER, LOCK: CLIP MTG	EA	1	*	*	*	*	*		
1568					0309 - FUEL FILTERS									
1569	X2	0		4730-619-9638	STRAINER ASSEMBLY	EA	1	*	*	*	*	*	16	20
1570	X1	0		2910-382-8768	BAIL ASSEMBLY	EA	1	*	*	*	*	*	16	19
1571	P	0		2910-384-3834	BOWL, SEDIMENT: GLASS	EA	1	2	2	3	30	10	16	16
1572	X1	0		2910-305-5749	COVER, STRAINER	EA	1	*	*	*	*	*	16	16
1573	P	0		2910-142-2738	STRAINER ELEMENT, SEDIMENT	EA	1	*	*	*	*	*	16	17
1574	X1	0		2910-368-6657	VALVE, FUEL REGULATING: SHUT OFF	EA	1	*	*	*	*	*	16	21
1575	P	0		5330-187-2962	WASHER, NONMETALLIC	EA	1	4	8	17	200	100	16	18
1575A					GROUP 04 - EXHAUST SYSTEM									
1576					0401 - MUFFLER AND PIPES									
1577	X2	0			GUARD, MUFFLER	EA	1	*	*	*	*	*		
1578		0		5310-584-5005	NUT, PLAIN, HEXAGON: MUFFLER GUARD TO CANOPY	EA	4	*	*	*	*	*		
1579		0		5305-637-4028	SCREW, CAP, HEXAGON HEAD: MUFFLER GUARD TO CANOPY	EA	4	*	*	*	*	*		
1580		0		5310-011-5544	WASHER, LOCK: MUFFLER GUARD TO CANOPY	EA	8	*	*	*	*	*		
1581					GROUP 05 - COOLING SYSTEM									
1581A					0502 - DEFLECTORS, SHROUDS									
1582		F		5306-019-3988	BOLT, MACHINE: FLYWHEEL SHROUD MTG	EA	3	*	*	*	*	*	18	10
1583	F				SHROUD, FLYWHEEL	EA	1	*	*	*	*	*	18	8
1584	X2	F		5310-596-4911	WASHER, LOCK: FLYWHEEL SHROUD MTG	EA	3	*	*	*	*	*	18	9

LINE NO.	(1) SOURCE MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR ALW. DS/GS MAINT. ALW. PERCENT	(9) DEPT. ALW. PERCENT	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.						(c) 1-20	(d) 21-50	(e) 51-100			(a) FIG. NO.	(b) ITEM OR SYM.
1624	X1		5310-186-7410	WASHER, FLAT: CONTACT SUPPORT MTG	EA		2						36	19
1625	X1		2920-354-0750	WICK AND HOLDER, CAM	EA		1						35	22
1626	X1		5335-830-9983	WIRE, FABRIC, VENT	EA		2						35	25
1627	X1		2920-360-8381	GASKET: MAGNETO MTG (COMPONENT OF GASKET SET, STOCK NO. 2805-720-4773, SEE GROUP 0100, PART 1) (CAN BE MANUFACTURED FROM PAPER, STOCK NO. 5330-233-5846)	EA		1						36	3
1628	X2		2990-603-4773	GEAR, HELICAL: DRIVE	EA		1	*	*	*	*	*	36	4
1629	O		5310-012-0377	NUT, PLAIN, HEXAGON: MAGNETO MTG	EA		1	*	*	*	*	*	36	24
1630	O		5315-011-2726	PIN, COTTER: DRIVE GEAR	EA		2	*	*	*	*	*	36	23
1631	O		5305-514-9662	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG	EA		2	*	*	*	*	*	36	2
1632	O		5310-582-9930	WASHER, LOCK: MAGNETO MTG	EA		1	*	*	*	*	*	36	22
1633	O		5310-595-7237	WASHER, LOCK: MAGNETO	EA		1	*	*	*	*	*	36	
1634	P		2920-844-2035	REPAIR KIT, MAGNETO	EA		1	2		5			36	
1635	X1		2920-142-1888	ARM, CONTACT SET, DISTRIBUTOR	EA		1						36	20
1636	X1		5340-675-5253	CLIP, RETAINING	EA		1						36	9
1637	X1		5340-598-3180	CLIP, RETAINING: ROTOR DRIVE SHAFT	EA		1						35	3
1638	X1		2920-217-3489	CONDENSER	EA		1						36	16
1639	X1		5305-281-6387	GASKET: END CAP	EA		4						36	5
1640	X1		5305-281-6387	SCREW, CAP END	EA		1						36	8
1641	X1		2920-356-1221	SEAL, CONDENSER	EA		1						35	15
1642	X1		5310-794-8555	SEAL: ROTOR SHAFT	EA		1						35	5
1643	X1			SPACER, GROUND SWITCH	EA		1						36	10
1644	X1			WASHER, FLAT: RETAINING DRIVE END BEARING	EA		1						35	14
1645	X1		5310-205-7981	WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA		1						35	4
1646	X1		5310-205-7981	WASHER: GREASE RETAINING INNER BEARING SUPPORT	EA		1						35	4
1647	X1			WASHER: GREASE RETAINING, OUTER BEARING SUPPORT	EA		1						35	18
1648	X1		5310-285-1591	WASHER: ROTOR SHAFT OUTER SEAL	EA		1						35	6
1649	P		2920-887-1289	CABLE, IGNITION: SPARK PLUG	EA		2	*	*	*	*	10	35	4
1650	X2			CABLE, CABLE: SPARK PLUG WIRES	EA		2	*	*	*	*	*	2	1
1651	O		5305-013-1218	CLAMP, MACHINE: CABLE CLAMP MTG	EA		2	*	*	*	*	240	2	3
1652	P		2920-841-1890	SCREW, MACHINE: CABLE CLAMP MTG	EA		2	5	10	20	*	200	2	6
1653	O		5310-013-8542	SPARK PLUG	EA		1	*	*	*	*	*	2	2
1654	P		5330-599-5356	WASHER, LOCK: CABLE CLAMP MTG	EA		2	2	3	5	60	200	2	5
1655				GASKET: SPARK PLUG	EA									
				GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS										
				2210 - DATA PLATES										
1655A				PLATE, INSTRUCTION: ENGINE OPERATION	EA		1	*	*	*	*	*	*	*
1656	X2			PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*	*	*	*
1657	X2				EA		1	*	*	*	*	*	*	*

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PLANNING	(9) DEPT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION			
	(a)	(b)						(c)	(a)	(b)			(c)	(a)	(b)	
																MANUFACTURER'S

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. CTYGCY. PLANNING 100 EQUIP.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.	
1688					PART VI											
1688A					GROUP 01 - ENGINE											
1688R					0100 - ENGINE ASSEMBLY											
1689	X2	F		5305-27-1195	ENGINE, GASOLINE	EA		1	*	*	*	*	*	11	3	
1690		F		5310-011-5551	SCREW, CAP, HEXAGON HEAD: ENGINE MTG	EA		4	*	*	*	*	*	11	4	
1691		F			WASHER, LOCK: ENGINE MTG	EA		4	*	*	*	*	*			
1692					0101 - CRANKCASE, BLOCK, CYLINDER HEAD											
1693	X2	H	R		BLOCK ASSEMBLY, CYLINDER	EA		1	*	SEE GRP 0105	*	*	*	6	4	
1694	P	F		2805-309-2040	SEAT, VALVE	EA		4	*	PART II	*	*	*			
1695		O		5307-011-2572	STUD, PLAIN: MANIFOLD MTG	EA		2	SEE GRP 0108	SEE GRP 0108						
1696	X2	O			EXTENSION, OIL DRAIN	EA		1	*	PART I	*	*	*			
1697					0102 - CRANKSHAFT											
1698	X2	O			SHOULDER, CRANKSHAFT: BLOWER DRIVE	EA		1	*	*	*	*	*	4	4	
1699					0105 - VALVES, CAMSHAFTS AND TIMING SYSTEM											
1700	P	H		2805-536-0753	LIFTER, VALVE	EA		4	*	*	2	8	20	7	9	
1701					0106 - ENGINE LUBRICATION SYSTEM											
1702		O		4730-274-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TFI TO GOVERNOR OIL LINE	EA		1	*	*	*	*	*	10	16	
1703		O		5306-543-4308	BOLT, MACHINE: FILTER MTG	EA		4	*	*	*	*	*	10	22	
1704	X2	O		2940-358-2536	FILTER, FLUID, PRESSURE	EA		1	*	*	*	*	*	10	20	
1705	X1	O			HOODY, ASSEMBLY	EA		1	*	*	*	*	*	10	14	
1706	X2	O		2940-393-5588	COVER ASSEMBLY	EA		1	*	*	*	*	*	10	10	
1707	X1	O			COVER, FILTER	EA		1	*	*	*	*	*	10	9	
1708	X2	O		5330-076-9588	GASKET: FIBER	EA		1	*	*	*	*	*	10	7	
1709	X1	O			HANDLE ASSEMBLY	EA		1	*	*	*	*	*	10	11	
1710	X2	O			RING, SNAP	EA		1	*	*	*	*	*	10	13	
1711	X2	O			WASHER, SHOULDRED	EA		1	*	*	*	*	*	10	12	
1712	X2	O		5310-417-8620	SPRING, COMPRESSION	EA		1	*	*	*	*	*	10	8	
1713	P	O		5330-298-0776	WASHER, NONMETALLIC: COVER SCREW	EA		1	*	2	2	15	100	10	23	
1714	P	O		2940-141-9025	FILTER ELEMENT	EA		1	13	25	50	600	100	10	6	
1715	P	O		5330-599-1285	GASKET, COVER WASHER, NONMETALLIC	EA		1	13	25	50	600	100	10		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. P. 100 EQUIP. CTYCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION			
								(a)	(b)	(c)			(a)	(b)		
	(a)	(b)														
	(a)	(b)														

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	MANUFACTURER'S		(4) UNIT OF ISSUE	(5) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. AL. W.			(8) 1-YR. AL. W. PER 100 EQUIP. CTRY. PLANNING	(9) DEPOT MAINT. AL. W. PER 100 EQUIP.	(10) ILLUS. TRATION	
	(a) SO	(b) MAINT	(c) RECOV.		CODE	PART NUMBER			(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM NO.
1749	X1			5305-012-1832		82796 6560	EA	2						36	17
1750	X1			5305-543-2218		82697 856N	EA	2						35	26
1751	X1			5310-794-8554		82796 3155128	EA	1						36	14
1752	X1					82796 JX2514C	EA	1						35	28
1753	X1					82796 8LW6	EA	1						36	13
1754	X1					82796 DZ735A	EA	1						36	12
1755	X1					82796 CW2514	EA	1						36	11
1756	X1					82796 E2513A	EA	1						35	7
1757	X1					72987 ZV2563C	EA	1						35	9
1758	X1					82796 WT2563	EA	1						35	8
1759	X1					82796 AZ5957	EA	1						35	27
1760	X1			2920-128-7583		82796 E2565	EA	1						35	19
1761	X1			2920-128-7572		82796 C5963	EA	1						35	13
1762	X1			2920-602-4258		82796 D5949A	EA	1						35	11
1763	X1			3110-144-8988		82796 C5949	EA	1						35	24
1764	X1			2920-286-2712		82796 F2572	EA	1						35	15
1765	X1					82796 C2741	EA	1						35	12
1766	X1			2920-831-1171		82796 B6030A	EA	2						35	21
1767	X1			5315-715-1699		82796 3K1	EA	1						35	2
1768	X1			5310-336-7158		82796 M2570	EA	1						35	17
1769	X1			5305-206-8263		82796 856G	EA	4						35	20
1770	X1			5305-206-0109		82796 654U	EA	2						35	19
1771	X1			5305-206-0109		82796 AZ568	EA	1						35	25
1772	X1			2920-537-1330		82796 B3967	EA	2						35	3
1773	X1			2920-354-0766		82796 B14631	EA	1						36	
1774	X1					82796 B2665K	EA	2						35	
1775	X1			5310-186-7410		82796 B5969	EA	2						35	
1776	X1			2920-354-0750		82796 C2788	EA	1						35	
1777	X1			5335-830-9983		82796 C6032B	EA	2						35	
1778	X1			2920-360-8381		66289 Q6616	EA	1						36	
1779	X2	0		(COMPONENT OF GASKET SET, STOCK NO. 2805-720-4773, SEE GROUP 0100, PART 1)		66289 Q093C3	EA	1						36	4
1780		0		(CAN BE MANUFACTURED FROM PAPER, STOCK NO. 5330-233-5846)			EA	1						36	24
1781		0		GEAR, HELICAL: DRIVE			EA	1						36	23
1782		0		NUT, PLAIN, HEXAGON: MAGNETO MTG			EA	1						36	1
1783		0		PIN, COTTER: DRIVE GEAR			EA	2						36	2
1784		0		SCREW, CAP, HEXAGON HEAD: MAGNETO MTG			EA	1						36	22
1785	P	0		WASHER, LOCK: MAGNETO MTG		66289 PE76A	EA	1						36	20
1786				WASHER, LOCK: MAGNETO MTG		66289 PL56A	EA	1						35	3
1787	X1			REPAIR KIT, MAGNETO		82796 SK72	EA	1						36	9
1788	X1			ARM, CONTACT SET, DISTRIBUTOR		82796 Q2437A	EA	1						36	
				CLIP, RETAINING: ROTOR DRIVE SHAFT		82796 B1498B	EA	1						35	
				CLIP, RETAINING: SWITCH		82796 C1498C	EA	1						36	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. CODE						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR NO.
1789	X1			CONDENSER	EA		1						36	16
1790	X1		2910-217-3489	GASKET: END CAP	EA		1						36	8
1791	X1		5305-281-6387	SCREW, CAP END	EA		4						36	8
1792	X1			SEAL, CONDENSER	EA		1						36	15
1793	X1		2920-356-1221	SEAL, ROTOR SHAFT	EA		1						32	5
1794	X1			SPACER, GROUND SWITCH	EA		1						36	10
1795	X1		5310-794-8555	WASHER, FLAT: RETAINING DRIVE END BEARING	EA		1						35	14
1796	X1		5310-205-7981	WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA		1						35	4
1797	X1		5310-205-7981	WASHER: GREASE RETAINING INNER BEARING SUPPORT	EA		1						35	4
1798	X1			WASHER: GREASE RETAINING, OUTER BEARING SUPPORT	EA		1						35	18
1799	X1		5310-285-1591	WASHER: ROTOR SHAFT OUTER SEAL	EA		1						35	6
1800	P	0	2920-887-1289	CABLE, IGNITION: SPARK PLUG	EA		2	*	*	2	10	10	2	4
1801	X2	0		CLAMP, CABLE: SPARK PLUG WIRES	EA		2	*	*	*	*	*	2	1
1802	P	0	5305-013-1238	SCREW, MACHINE: CABLE CLAMP MTG	EA		2	5	10	20	240	200	2	3
1803	P	0	2920-841-1890	SPARK PLUG	EA		1	*	*	*	*	*	2	2
1804	P	0	5310-013-8542	WASHER, LOCK: CABLE CLAMP MTG	EA		2	2	3	5	60	200	2	5
1805	P	0	5330-599-5356	GASKET: SPARK PLUG	EA									
1806				GROUP 22 - BODY CHASSIS OR HULL AND ACCESSORY ITEMS										
1806				2210 - DATA PLATES										
1807	X2	0		PLATE, INSTRUCTION: ENGINE OPERATION	EA		1	*	*	*	*	*		
1808	X2	0		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*	*		
1809	X2	0		PLATE, NAME: MAGNETO	EA		2	*	*	*	*	*		
1810		0	5305-335-4180	SCREW, DRIVE: NAMEPLATE MTG	EA									
1811				GROUP 57 - SPRAY EQUIPMENT COMPONENTS										
1811				5703 - AIR BLOWER ASSEMBLY										
1812	X2	0		ADAPTER: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*	37	1
1813	X2	0		ELBOW: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*	37	5
1814	X1	0		FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	*	37	2
1815	X1	0		BODY, FILTER	EA		1	*	*	*	*	*	37	3
1816	X2	0		BOLT, MACHINE: TOP	EA		1	*	*	*	*	*	37	4
1817	X2	0		ELEMENT, FILTER STRAINER	EA		1	*	*	*	*	*	37	
1818	X2	0		TOP ASSEMBLY	EA		1	*	*	*	*	*	37	
1819	X2	0	5310-227-6566	WASHER, FLAT: TOP	EA		1	*	*	*	*	*	37	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PLANNING	(9) DEPT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION				
	(a) SOURCE	(b) MAINT						(c) RECOV	(a) 1-20	(b) 21-50			(c) 51-100	(a) FIG. NO.	(b) ITEM OR SYM.		
1820				5704 - SPRAY DUCTS AND MANIFOLDS													
1821	X2	O		NOZZLE ASSEMBLY: SPRAY	EA		10	*	*	*	*	*	*	34	16		
1822	X1			HUB, ASSEMBLY	EA		10										
1823	X1			IMPELLER: SPRAY NOZZLE	EA		10										
1824	X1			NUT, SELF-LOCKING, HEXAGON: FACE	EA		20										
1825	X1			PLATE SCREW	EA		10										
1826	X1			SCREW, MACHINE: FACE PLATE TO NOZZLE, No. 4-40 TWO SIZE, 3/8 IN. LG	EA		20	*	*	*	*	*	*				
1827	X2	O		CLAMP ASSEMBLY: NOZZLE ASSEMBLY	EA		3	*	*	*	*	*	*	38	1		
1828	X2	O		NOZZLE HEAD ASSEMBLY: SPRAY	EA		1	*	*	*	*	*	*	38	4		
1829	X2	O		BODY: NOZZLE HEAD	EA		1	*	*	*	*	*	*	38	2		
1830	X2	O		COVER: NOZZLE HEAD	EA		2	*	*	*	*	*	*	38	3		
1831	P	O		GASKET, LONG: COVER MTG	EA		4	2	2	3	40	10	38				
1832	P	O		GASKET, SHORT: COVER MTG	EA		4	2	2	3	40	10	38				
1833	X2	O		SCREW, MACHINE: COVER MTG, 1/4-28 TWO SIZE, 1/2 IN. LG	EA		28	*	*	*	*	*	*	38	6		
1834	X2	O		WASHER, LOCK: COVER MTG, 1/4 I.T.	EA		28	*	*	*	*	*	*	38	5		
1835				GROUP 76 - FIRE FIGHTING EQUIPMENT COMPONENTS													
1835A				7603 - FIRE EXTINGUISHERS													
1836	X2	O		BRACKET, MOUNTING: FIRE EXTINGUISHER	EA		1	*	*	*	*	*	*				
1837	X2	O		EXTINGUISHER, FIRE	EA		1	*	*	*	*	*	*				
1838	X2	O		NUT, PLAIN, HEXAGON: BRACKET MTG, 1/4-20 TWO SIZE	EA		2	*	*	*	*	*	*				
1839	X2	O		SCREW, MACHINE: BRACKET MTG, 1/4-20 x 1/2	EA		2	*	*	*	*	*	*				
1840	X2	O		WASHER, LOCK: BRACKET MTG, 1/4 IN. SCREW SIZE	EA		2	*	*	*	*	*	*				


LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY IN UNIT	(7) 30-DAY DS.GS MAINT. ALW.			(8) 1-YR. ALW. P. 100 EQUIP. CTY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT. AND RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM NO.
1841				PART VII										
1841A				GROUP 01 - ENGINE										
1841B				0100 - ENGINE ASSEMBLY										
1842	X2	F	5305-527-4195	ENGINE, GASOLINE	EA		1	*	*	*	*	*	11	3
1843		F	5305-527-4195	SCREW, CAP, HEXAGON HEAD: ENGINE MTG	EA		4	*	*	*	*	*	11	4
1844		F	5310-011-5551	WASHER, LOCK: ENGINE MTG	EA		4	*	*	*	*	*		
1845				0101 - CRANKCASE, BLOCK, CYLINDER HEAD										
1846	X2	H		BLOCK ASSEMBLY, CYLINDER	EA		1	*	*	*	*	*	6	4
1847	P	F	2805-309-8040	SEAT, VALVE	EA		4	*	*	*	*	*		
1848		O	5307-011-2572	STUD, PLAIN: MANIFOLD MTG	EA		2	SEE GRP 0105 PART II	SEE GRP 0105 PART II		*	*		
1849	X2	O		EXTENSION, OIL DRAIN	EA		1	*	*	*	*	*		
1850				0102 - CRANKSHAFT										
1851	X2	O		SHEAVE, CRANKSHAFT: BLOWER DRIVE	EA		1	*	*	*	*	*	4	4
1852				0105 - VALVES, CAMSHAFTS AND TIMING SYSTEM										
1853	P	H	2805-536-8753	LIFTER, VALVE	EA		4	*	*	2	8	20	7	9
1854				0106 - ENGINE LUBRICATION SYSTEM										
1855		O	4730-278-4323	ADAPTER, STRAIGHT, PIPE TO TUBE: TEE TO GOVERNOR OIL LINE	EA		1	*	*	*	*	*	10	16
1856		O	5306-543-4308	BOLT, MACHINE: FILTER MTG	EA		4	*	*	*	*	*	10	22
1857	X2	O	2940-358-2436	FILTER, FLUID, PRESSURE	EA		1	*	*	*	*	*	10	20
1858	X1	O	2940-358-2536	BODY, ASSEMBLY	EA		1	*	*	*	*	*	10	14
1859	X2	O	2940-393-5988	COVER ASSEMBLY	EA		1	*	*	*	*	*	10	10
1860	X1	O		COVER, FILTER	EA		1	*	*	*	*	*	10	9
1861	X2	O	5330-056-9588	GASKET: FIBER	EA		1	*	*	*	*	*	10	7
1862	X1	O		HANDLE ASSEMBLY	EA		1	*	*	*	*	*	10	11
1863	X2	O		RING, SNAP	EA		1	*	*	*	*	*	10	13
1864	X2	O	5310-417-8620	WASHER, SHOULDERS	EA		1	*	*	*	*	*	10	12
1865	X2	O		SPRING, COMPRESSION	EA		1	*	*	*	*	*	10	8
1866	P	O	5330-298-0776	WASHER, NONMETALLIC: COVER SCREW	EA		1	*	*	2	15	100	10	23
1867	P	O	2940-141-9025	FILTER ELEMENT	EA		1	13	25	50	600	100	10	6
1868	P	O	5330-599-1285	GASKET, COVER WASHER, NONMETALLIC	EA		1	13	25	50	600	100	10	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS-GS MAINT. ALW.			(8) 1-YR. ALW. P. 100 EQUIP. CTYCY. PLANNING	(9) DEPT. ALW. P. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR SYM. NO.
1869		O		5310-368-1908	NUT, PLAIN, SQUARE: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	5
1870		O		5305-013-3083	SCREW, MACHINE: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	21
1871	X2	O		2940-732-4214	STRAP: OIL FILTER MTG	EA		1	*	*	*	*	*	10	3
1872		O		5310-013-8542	WASHER, LOCK: OIL FILTER STRAP	EA		1	*	*	*	*	*	10	4
1873		O		5310-176-8160	NUT, PLAIN, HEXAGON: FILTER MTG	EA		4	*	*	*	*	*	10	1
1874		O		4730-603-4470	TEE, PIPE: OIL FILTER INLET	EA		1	*	*	*	*	*	10	15
1875	X2	O		2940-542-3807	TUBE ASSEMBLY, OIL	EA		1	*	*	*	*	*	10	25
1876		O		5310-596-4911	WASHER, LOCK: FILTER MTG	EA		4	*	*	*	*	*	10	2
1876A					GROUP 03 - FUEL SYSTEM										
1877					0309 - FUEL FILTERS										
1878	X2	O		4730-639-9638	STRAINER ASSEMBLY	EA		1	*	*	*	*	*	16	20
1879	X1	O		2910-382-8768	BOWL, SEDIMENT	EA		1	2	2	3	30	10	16	19
1880	P	O		2910-354-3834	COVER, STRAINER	EA		1	*	*	*	10	20	16	16
1881	X1	O		2910-305-5749	STRAINER ELEMENT, SEDIMENT	EA		1	*	*	2	10	17	16	17
1882	P	O		2910-142-2738	VALVE, FUEL REGULATING: SHUT OFF	EA		1	4	8	17	200	10	16	21
1883	X1	O		2910-368-6657	WASHER, NONMETALLIC: BOWL MTG	EA		1						16	18
1884	P	O		5330-187-2962											
1885					GROUP 05 - COOLING SYSTEM										
1885A					0502 - DEFLECTORS, SHROUDS										
1886		F		5306-019-3988	BOLT, MACHINE: FLYWHEEL SHROUD MTG	EA		3	*	*	*	*	*	18	10
1887	X2	F			SHROUD, FLYWHEEL	EA		1	*	*	*	*	*	18	8
1888		F		5310-596-4911	WASHER, LOCK: FLYWHEEL SHROUD MTG	EA		3	*	*	*	*	*	18	9
1889					GROUP 06 - ELECTRICAL SYSTEM										
1889A					0605 - IGNITION COMPONENTS										
1890	P	O	R	2920-979-3504	MAGNETO (INCLUDES COMPONENTS OF REPAIR KIT, Stock No. 2920-844-2035)	EA		1	*	*	2	10	2		
1891	X1				CAP, END: MAGNETO	EA		1						36	7
1892	X1				COIL, MAGNETO	EA		1						35	16
1893	X1				FERRULE	EA		1						35	1
1894	X1				HOUSING: MAGNETO	EA		1						36	6
1895	X1				OUTLET, CABLE	EA		1							
1896	X2	O			PLATE, NAME: MAGNETO	EA		1		SEE ERP 2210					
1897	X1				ROTOR, MAGNETIC	EA		1						35	30
1898	X1				SCREW: CONDENSER TERMINAL	EA		1						36	
1899	X1			5305-042-0450	SCREW: CONTACT SUPPORT	EA		2							18

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING 100 EQUIP.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION				
	SOURCE	MAIN	RECOV.						(a)	(b)	(c)			(a)	(b)	(c)		
1900	X1			5305-010-0749	SCREW, MACHINE: BREAKER ARM TERMINAL	82796	8SHU	EA	1						36	21		
1901	X1				SCREW, MACHINE: CABLE OUTLET No. 8-32 x 7/16 IN.	82796	857K	EA	1						35	29		
1902	X1			5305-012-1832	SCREW, MACHINE: CONDENSER MTG	82796	6S60	EA	2						36	17		
1903	X1				SCREW, MACHINE: WASHER RETAINING, 8-32 x 3/8 IN.	82796	8SGN	EA	1									
1904	X1			5305-543-2281	SETSCREW: COIL BRIDGE	82796	31SS12B	EA	2						35	26		
1905	X1				SWITCH COMPLETE GROUND	82796	JX2514C	EA	1						36	14		
1906	X1			5310-794-8554	WASHER, LOCK: RETAINING WASHER SCREW	82796	8LW6	EA	1						35	28		
1907	X1				NUT, GROUND SWITCH	82796	D2735A	EA	1						36	13		
1908	X1				PLUNGER, GROUND SWITCH	82796	QW2514	EA	1						36	12		
1909	X1				SPRING, GROUND SWITCH	82796	E2513A	EA	1						36	11		
1910	X1				COUPLING, IMPULSE	82796	WZ2563C	EA	1						35			
1911	X1				COUPLING, HUB ASSEMBLY	82796	A75957	EA	1						35	7		
1912	X1				SHELL, COUPLING	82796	E2565	EA	1						35	9		
1913	X1			2920-428-7583	SPRING, COUPLING DRIVE	82796	C5963	EA	1						35	8		
1914	X1			2920-428-7572	SPRING, PAWL	82796	D5949A	EA	1						35	27		
1915	X1			2920-602-4258	BEARING, CAM END	82796	C5949	EA	1						35	19		
1916	X1			3110-144-8998	BUSHING: GEAR COUPLING	82796	F2572	EA	1						35	13		
1917	X1			2920-286-2712	BUTTON, GROUND SWITCH	82796	C2741	EA	1						35	11		
1918	X1				COVER, VENT	82796	B6030C	EA	1						35	24		
1919	X1			2920-831-1171	KEY: ROTOR SHAFT TO IMPULSE COUPLING	82796	3K1	EA	2						35	15		
1920	X1			5315-615-1699	NUT, CASTELLATED, HEXAGON: COUPLING	82796	M2570	EA	1						35	12		
1921	X1			5310-336-7158	SCREW, MACHINE: BEARING SUPPORT	82796	8S6G	EA	1						35	21		
1922	X1			5305-206-8263	SCREW, VENT: No. 6-32 x 1/4 IN.	82796	6S4U	EA	4						35	23		
1923	X1				SETSCREW: COUPLING PAWL STOP	82796	A2568	EA	2						35	2		
1924	X1			5305-206-0169	SPRING, COIL LEAD	82796	B3967	EA	1						35	17		
1925	X1			2920-537-1330	SUPPORT, BEARING	82796	BY4631	EA	2						35	20		
1926	X1			2920-354-0766	WASHER: COUPLING PLATE	82796	B2665K	EA	1						35	10		
1927	X1				WASHER, FLAT: CONTACT SUPPORT MTG	82796	B5369	EA	1						36	19		
1928	X1			5310-186-7410	WICK AND HOLDER, CAM	82796	G2788	EA	2						35	22		
1929	X1			2920-354-0750	WIRE, FABRIC, VENT	82796	C60328	EA	1						35	25		
1930	X1			5335-830-9943	GASKET: MAGNETO MTG	66289	QD616	EA	2						36			
1931	X1			2920-360-8361	(COMPONENT OF GASKET SET, STOCK No. 2805-720-4773, Src Group C100, PART 1)			EA	1									
					(CAN BE MANUFACTURED FROM PAPER, STOCK No. 5330-233-5846)													
1932	X2	0		2930-603-4773	GEAR, HELICAL: DRIVE	66289	QD93C3	EA	1						36	4		
1933		0		5315-011-2726	PIN, COTTER: DRIVE GEAR			EA	1						36	23		
1934		0		5310-012-0377	NUT, FLAIN, HEXAGON: MAGNETO MTG			EA	1						36	24		
1935		0		5305-514-8662	SCREW, CAP, HEXAGON HEAD: MAGNETO MTG			EA	2						36	1		
1936		0		5310-582-9930	WASHER, LOCK: MAGNETO MTG			EA	2						36	2		
1937		0		5310-595-7237	WASHER, LOCK: MAGNETO MTG			EA	1						36			
1938	P			2920-244-2035	REPAIR KIT, MAGNETO			EA	1						36	22		
1939	X1			2920-142-1888	ARM, CONTACT SET, DISTRIBUTOR			EA	1						36	20		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE		(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY IN UNIT	(7) 30-DAY DS.GS MAINT. ALW.			(8) 1-YR. ALW. P. 100 EQUIP. CTRY. PLANNING	(9) DEPT. MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) SYM. NO.
1940	X1		5340-598-3180	CLIP, RETAINING: ROTOR DRIVE SHAFT	EA		1						35	3
1941	X1		5340-675-5253	CLIP, RETAINING: SWITCH CONDENSER	EA		1						36	9
1942	X1		2920-217-3486	GASKET: IND CAP	EA		1						36	16
1943	X1		5305-281-6387	SCREW, CAP END	EA		1						36	5
1944	X1		2920-356-1221	SEAL, CONDENSER	EA		4						36	8
1945	X1		5310-794-8555	SEAL: ROTOR SHAFT	EA		1						36	15
1946	X1			SPACER, GROUND SWITCH	EA		1						35	5
1947	X1			WASHER, FLAT: RETAINING DRIVE END BEARING	EA		1						36	10
1948	X1			WASHER, FLAT: ROTOR SHAFT INNER SEAL	EA		1						35	14
1949	X1		5310-205-7981	WASHER: GREASE RETAINING INNER BEARING SUPPORT	EA		1						35	4
1950	X1		5310-205-7981	WASHER: GREASE RETAINING, OUTER BEARING SUPPORT	EA		1						35	4
1951	X1			WASHER: ROTOR SHAFT OUTER SEAL	EA		1						35	18
1952	X1		5310-285-1521	CABLE, IGNITION: SPARK PLUG	EA		1						35	5
1953	X2	0	2920-887-1289	CLAMP, CABLE: SPARK PLUG WIRES	EA		2	*	*	2	10	10	2	4
1954	X2	0		SCREW, MACHINE: CABLE CLAMP MTG	EA		2	*	*	*	*	*	2	1
1955	P	0	5305-013-1238	SPARK PLUG	EA		2	5	10	20	240	200	2	3
1956	P	0	2920-841-1890	WASHER, LOCK: CABLE CLAMP MTG	EA		1	*	*	*	60	200	2	6
1957	P	0	5310-013-8542	GASKET: SPARK PLUG	EA		2	2	3	5		200	2	5
1958			5330-599-5356	GROUP 22 - BODY CHASSIS OR HULL, AND ACCESSORY ITEMS										
1959				2210 - DATA PLATES										
1959A				PLATE, INSTRUCTION: ENGINE OPERATION	EA		1	*	*	*	*	*		
1960	X2	0		PLATE, INSTRUCTION: MILITARY STANDARD PARTS	EA		1	*	*	*	*	*		
1961	X2	0		PLATE, NAME: MAGNETO	EA		1	*	*	*	*	*		
1962	X2	0		SCREW, DRIVE: NAME PLATE MTG	EA		2	*	*	*	*	*		
1963			5305-335-4180	GROUP 57 - SPRAY EQUIPMENT COMPONENTS										
1964				5703 - AIR BLOWER ASSEMBLY										
1964A				ADAPTER: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*		
1965	X2	0		ELBOW: OVERBOARD OIL DRAIN	EA		1	*	*	*	*	*		
1966	X2	0	4730-230-1924	FILTER, SILENCER: AIR BLOWER	EA		1	*	*	*	*	*	37	1
1967	X1	0		BODY, FILTER	EA		1	*	*	*	*	*	37	5
1968	X1	0		BOLT, MACHINE: TOP	EA		1	*	*	*	*	*	37	2
1969	X2	0		ELEMENT, FILTER, STRAINER	EA		1	*	*	*	*	*	37	
1970	X2	0			EA		1	*	*	*	*	*	37	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS GS MAINT. ALW.			(8) 1-YR. ALW. PER. PLANNING CTYGCY. 100 EQUIP.	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a)	(b)	(c)						(a)	(b)	(c)			(a) FIG. NO.	(b) ITEM OR NO.
1971	X2	0			TOP ASSEMBLY	EA		1	*	*	*	*	*	37	3
1972		0		5310-227-6566	WASHER, FLAT: TOP	EA		1	*	*	*	*	*	37	4
1973					5704 - SPRAY DUCTS AND MANIFOLDS										
1974	X2	0			NOZZLE ASSEMBLY: SPRAY										
1975	X1				HUB ASSEMBLY	EA		10			*	*	*	34	16
1976	X1				IMPELLER: SPRAY. NOZZLE	EA		10							
1977	X1				NUT, SELF-LOCKING, HEXAGON: FACE	EA		10							
1978	X1				PLATE SCREW	EA		20							
1979	X1				PLATE, FACE	EA		10							
1980	X2	0			SCREW, MACHINE: FACE PLATE TO NOZZLE, No. 4-40 THD SIZE, 3/4 IN. LG	EA		20							
1981	X2	0			BODY: NOZZLE HEAD	EA		1	*	*	*	*	*	38	1
1982	X2	0			CLAMP ASSEMBLY: NOZZLE ASSEMBLY	EA		3	*	*	*	*	*	38	4
1983	X2	0			COVER: NOZZLE HEAD	EA		2	*	*	*	*	*	38	2
1984	P	0		5330-956-4306	GASKET, LONG: COVER MTG	EA		4	2	2	3	40	10	38	3
1985	X2	0		5330-925-0455	GASKET, SHORT: COVER MTG	EA		4	2	2	3	40	10	38	3
1986	X2	0			NOZZLE HEAD ASSEMBLY: SPRAY	EA		1	*	*	*	*	*	38	3
1987	X2	0			SCREW, MACHINE: COVER MTG, 1/4-28 THD SIZE, 1/2 IN. LG	EA		28	*	*	*	*	*	38	6
					WASHER, LOCK: COVER MTG, 1/4 I.T.	EA		28	*	*	*	*	*	38	5




MEC 3740-200-25P/1

Figure 1. Crankcase and Related Parts.

INDEX TO PARTS, FIGURE 1

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0102	1	SCREW	11	0106	1	WASHER	22	0106	1	GAGE-CP
2	0102	1	WASHER	12	0101	1	PLUG	23	0106	1	GASKET
3	0102	1	RETAINR	13	0102	1	STUD	24	0106	1	BODY
4	0105	1	PIN	14	0102	1	SHIM	25	0106	1	NIPPLE
5	0101	1	STUD	15	0102	1	GASKET	26	0101	1	PLUG
6	0101	1	NOZZLE	16	0102	1	RETAINR	27	0101	1	TUBE
7	0101	1	NUT	17	0102	1	SEAL	28	0101	1	CRNKCSE
8	0101	1	WASHER	18	0102	1	PLATE	29	0101	1	PIN
9	0101	1	PLUG	19	0102	1	NUT	30	0101	1	SPRING
10	0106	1	SCREW	20	0102	1	GASKET	31	0311	1	PACKING
11	0102	1	WASHER	21	0102	1	SHIM	32	0311	1	SHAFT




EMC 40-200-25P/2

Figure 2. Cylinder Head and Related Parts.

INDEX TO PARTS, FIGURE 2

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0605	2,3,4,5	CLAMP	5	0605	6,7	GASKET	12	0101	1	BOLT
1	0605	6,7	CLAMP	6	0605	2,3,4,5	SPK PLG	12	0105	1	BOLT
2	0605	2,3,4,5	WASHER	6	0605	6,7	SPK PLG	13	0101	1	GASKET
2	0605	6,7	WASHER	7	0101	1	INSERT	14	0105	1	GASKET
3	0605	2,3,4,5	SCREW	8	0101	1	CLOR HD	15	0105	1	PLATE
3	0605	6,7	SCREW	9	0101	1	BOLT	16	0105	1	WASHER
4	0605	2,3,4,5	CABLE	10	0101	1	WASHER	17	0105	1	PIN
4	0605	6,7	CABLE	11	0606	1	SWITCH	18	0101	1	BOLT
5	0605	2,3,4,5	GASKET								




MEC 3740-200-25P/3

Figure 3. Crankshaft Assembly and Related Parts.

INDEX TO PARTS, FIGURE 3

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0102	1	SLINGER	6	0102	1	CN-RLRS
2	0105	1	GEAR	7	0102	1	CUP
3	0102	1	CUP	8	0102	1	KEY
4	0102	1	CN-RLRS	9	0102	1	KEY
5	0102	1	CRKSHFT	10	0102	1	KEY




EMC 3740-200-259

Figure 4. Flywheel, Pulleys and Related Parts.

INDEX TO PARTS, FIGURE 4

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0102	1	SHEAVE	7	0103	1	FLYWHEEL	14	0102	1	NUT AT
2	0102	1	BOLT	8	0103	1	WASHER	15	1501	1	BRACKET
2	0103	1	BOLT	9	0502	1	CLIP	16	1501	1	SCREW
3	0102	1	BUSHING	10	0502	1	WASHER	17	0107	1	CRANK
4	0102	2,3,4,5	SHEAVE	10	1501	1	WASHER	18	0102	1	WASHER
4	0102	6,7	SHEAVE	11	0502	1	SCREW	19	0502	1	SCREEN
5	0103	1	SETSCRW	12	0102	1	PIN	20	0103	1	PULLEY
6	0103	1	GEAR	13	0102	1	NUT	21	0102	1	PIN



INDEX TO PARTS, FIGURE 5


REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0104	1	RING
2	0104	1	RING
3	0104	1	RING
4	0104	1	PISTON
5	0104	1	PIN
6	0104	1	RING
7	0104	1	BEARING
8	0104	1	BOLT
9	0104	1	ROD
10	0104	1	BEARING
11	0104	1	NUT
12	0104	1	NUT

MEC 3740-200-25P/5

Figure 5. Piston and Connecting Rod.

INDEX TO PARTS, FIGURE 6

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0105	1	VALVE
2	0105	1	GUIDE
3	0105	1	SEAT
4	0101	2,3,4,5	BLCK AY
4	0101	6,7	BLCK AY
5	0101	1	NUT
6	0101	1	WASHER
7	0101	1	GASKET
8	0105	1	SPRING
9	0105	1	SEAT
10	0105	1	RETAINR
11	0105	1	CAP
12	0108	1	STUD



EMC 3740-200-25 P/6

Figure 6. Block Assembly, Valve, Spring and Related Parts.





Figure 7. Camshaft and Related Parts.

INDEX TO PARTS, FIGURE 7

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0105	1	PIN	7	0105	1	GEAR
2	0105	1	PLUNGER	8	0105	2,4	SCREW
3	0105	1	BOLT	9	0105	2,3,4,5	LIFTER
4	0105	1	WASHER	9	0105	6,7	LIFTER
5	0105	1	SPRING	10	0105	1	CAMSHFT
6	0105	1	PLATE				




EMC 3740-200-25P 8

Figure 8. Timing Gear Cover and Related Parts.

INDEX TO PARTS, FIGURE 8

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0309	1	PACKING	8	0105	1	BOLT
2	0308	1	SHAFT	9	0105	1	GASKET
3	0105	1	COVER	10	0105	1	WASHER
4	0105	1	PLUG	11	0105	1	SCREW
5	0105	1	GASKET	12	0105	1	PLUG
6	0105	1	SPACER	13	0105	1	BOLT
7	0105	1	WASHER	14	0102	1	SEAL




EMC 3740-200-25P/9

Figure 9. Oil Pump.

INDEX TO PARTS, FIGURE 9

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0106	1	CAP	8	0106	1	BODY
2	0106	1	ROD	9	0106	1	CUP
3	0106	1	PLUNGER	10	0106	1	WASHER
4	0106	1	SPRING	11	0106	1	STRAINR
5	0106	1	RETAINR	12	0106	1	SCREW
6	0106	1	BALL	13	0106	1	WASHER
7	0106	1	GASKET				



EMC 3740-200-25 P/10

Figure 10. Oil Filter Assembly.

INDEX TO PARTS, FIGURE 10

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0106	2,3,4,5	NUT	8	0106	6,7	WASHER	17	0106	1	ELBOW
1	0106	6,7	NUT	9	0106	2,3,4,5	GASKET	18	0106	1	LINE AY
2	0106	2,3,4,5	WASHER	9	0106	6,7	GASKET	19	0106	1	ELBOW
2	0106	6,7	WASHER	10	0106	2,3,4,5	COVER	20	0106	2,3,4,5	BODY AY
3	0106	2,3,4,5	STRAP	10	0106	6,7	COVER	20	0106	6,7	BODY AY
3	0106	6,7	STRAP	11	0106	2,3,4,5	RING	21	0106	2,3,4,5	SCREW
4	0106	2,3,4,5	WASHER	11	0106	6,7	RING	21	0106	6,7	SCREW
4	0106	6,7	WASHER	12	0106	2,3,4,5	SPRING	22	0106	2,3,4,5	BOLT
5	0106	2,3,4,5	NUT	12	0106	6,7	SPRING	22	0106	6,7	BOLT
5	0106	6,7	NUT	13	0106	2,3,4,5	WASHER	23	0106	2,3,4,5	FTR LMT
6	0106	2	WASHER	13	0106	6,7	WASHER	23	0106	6,7	FTR LMT
6	0106	3	GASKET	14	0106	2,3,4,5	COVER	24	0106	2,4	HOSE AY
6	0106	4	WASHER	14	0106	6,7	COVER	25	0106	2	LINE AY
6	0106	5,6,7	GASKET	15	0106	2,3,4,5	TEE	25	0106	3	TUBE AY
7	0106	2,3,4,5	HANDLE	15	0106	6,7	TEE	25	0106	4	LINE AY
7	0106	6,7	HANDLE	16	0106	2,3,4,5	ADAPTER	25	0106	5,6,7	TUBE AY
8	0106	2,3,4,5	WASHER	16	0106	6,7	ADAPTER				





Figure 11. Oil Pan Engine Base.

INDEX TO PARTS, FIGURE 11

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0106	1	GASKET
2	0106	1	BASE
3	0100	2,3,4,5	SCREW
3	0100	6,7	SCREW
4	0100	2,3,4,5	WASHER
4	0100	6,7	WASHER
5	0106	1	PLUG
6	0106	1	SCREW
7	0106	1	WASHER


INDEX TO PARTS, FIGURE 12

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0304	1	NUT
2	0304	1	WASHER
3	0304	1	FTR-CAP
4	0304	1	GASKET
5	0304	1	CUP AY
6	0304	1	GASKET
7	0304	1	AR CLNR
8	0304	1	STUD
9	0304	1	BRACKET
10	0304	1	BOLT
11	0304	1	WASHER
12	0106	1	GASKET
13	0106	1	BREATHR
14	0304	1	GASKET
15	0304	1	CLAMP
16	0304	1	HOSE



EMC 3740-200-25P/12

Figure 12. Air Cleaner and Related Parts.



MEC 3740-200-25P/13

Figure 13. Fuel Tank and Related Parts.

INDEX TO PARTS, FIGURE 13

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0306	1	TUBE	7	0306	1	SCREW
2	0306	1	LINE	8	0306	1	WASHER
3	0306	1	CAP	9	0306	1	NUT
4	0306	1	WASHER	10	0306	1	SCREW
5	0306	1	TANK	11	0306	1	MOUNT
6	0306	1	STRAP	12	0306	1	PLUG





Figure 14. Governor Assembly.

INDEX TO PARTS, FIGURE 14

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0308	1	PLUG	11	0308	1	WASHER
2	0308	1	HOUSING	12	0308	1	BUSHING
3	0308	1	CLEVIS	13	0308	1	GEAR
4	0308	1	PIN	14	0308	1	SLV-BRG
5	0308	1	GASKET	15	0308	1	SFT-LVR
6	0308	1	WASHER	16	0308	1	PACKING
7	0308	1	SCREW	17	0308	1	SCREW
8	0308	1	PIN	18	0106	1	ELBOW
9	0308	1	FLYWGHT	19	0308	1	PLUG
10	0308	1	PIN				




EMC 3740-200-25 P/15

Figure 15. Governor Choke and Controls.

INDEX TO PARTS, FIGURE 15

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0308	1	SPRING	10	0308	1	SCREW
2	0308	1	PIN	11	0308	1	PIN
3	0308	1	PIN	12	0308	1	CHAIN
4	0308	1	SPRING	13	0308	1	SETSCRW
5	0308	1	RETAINR	14	0308	1	COLLAR
6	0308	1	PIN	15	0312	1	NUT
7	0308	1	NUT	16	0312	1	CONTROL
8	0308	1	LEVER	17	0308	1	CONTROL
9	0308	1	WASHER				



MEC 3740-200-25P/16


Figure 16. Intake, Manifold, Carburetor, Fuel Pump and Strainer.

INDEX TO PARTS, FIGURE 16

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0108	1	NUT	14	0302	1	WASHER	20	0309	2,3,4,5	BAIL AY
2	0108	1	WASHER	15	0302	1	SCREW	20	0309	6,7	BAIL AY
3	0108	1	CLAMP	16	0309	2,3,4,5	COVER	21	0309	2,3,4,5	VALVE
4	0301	1	BOLT	16	0309	6,7	COVER	21	0309	6,7	VALVE
5	0108	1	MANIFOLD	17	0309	2	SCREEN	22	0301	1	PLUG
6	0108	1	GASKET	17	0309	3	STR LMT	23	0301	1	CRBURTR
7	0306	1	ELBOW	17	0309	4	SCREEN	24	0301	1	GASKET
8	0306	1	NIPPLE	17	0309	5,6,7	STR LMT	25	0312	1	ROD
9	0302	1	PUMP	18	0309	2,3,4,5	WASHER	26	0301	1	GASKET
10	0302	1	GASKET	18	0309	6,7	WASHER	27	0312	1	PIN
11	0306	1	ELBOW	19	0309	2,3,4,5	BOWL	28	0108	1	PLUG
12	0306	1	LINE	19	0309	6,7	BOWL	29	0301	1	WASHER
13	0306	1	ADAPTER								


INDEX TO PARTS, FIGURE 17

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0401	1	CLAMP
2	0401	1	SCREW
3	0401	1	MUFFLER
4	0401	1	ELBOW
5	0401	1	PIPE
6	0108	1	MANIFOLD
7	0108	1	GASKET
8	0401	1	BOLT
9	0401	1	CAP
10	0401	1	SPRING
11	0401	1	SUPPORT
12	0401	1	WASHER
13	0401	1	SCREW
14	0401	1	NUT
15	0401	1	WASHER
16	0401	1	NUT
17	0401	1	CLAMP
18	0401	1	PLUG



MEC 3740-200-25P/17

Figure 17. Muffler, Pipe, Exhaust Manifold and Related Parts.




MEC 3740-20-25P/18

Figure 18. Shrouds, Cover and Related Parts.

INDEX TO PARTS, FIGURE 18

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0502	1	SHROUD	6	0502	1	DEFLCTR	9	0502	2,3,4,5	WASHER
2	0502	1	SCREW	7	0502	1	SCREW	9	9592	6,7	WASHER
3	0502	1	COVER	8	0502	2,3,4,5	SHROUD	10	0502	2,3,4,5	BOLT
4	0502	1	WASHER	8	0502	6,7	SHROUD	10	0502	6,7	BOLT
5	0502	1	SCREW								




MEC 3740-200-25P/19

Figure 19. Generator.

INDEX TO PARTS, FIGURE 19

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0601	1	BOLT	13	0601	1	RETAINR	25	0601	1	SPACER
2	0601	1	WASHER	14	0601	1	GASKET	26	0601	1	ARM
3	0601	1	BOLT	15	0601	1	BEARING	27	0601	1	BOLT
4	0601	1	WASHER	16	0601	1	RETAINR	28	0601	1	WASHER
5	0601	1	HEAD AY	17	0601	1	WASHER	29	0601	1	OILER
6	0601	1	PIN	18	0601	1	WASHER	30	0601	1	HEAD
7	0601	1	WASHER	19	0601	1	SCREW	31	0601	1	COVER
8	0601	1	NUT	20	0601	1	BELT	32	0601	1	BEARING
9	0601	1	AMMATURE	21	0601	1	NUT	33	0601	1	WICK
10	0601	1	KEY	22	0601	1	WASHER	34	0601	1	OILER
11	0601	1	RING	23	0601	1	PULLEY	35	0601	1	RETAINR
12	0601	1	RETAINR	24	0601	1	FAN				




MEC 3740-200-25P/20

Figure 20. Generator Brushes.

INDEX TO PARTS, FIGURE 20

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0601	1	SPRING
2	0601	1	ARM
3	0601	1	SCREW
4	0601	1	WASHER
5	0601	1	BRSH ST




MEC 3740-200-25P/21

Figure 21. Starter.

INDEX TO PARTS, FIGURE 21

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0603	1	SCREW	14	0603	1	ARMATURE	27	0603	1	WASHER
2	0603	1	GASKET	15	0603	1	WASHER	28	0603	1	SCREW
3	0603	1	BRACKET	16	0603	1	WASHER	29	0603	1	SPRING
4	0603	1	END BEL	17	0603	1	BEARING	30	0603	1	SPRING
5	0603	1	BRUSH	18	0603	1	GASKET	31	0603	1	HEAD
6	0603	1	BRUSH	19	0603	1	KEY	32	0603	1	WASHER
7	0603	1	NUT	20	0603	1	WASHER	33	0603	1	SETSCREW
8	0603	1	WASHER	21	0603	1	BOLT	34	0603	1	BOLT
9	0603	1	CABLE	22	4702	1	BRACKET	35	0603	1	SCREW
10	0603	1	SCREW	23	0603	1	HOUSING	36	0603	1	DISK
11	0603	1	BAND	24	0603	1	CAP	37	0603	1	SPRING
12	0603	1	NUT	25	0603	1	BEARING	38	0603	1	FRM-FLO
13	0603	1	WASHER	26	0603	1	SEAL				




MEC 3740-200-25P/22

Figure 22. Magneto.

INDEX TO PARTS, FIGURE 22

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0605	2,4	SCREW	21	0605	2,4	COIL	41	0605	2,4	SCREW
2	0605	2,4	WASHER	22	0605	2,4	CORE AY	42	0605	2,4	GASKET
3	0605	2,4	GASKET	23	0605	2,4	GEAR	43	0605	2,4	SEAL
4	0605	2,4	BEARING	24	0605	2,4	RING	44	0605	2,4	NUT
5	0605	2,4	RETAINR	25	0605	2,4	WASHER	45	0605	2,4	WASHER
6	0605	2,4	BEARING	26	0605	2,4	CUP	46	0605	2,4	BEARING
7	0605	2,4	RING	27	0605	2,4	SPRING	47	0605	2,4	CONT ST
8	0605	2,4	SHIELD	28	0605	2,4	NUT	48	0605	2,4	ROD GRP
9	0605	2,4	SPACER	29	0605	2,4	WASHER	49	0605	2,4	CONDNSR
10	0605	2,4	ROTOR	30	0605	2,4	WASHER	50	0605	2,4	SPRING
11	0605	2,4	HOUSING	31	0605	2,4	RETAINR	51	0605	2,4	WASHER
12	0605	2,4	GASKET	32	0605	2,4	SPRING	52	0605	2,4	WASHER
13	0605	2,4	SCREW	33	0605	2,4	ARM	53	0605	2,4	PIN
14	0605	2,4	WASHER	34	0605	2,4	SPACER	54	0605	2,4	WICK
15	0605	2,4	TML BLK	35	0605	2,4	FLANGE	55	0605	2,4	LEAD
16	0605	2,4	COVER	36	0605	2,4	DEFLECTR	56	0605	2,4	S AY WS
17	0605	2,4	WASHER	37	0605	2,4	PLATE	57	0605	2,4	BRACKET
18	0605	2,4	SCREW	38	0605	2,4	NUT	58	0605	2,4	FELT
19	0605	2,4	CLAMP	39	0605	2,4	SETSCRW	59	0605	2,4	WASHER
20	0605	2,4	S AY WS	40	0605	2,4	WASHER				




MEC 3740-200-25P/23

Figure 23. Stop Switch and Related Parts.

INDEX TO PARTS, FIGURE 23

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0607	1	COVER	7	0607	1	WASHER
2	0607	1	INSULTN	8	0607	1	NUT
3	0607	1	LEAD AY	9	0607	1	SWITCH
4	0606	1	WIRE AY	10	0607	1	SCREW
5	0607	1	GROMMET	11	0607	1	WASHER
6	0607	1	BOX				




MEC 3740-200-25P/24

Figure 24. Control Panel, Ammeter and Starter Switch.

INDEX TO PARTS, FIGURE 24

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0607	1	SCREW
2	0607	1	WASHER
3	0607	1	PANEL
4	0607	1	AMMETER
5	0607	1	CABLE
6	0607	1	NUT
7	0607	1	SWITCH
8	0607	1	SCREW



MEC 3740-200-25P/25

Figure 25. Battery Storage Holder and Leads.

INDEX TO PARTS, FIGURE 25

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0612	1	CABLE
2	0612	1	NUT
3	0612	1	WASHER
4	0612	1	CABLE
5	0612	1	CLAMP

INDEX TO PARTS, FIGURE 26

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0615	1	COVER	10	0615	1	LEAD	17	0602	1	NUT
2	0615	1	SCREW	11	0615	1	LEAD AY	17	0615	1	NUT
3	0615	1	WASHER	12	0615	1	LEAD AY	18	0602	1	WASHER
4	0602	1	REGULTR	13	0615	1	ADAPTER	18	0615	1	WASHER
5	0615	1	LEAD AY	14	0602	1	SCREW	19	0602	1	SCREW
6	0615	1	BASE AY	14	0615	1	SCREW	19	0615	1	SCREW
7	0615	1	CAPCTOR	15	0615	1	CAPCTOR	20	0615	1	NUT
8	0615	1	WASHER	16	0602	1	WASHER	21	0615	1	NUT
9	0615	1	SCREW	16	0615	1	WASHER	22	0615	1	LEAD





Figure 26. Voltage Regulator and Related Parts.



EMC 3740-200-25P/26


Figure 27. Chassis Frame, Belt Guard and Components.

INDEX TO PARTS, FIGURE 27

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5703	1	SCREW	6	1501	1	RIVET
2	5703	1	WASHER	7	1501	1	STUD
3	5703	1	GUARD	8	1501	1	CHASSIS
4	5703	1	SCREW	9	1501	1	RECPTCL
5	1501	1	FASTENR				


INDEX TO PARTS, FIGURE 28

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	1808	1	STRAP	10	1801	1	STUD	19	1808	1	STRAP
2	1808	1	STRAP	11	1801	1	RETAINR	20	1501	1	BOLT
3	1801	1	RETAINR	12	1801	1	GROMMET	21	1801	1	SCREW
4	1801	1	GROMMET	13	1801	1	STUD	22	1801	1	FLANGE
5	1801	1	STUD	14	1801	1	PANEL	23	2201	1	SHIM
6	1801	1	PANEL	15	1801	1	RECPTCL	24	2201	1	SHIM
7	2201	1	STRIP	16	1801	1	RIVET	25	1801	1	WASHER
8	2201	1	CURTAIN	16	2201	1	RIVET	25	2201	1	WASHER
9	1801	1	SCREW	17	1801	1	DCK PLT	26	1801	1	NUT
9	2201	1	SCREW	18	2201	1	RECPTCL	26	2201	1	NUT



MEC 3740-200-25P/28

Figure 28. Canopy Assembly and Deck Plate.




EMC 3740-200-25P/28

Figure 29. Water Pump, Sheave and Belt.

INDEX TO PARTS, FIGURE 29

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5507	1	KEY	15	5501	1	BUSHING	28	5505	1	PLUNGER
2	5507	1	BUSHING	16	5501	1	GEAR	29	5500	1	CAP
3	5507	1	SHEAVE	17	5501	1	GEAR	30	5708	1	UNION
4	5501	1	SCREW	18	5501	1	GER SET	31	5708	1	BUSHING
5	5501	1	GLAND	19	5500	1	PLUG	32	5500	1	HOUSING
6	5501	1	RING	20	5500	1	SCREW	33	5500	1	DOWEL
7	5501	1	PACKING	21	5500	1	SHIM	34	5708	1	NIPPLE
8	5501	1	SEAL	22	5500	1	WASHER	35	5708	1	COCK
9	5501	1	SPRING	23	5500	1	NUT	36	5708	1	TEE
10	5501	1	STOP	24	5505	1	SCREW	37	5708	1	ELBOW
11	5501	1	RING	25	5500	1	CAP	38	5507	1	BOLT
12	5500	1	NUT	26	5500	1	GASKET	39	5507	1	BELT
13	5500	1	FITTING	26	5505	1	GASKET	40	5500	1	SCREW
14	5500	1	STAND	27	5505	1	SPRING				




MEC 3740-200-25P/30

Figure 30. Air Blower Assembly.

INDEX TO PARTS, FIGURE 30

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5703	1	SCREW	12	5703	1	PLATE	23	5708	1	NIPPLE
2	5703	1	WASHER	13	5703	1	FITTING	24	5703	1	SCREW
3	5703	1	FITTING	14	5703	1	SCREW	25	5703	1	WASHER
4	5703	1	CAP	15	5703	1	SCREW	26	5703	1	FLANGE
5	5703	1	GASKET	16	5703	1	NUT	27	5703	1	PIN
6	5703	1	SCREW	17	5703	1	BRACKET	28	5703	1	GASKET
7	5703	1	WASHER	18	5703	1	ROTOR	29	5703	1	SCREW
8	5703	1	BEARING	19	5703	1	KEY	30	5703	1	WASHER
9	5703	1	SEAL	20	5708	1	ELBOW	31	5703	1	MANIFOLD
10	5703	1	PLUG	21	5708	1	COUPLING	32	5703	1	HOUSING
11	5703	1	BOLT	22	5708	1	LOCKNUT	33	5703	1	NUT



MEC 3740-200-25P/31

Figure 31. Cover, Plate, Pulley and Related Parts.

INDEX TO PARTS, FIGURE 31

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5703	1	PLATE	15	5703	1	PLATE	29	5703	1	WASHER
2	5703	1	SPACER	16	5703	1	SCREW	30	5703	1	RING
3	5703	1	PIN	17	5703	1	SHAFT	31	5703	1	GASKET
4	5703	1	PLUG	18	5703	1	PLATE	32	5703	1	NUT
5	5703	1	PLUG	19	5703	1	SCREW	33	5703	1	WASHER
6	5703	1	SPACER	20	5703	1	KEY	34	5703	1	SCREW
7	5703	1	SEAL	21	5703	1	BUSHING	35	5703	1	RETAINR
8	5703	1	BEARING	22	5703	1	BOLT	36	5703	1	WASHER
9	5703	1	PLATE	23	5703	1	BELT	37	5703	1	BASE
10	5703	1	BOLT	24	5703	1	PULLEY	38	5703	1	ELEMENT
11	5703	1	GEAR AY	25	5703	1	SEAL	39	5703	1	SHIELD
12	5703	1	SHIM	26	5703	1	COVER	40	5703	1	WASHER
13	5703	1	DOWEL	27	5703	1	PLUG	41	5703	1	SCREW
14	5703	1	NUT	28	5703	1	BOLT				





Figure 32. Air Filter Silencer.

INDEX TO PARTS, FIGURE 32

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5703	2,3,4	NUT	5	5703	2,3,4	BODY
2	5703	2,3,4	WASHER	6	5703	2,3,4	ELEMENT
3	5703	2,3,4	WASHER	7	5703	2,3,4	FELT
4	5703	2,3,4	GASKET	8	5703	2,3,4	TOP AY



MEC 3740-200-25P/33 ①


Figure 33 ① . Control Panel, Rear.

INDEX TO PARTS, FIGURE 33 ①

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5708	1	ELBOW	11	5708	1	SCREEN	21	5708	1	TUBE
2	5708	1	CUPLING	12	5708	1	CAP	22	5708	1	TUBE
3	5708	1	ELBOW	13	5708	1	PLUG	23	5708	1	TUBE
4	5708	1	LOCKNUT	14	5708	1	GASKET	24	4702	1	NUT
5	5707	1	NUT	15	5708	1	BUSHING	24	5708	1	NUT
6	5707	1	WASHER	16	5708	1	BODY	25	4702	1	TUBE
7	5707	1	PANEL	17	5708	1	BUSHING	26	4702	1	WASHER
8	5707	1	MOUNT	18	5708	1	TUBE	27	4702	1	TUBE
9	4702	1	WASHER	19	5708	1	CLIP	28	5708	1	LOCKNUT
10	4702	1	NUT	20	5708	1	SCREW	29	5708	1	CNNCTOR


INDEX TO PARTS, FIGURE 33 ②

REF NO.	FUNCT GROJP	APPL PARTS	ITEM NAME
30	5707	1	BRACKET
31	5707	1	SCREW
32	5708	1	BUSHING
33	5708	1	NIPPLE
34	5702	1	FLOAT
35	5702	1	STOP
36	5702	1	RING
37	5702	1	RING
38	5702	1	TUBE
39	5702	1	BODY
40	5702	1	SCREW
41	5702	1	MANOMTR
42	5702	1	SCREW
43	5708	1	WHEEL
44	5708	1	VALVE
45	5708	1	CLAMP
46	5708	1	SCREW
47	5708	1	CAP
48	5708	1	SPRING
49	5708	1	SCREEN
50	5708	1	SPRING
51	5708	1	BODY
52	5708	1	BUSHING
53	5708	1	CNNCTOR
54	5708	1	HOSE
55	5708	1	LOCKNUT
56	5708	1	NIPPLE
57	5708	1	UNION
58	5708	1	TEE
59	5708	1	ELBOW
60	5708	1	NIPPLE
61	5708	1	ELBOW
62	5702	1	VALVE
63	5708	1	VALVE
64	5708	1	SCREW
65	5702	1	GAGE
66	5708	1	NIPPLE
67	5702	1	PLUG
68	5702	1	RING
69	5702	1	RING
70	5702	1	RING
71	5702	1	FITTING
72	5708	1	HOSE



MEC 3740-200-25P/33 ②

Figure 33 ② . Control Panel, Front.




MEC 3740-200-25P/34

Figure 34. Spray Manifold, Nozzle Assemblies and Fittings.

INDEX TO PARTS, FIGURE 34

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5704	2,3,4,5	END CAP	8	5708	1	SLEEVE	15	5708	1	TUBE AY
2	5704	2,3,4,5	CLAMP	9	5708	1	TUBE AY	16	5704	2,3,4,5	NOZL AY
3	5704	2,3,4,5	SCREW	10	5704	2,3,4,5	ELBOW	16	5704	6,7	NOZL AY
4	5704	2,3,4,5	NZL HED	11	5704	2,3,4,5	ELBOW	17	5708	1	NIPPLE
5	5708	1	TEE	12	5708	1	CROSS	18	5708	1	LOCKNUT
6	5708	1	BUSHING	13	5708	1	ELBOW	19	5708	1	ELBOW
7	5708	1	CNNCTOR	14	5708	1	TEE				




MEC 6115-300-25P/21

Figure 35. Magneto.

INDEX TO PARTS, FIGURE 35

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0605	3,5,6,7	HOUSING	11	0605	3,5,6,7	BUSHING	21	0605	3,5,6,7	SCREW
2	0605	3,5,6,7	SETSCRW	12	0605	3,5,6,7	NUT	22	0605	3,5,6,7	WCK-HDR
3	0605	3,5,6,7	CLIP	13	0605	3,5,6,7	BEARING	23	0605	3,5,6,7	SCREW
4	0605	3,5,6,7	WASHER	14	0605	3,5,6,7	WASHER	24	0605	3,5,6,7	COVER
5	0605	3,5,6,7	SEAL	15	0605	3,5,6,7	KEY	25	0605	3,5,6,7	WR FBRC
6	0605	3,5,6,7	WASHER	16	0605	3,5,6,7	COIL	26	0605	3,5,6,7	SETSCRW
7	0605	3,5,6,7	CUPLING	17	0605	3,5,6,7	SPRING	27	0605	3,5,6,7	SPRING
8	0605	3,5,6,7	SPRING	18	0605	3,5,6,7	WASHER	28	0605	3,5,6,7	WASHER
9	0605	3,5,6,7	SHELL	19	0605	3,5,6,7	BEARING	29	0605	3,5,6,7	SCREW
10	0605	3,5,6,7	WASHER	20	0605	3,5,6,7	SUPPORT	30	0605	3,5,6,7	ROTOR




EMC 6115-300-35P/23

Figure 36. Magneto Cap, Condenser and Point Set.

INDEX TO PARTS, FIGURE 36

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME	REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	0605	3,5,6,7	SCREW	9	0605	3,5,6,7	CLIP	17	0605	3,5,6,7	SCREW
2	0605	3,5,6,7	WASHER	10	0605	3,5,6,7	SPACER	18	0605	3,5,6,7	SCREW
3	0605	3,5,6,7	GASKET	11	0605	3,5,6,7	SPRING	19	0605	3,5,6,7	WASHER
4	0605	3,5,6,7	GEAR	12	0605	3,5,6,7	PLUNGER	20	0605	3,5,6,7	ARM
5	0605	3,5,6,7	GASKET	13	0605	3,5,6,7	NUT	21	0605	3,5,6,7	SCREW
6	0605	3,5,6,7	OUTLET	14	0605	3,5,6,7	SWITCH	22	0605	3,5,6,7	WASHER
7	0605	3,5,6,7	CAP	15	0605	3,5,6,7	SEAL	23	0605	3,5,6,7	PIN
8	0605	3,5,6,7	SCREW	16	0605	3,5,6,7	CONDNSR	24	0605	3,5,6,7	NUT




MEC 3740-200-25P/37

Figure 37. Air Filter Silencer.

INDEX TO PARTS, FIGURE 37

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5703	5,6,7	BODY
2	5703	5,6,7	ELEMENT
3	5703	5,6,7	TOP AY
4	5703	5,6,7	WASHER
5	5703	5,6,7	BOLT



MEC 3740-200-25P/38

Figure 38. Nozzle Head Assembly.

INDEX TO PARTS, FIGURE 38

REF NO.	FUNCT GROUP	APPL PARTS	ITEM NAME
1	5704	6,7	BODY
2	5704	6,7	GASKET
3	5704	6,7	GASKET
4	5704	6,7	COVER
5	5704	6,7	WASHER
6	5704	6,7	SCREW

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE
AA86ASS1	66289	097
AA86A5S1	66289	076
		087
		092
AA86A5S2	66289	071
		082
A8100B3S1	66289	001
		044
AD41A	66289	047
AF49C	66289	048
AG30	66289	048
AP26	71176	014
		064
AZ5957	82796	078
		089
		094
		099
A13200E5359	81336	023
		027
		031
		034
		075
		080
		086
		091
A13200E5362	81336	023
		075
A13200E5402	81336	012
		015
		061
		067
A13200E5412	81336	015
		066
A13200E5422	81336	011
		061
A13200E5423	81336	011
		060
A13200E5424	81336	011
		011
		060
		061
A13200E5425-1	81336	011
		011
		061
		061
A13200E5427	81336	011
		060
A13200E5431	81336	013
		063
A13200E5434	81336	006
		018
		054
		070
A179X	79575	021
		029
		073
		084
A195	82697	038
		095
A195	82796	025
		026
		033
		037
		041
		042
		078
		080
		089
		093
		098
		100
A195	82976	034
		091
A2492A	82796	026
		034
		037
		041
		079
		090
		095
		100
A2492C	82796	026

NUMBER	CODE	PAGE
		026
		034
		034
		037
		037
		037
		041
		041
		079
		079
		090
		090
		095
		095
		100
		100
A2492D	82796	026
		033
		041
		079
		090
		100
A2568	82696	078
A2568	82796	089
		094
		099
A3-4ATWB	82247	017
		068
A676	11583	022
		026
		030
		034
		037
		041
		074
		079
		085
		090
		095
		100
A7419	61976	004
		050
BA51AS1	66289	043
BB126C4	66289	048
BD103C4	66289	047
BD103C4S1	66289	047
BG209	66289	045
BG224D	66289	045
BG2240S2	66289	045
BP60-3	71176	014
		064
BW8826	00736	038
		095
BW8-80Q	00736	023
		026
		031
		034
		038
		042
		075
		080
		086
		091
		095
		101
BW8-826	00736	023
		026
		031
		034
		042
		075
		080
		086
		091
		095
		100
BW8GS	00736	023
		026
		031
		075
		080
		086
		091
		100
		023
		026
		031
		075
		080
		086

NUMBER	CODE	PAGE
BW8GS825	00736	023
		026
		031
		075
		080
		086
BY4631	82796	079
		089
		094
		099
B1-286S1	66289	004
		051
B13200E45420-2	81336	012
		061
B13200E5347	81336	023
		027
		031
		034
		075
		080
		086
		091
B13200E535	81336	031
B13200E535W	81336	086
B13200E5350	81336	023
		027
		031
		075
		080
		086
B13200E5353	81336	023
		075
B13200E5355	81336	014
		066
B13200E5413	81336	011
		060
B13200E5413-4	81336	011
		060
B13200E5413-5	81336	011
		060
B13200E5413-6	81336	011
		060
B13200E5415	81336	011
		060
B13200E5415-4	81336	011
		060
B13200E5415-5	81336	011
		060
B13200E5415-6	81336	011
		060
B13200E5417	81336	011
		060
B13200E5419	81336	012
		061
B13200E5421	81336	011
		061
B13200E5435	81336	001
		045
B1498B	82796	037
		094
B1498D	82795	041
		100
B1498D	82796	033
		090
B2665K	82796	079
		089
		094
		099
B3967	82796	079
		089
		094
		099
B5969	82796	079
		090
		094
		099
B6030A	82796	078
		089
		094
		099
CA62S1	66289	044
CFA32033	82254	006

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
CFA40004	82254	053			096	CFR41535-5	82254	038
CFA40008	82254	060			101			042
		006	CFA41537	82254	038			096
		053			042	CFR41536	82254	101
CFA40023	82254	017			096			038
		068			101			042
CFA40825	82254	006	CFA41538	82254	038			096
		053			042	CF440974	82254	101
CFA40027	82254	006			096			040
		054			101			097
CFA40030	82254	006	CFB40009	82254	006	CLA3171	82254	016
		053			053			067
CFA40034	82254	007	CFB55020	82254	038	CLS3H0080-0132-3	95875	059
		054			042	CLS3H0080-0132-5	95875	059
CFA40035	82254	007			096	CSA40330	82254	064
		056			101	CW2514	82796	078
CFA40041	82254	010	CFC40010	82254	015			089
		059			067			094
CFA40042	82254	010	CFC40018	82254	004			099
		059			051	C13200E5342	81336	023
CFA40044	82254	006	CFN40566	82254	034			027
		054			038			031
CFA40045	82254	005			042			034
		052			091			075
CFA40615	82254	017			095			080
		068			100			086
CFA40961	82254	027	CFN40998	82254	034			091
		035			038	C13200E5358	81336	023
		038			042			027
		080			091			031
		091			095			034
		096			100			075
CFA40962	82254	101	CFR40031	82254	009			080
		027			058			086
		035	CFR40088	82254	020			091
		038			028	C13200E5363	81336	015
		042			071			066
		081			076	C13200E5428-1	81336	004
		091	CFR40089	82254	001			051
		096			044	C13200E5432	81336	014
		101	CFR40288-5	82254	012			066
CFA40963	82254	027			061	C142-74	79960	003
		035	CFR40419	82254	060			050
		038	CFR40419-1	82254	060	C1498G	82796	025
		042	CFR40420	82254	011			033
		080			060			037
		091			061			041
		096	CFR40421	82254	011			079
		101			060			090
CFA40964	82254	027			060			094
		035			070			100
		038	CFR40422	82254	011	C181-329	79960	003
		042			060			050
		080			060	C21P2	73370	024
		091	CFR40423	82254	060			032
		096	CFR40468	22375	013			040
CFA40970	82254	024			062			076
		032	CFR40469	22375	013			087
		077			062			092
		088	CFR40587	82254	017			097
CFA40971	82254	027			068	C225	95875	010
		035	CFR40744	82254	056			059
		081	CFR40803	82254	007	C2741	82796	078
		091			056			089
CFA40972	82254	024	CFR40829	82254	005			094
		027			018			099
		032			052	C3861	82796	037
		035			070			095
		077	CFR40870	82254	025	C5949	82796	078
		081			033			089
		088			077			094
		091			088			099
CFA40974	82254	024	CFR40975	82254	024	C5963	82796	078
		027			032			089
		032			036			094
		035			076			099
		077			087	C6032B	82796	079
		081			092			094
		088	CFR41535-1	82254	038	C6032B	82796	090
		091			042			099
CFA41100	82254	038			096	DA65	66289	047
		042			101	DA65S1	66289	046

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
D13200D5341-9	81336	017	D13200E5399-38	81336	062	F4721	72850	008
D13200E0109	81336	069			012	F4855	72850	057
		015	D13200E5399-39	81336	061			008
D13200E5341	81336	066			012	F63	66289	057
		023	D13200E5399-40	81336	062	F66	66289	071
		027			012			082
		031	D13200E5399-5	81336	062			076
		034			018	F6745	72850	087
		075	D13200E5399-7	81336	069			092
		080			013			097
		086	D13200E5402	81336	062			008
		091			011			057
D13200E5341-1	81336	017	D13200E5419	81336	060	GAR171A	19728	056
D13200E5341-3	81336	069			018	GAR75A	19728	055
D13200E5341-4	81336	017			070	GA36A1	66289	045
		069	D13200E5420-1	81336	018			047
D13200E5341-7	81336	016			070	GBM128	19728	056
		067	D13200E5430-4	81336	016	GBM21C	19728	056
D13200E5341-8	81336	016			067	GB45C	66289	047
		068	D13200E5430-8	81336	017	GD100A1	66289	052
D13200E5341-8	81336	017			068	GD93C3	66289	025
		069	D13200E5499-16	81336	016			033
D13200E5350	81336	034			067			037
		091	D1498D	82796	025			041
D13200E5353	81336	027			079			079
		034	D200E5399	81336	015			090
		080			067			094
		091	D2735A	82796	078			099
D13200E5370-20	81336	060			089	GEE27	19728	055
D13200E5399-11	81336	018			094	GGU27A	19728	055
		018			099	GGU31B	19728	055
		019	D5949A	82796	078	GGU32	19728	055
		069			089	GGW52	19728	056
		069			094	GG164	19728	056
		070			099	GH46	66289	046
D13200E5399-12	81336	016	EA106C	66289	047	GJC1033A	19728	055
		067	E8844A	19728	008	GJC1034A	19728	055
D13200E5399-13	81336	017			057	GJC2012AS	19728	056
		068	ELV3-0050-3	95875	010	GJC27B	19728	056
D13200E5399-17	81336	018			059	GJC3030FT	19728	054
		069	ESC8071CA445	81347	010	GJC35A	19728	055
D13200E5399-19	81336	016			059	GJC38A	19728	056
		016	E2493	82796	026	GJC39A	19728	055
		019			034	GJC42A	19728	056
		067			037	GJC46	19728	055
		067			079	GJC49B	19728	055
		070			090	GJP10050	19728	055
D13200E5399-2	81336	013			095	GJP1007A	19728	055
		063	E2493	82976	041	GJP1008B	19728	055
D13200E5399-20	81336	016			100	GJP102A	19728	055
		016	E2513A	82796	078	GJP1102A	19728	055
		019			089	GJP2001D	19728	055
		067			094	GJP2044A	19728	056
		067			099	GJP7404AT	19728	007
		070	E2565	82796	078			054
D13200E5399-23	81336	013			089	GK38D	19728	055
		018			094	GR32B	19728	056
		063			099	GY20C	19728	055
		069	F2572	82796	078	G2788	82796	079
D13200E5399-24	81326	018			089			090
		070			094			094
D13200E5399-24	81336	013			099			099
		063	F3P	73370	020	G3861	82796	026
D13200E5399-25	81336	018			028			033
		069			071			041
D13200E5399-26	81336	018			082			079
		069	F4373	82796	026			090
D13200E5399-27	81336	018			033			100
		069			037	G427585	82254	034
D13200E5399-29	81336	016			041			038
		067			079			042
D13200E5399-31	81336	016			090			091
		068			095			095
D13200E5399-32	81336	016			100			100
		068	F4610	72850	008	HF261	66289	045
D13200E5399-34	81336	012			057	HG227D	66289	047
		062	F4616	72850	008			071
D13200E5399-35	81336	012			057			076
		061	F4618	72850	008			082
D13200E5399-36	81336	012			057			087
		062	F4619	72850	008			092
D13200E5399-37	81336	012			057			097

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
HU2425	82796	078	MS13996-2	96906	046	MS35690-602	96906	096
HU2425	97296	098			046			009
HU2452	82796	089			046			013
IT12	77060	093	MS13997-1	96906	048			059
JK50	66289	009	MS13998-1	96906	047			063
		058	MS13999-2	96906	048	MS35691-405	96906	007
		005	MS35000-1	96906	009			010
		044			058			056
		053	MS35242-77	96906	013			059
JK52	66289	052			063	MS35903-1	96906	046
JK55	66289	053	MS35291-115	96906	071	MS35903-2	96906	046
JX2514C	82796	078			076	MS35903-3	96906	046
		089			082	MU54F	19728	008
		094			087			057
		099			092	MZ1024AD	19728	007
KA6381	66289	048			097			057
KA6381S1	66289	048	MS35291-13	96906	014	MZ1034CS	19728	008
KF23-1	66289	049			066			057
KF24	66289	049	MS35291-3	96906	015	MZ12D	19728	008
KF25	66289	048			015			057
KF28	66289	048			025	MZ1360A	19728	008
KF30	66289	048			033			057
KIT19728-36	19728	008			060	MZ19C	19728	008
		057			066			057
KIT19728-37	81336	056			067	MZ2002G	19728	008
LC266A	66289	003			077			057
		049			088	MZ2012ES	19728	008
LD242	66289	003	MS35291-31	96906	064			057
LJ310	66289	049	MS35291-32	96906	007	MZ2366T	19728	007
		002			054			056
		048	MS35291-36	96906	007	MZ357	19728	008
LK11	66289	004			054			057
		051	MS35291-4	96906	039	MZ358A	19728	008
LL125	66289	004			096			057
		018	MS35291-60	96906	015	MZ359A	19728	008
		051			066			057
		070	MS35291-66	96906	013	MZ364	19728	008
LP42C	66289	003			063			057
		050	MS35333-20	81336	013	MZ365	19728	008
LP43	66289	025			063			057
		033	MS35333-20	96906	024	MZ528	19728	008
		036			027			057
		040			032	M1077	82796	078
		077			035			089
		088			077			093
		093			081			098
		098			088	M2570	82796	078
LO-83	66289	003			091			089
		050	MS35333-21	96906	031			094
LO84C	66289	002			086			099
		048	MS35333-22	96906	013	M42XA	79575	021
L63L	66289	003			063			029
		050	MS35333-23	96906	007			073
MAD110	19728	008			010			084
		057			039	NC145G4S1	66289	046
MBG2042AS	19728	008			056	NY2430A	82796	078
		057			060			089
MBG402AT	19728	007			096			098
		056	MS35333-25	96906	038	NY2430A	82797	093
MDF25	19728	055			042	N10S10D	82796	033
MD292-4	66289	001			096			090
		046			101	N2498	82796	025
ME130	66289	045	MS35333-4	96906	025			033
ME38	66289	048			077			037
		048	MS35333-40	96906	033			041
ME71	66289	044			088			079
MN218	19728	055	MS35333-42	96906	009			090
		055			013			095
MS135690-405	96906	014			015			100
		066			059	PA291	66289	047
MS13931-4	96906	046			063	PA332	66289	001
MS13931-5	96906	046			066			044
MS13931-6	96906	046	MS35338-25	96906	060	PA333	66289	001
MS13932-4	96906	046	MS35650-102	96906	013			045
MS13932-5	96906	046			063	PA340	66289	052
MS13932-6	96906	046	MS35690-405	96906	015	PB148	66289	047
MS13933-4	96906	046			025	PB169A	66289	071
MS13933-5	96906	046			033			082
MS13933-6	96906	046			039	PC110	66289	003
MS13962-1	96906	046			066			050
MS13963-1	96906	047			077			071
MS13995-1	96906	046			088			076

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		087			074			090
		092			079			095
PC337	66289	097			085			100
PC447	66289	044			090	QB75	66289	002
		004			094			003
		051			099			043
PDC21-2P	23838-	031	PE80A	66289	015			049
		086			015			049
PD10	66289	047			023	QC58A	66289	003
PD11	66289	045			031			043
PD12	66289	044			066			050
PD147	66289	004			066	QD487A	66289	043
		051			075			045
PD153-2	66289	009			086	QD487B	66289	043
		058	PF101	66289	048			045
PD173A	66289	005	PF18	66289	001	QD612A	66289	002
		052			005			043
PD181	66289	047			044			047
PD78	66289	044			053	QD613C	66289	043
PE3	66289	003	PF25	66289	002			043
		007			047	QD616	66289	022
		044	PF52	66289	047			025
		048	PG314	66289	021			029
		049			029			037
		050			072			041
		054			083			043
PE34A	66289	083	PG488	66289	004			073
		007			051			079
		009	PG516A	66289	007			084
		010			056			090
		056	PG559	66289	026			094
		058			034			099
		059			037	QD617	66289	043
PE4	66289	003			041			043
		004			079	QD638A	66289	043
		020			090			052
		024			095	QD660	66289	043
		028			100			047
		032	PH14	66289	002	QD661A	66289	043
		036			048			047
		040	PH299	66289	045	QD662-14	66289	043
		050			047			049
		051	PH313A	66289	053	QD663A	66289	043
		072	PH356	66289	002			049
		072			049	QD667	66289	004
		077	PH387	66289	049			043
		078	PH403A3	66289	001			051
		083			044	QD669	66289	002
		088	PH452	66289	047			049
		088	PH77	66289	005	QD670	66289	003
		093			052			043
		093	PH77A	66289	001			044
		098			044			050
		098	PK121	66289	005	QD715	66289	002
PE45A	66289	009			052			043
		058	PK50A	66289	049			048
PE46	66289	044	PL53	66289	045	QD728	66289	004
		048	PL83	66289	045			051
PE49	66289	045	PM108	66289	048	QF81	66289	045
PE56A	66289	022	PM111-1	66289	005	QF81A	66289	045
		025			052	QT2477C	82796	078
		030	PM163A	66289	001			089
		033			044			093
		037	PM165-1	66289	048			098
		041	PM58	66289	049	QW5149	87373	027
		074	PM75A	66289	005			080
		079			053	QW5155	87373	027
		085	PS1330A	19728	008			080
		090			057	QX2433	82796	025
		094			055			033
PE59	66289	099	PU2178	19728	056			037
		001	PU218A	19728	056			041
		045	PU238A	19728	056			079
PE6	66289	044	PL-1-1-8	71176	014			090
PE72	66289	009			065			095
		058	P1-115E	66289	005			100
PE76A	66289	022			052	Q21A	66289	001
		025	P19-16	71176	064			043
		030	P2473	82796	025	Q2437A	82796	025
		033			033			033
		037			037			037
		041			041			041
					079			

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		079	SA10	66289	044	T56-23	79960	050
		090	SA26	66289	047	T56-24	79960	050
		094	SA52	66289	044	T56-48	79960	050
		099			053	T56-70	79960	050
RB86	66289	002	SA68	66289	002	T96DS1	66289	005
		048			047			052
RC109S1	66289	004	SA74	66289	009	UC75F	66289	001
		051			058			045
RD107A	66289	049	SA93	66289	048	UC75FS1	66289	001
RF1196	66289	044	SD108	66289	012			045
RF1199	66289	044			062	VB04201ET	19728	007
RF1301	66289	020	SD153	66289	023			056
		024			030	VB134C	66289	005
		028			074			052
		032	SD197A	66289	085	VB166	66289	052
		036			023	VE527W	66289	005
		040			031			052
		072			074	VE5428	66289	005
		077			085			052
		083	SD197B	66289	026	VE555B	66298	006
		088			034			053
		093			038	VE566D1	66289	009
		098			042			058
RF269	66289	004			080	VE693	66289	005
		020			090			053
		024			095	WD41C	66289	006
		028			100			054
		032	SD252	66289	026	WE2931S1	66289	048
		036			034	WE302ES1	66289	004
		040			038			051
		043			042	WY2563	82796	078
		051			080			089
		071			090			094
		076			095			099
		082			100	XA33	66289	007
		087	SD43	66289	045			022
		092	SE135AH	66289	077			026
		097			088			030
RF270	66289	004			093			034
		051			098			037
RF270-4	66289	048	SE135Y	66289	072			041
		052			083			054
RF794	66289	004	SE136D	66289	007			074
		051			054			079
RJ152S1	66289	048	SE137D7	66289	006			085
RK170	66289	045			054			090
RK178	66289	048	SE138	66289	006			095
RM1122	66289	004			054			100
		051	SE32	66289	006	XA34	66289	006
RM1299	66289	020			054			054
		028	SK72	82796	025	XA36	66289	007
		072			033			054
		083			037	XA67	66289	012
RM1319G	66289	002			041			062
		024			079	XA832	19728	008
		032			090			057
		036			094	XA928	19728	055
		049			099	XA929	19728	055
		077	SL23	77060	009	XC17	66289	045
		088			058	XD1	66289	047
		093	STYLEFX1-3-4	04959	018	XD113	66289	049
RM1319G	77278	040			069	XD13	66289	072
		098	SW634D	19728	055			077
RM796	66289	020	TA126	66289	005			083
		028			044			088
		072			053			093
		083	TC322SD1	66289	052			098
RSMS13959-2	81336	046	TC328D	66289	052	XD17	66289	001
RSMS13959-3	81336	046	TC368A	66289	005			001
RSMS35903-1	81336	046			052			014
RV28	66289	024	TC388-3S1	66289	047			014
		032			053			044
		036			052			046
		040	TC389-1	66289	052			064
		076	TC391B	66289	053			064
		087	TC422B	66289	052	XD19	66289	001
		092	TC427B	66289	002			043
		097			047			047
R123	66289	002	TC428G	66289	053	XD21	66289	001
		048	TE5	66289	008			002
R16-16	01510	014			057			043
		064	TT66	66289	005			047
					052			

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
XD27	66289	049			029	Z2474	82797	053
XD4	66289	048			073	OW352	78470	033
XD5	66289	049			084			088
XED16	11583	022	X8551	79575	022	OW352	78480	025
		030			030			036
		074			074			040
		085			085			077
XE17	66289	046	X8555	79575	022			093
XE61	66289	005			030			098
		052			073	OW447	78480	025
XHS2484	79575	021	X8598	79575	084			036
		029			022			040
		072			030			077
		083			073			093
XH1	66289	053			084			098
XK1	66289	003	X8774	79575	021	OW447	78489	033
		050			029			088
XK7A	66289	002			073	OW480T	78480	020
		049			084			028
XMD18	11583	026	YC10C	66289	009			072
		034			058			083
		041	YC66S9	66289	008	06096	78480	025
		079			058			033
		090	YC9F	66289	009			036
		095			058			041
		100	YD209	66289	009			077
XS2480	82796	078			058			088
		089	YD212D	66289	021			093
		093			029			098
		098			072	06137	78480	025
X1-1	66289	005			083			033
		052	YD215	66289	009			036
X1-7	66289	005			058			040
		052	YD300-23	66289	026			077
X180	19728	008			037			088
		057			041			093
X260	19728	056			079			098
X261	19728	008			095	07759	78480	020
		057			100			028
X2882	19728	008	YD30023	66289	034			072
		057			090			083
X295	19728	054	YD69-3	66289	009	07762	78480	021
X3279A	19728	055			058			028
X4898	19728	056	YE2	66289	009			072
X5524	79575	021			058			083
		029	YL177A	66289	009	07766	78480	020
		073			058			028
		084	YL226A	66289	009			072
X6586	79575	021			058			083
		029	YL292	66289	007	07769	78480	021
		073			056			025
		084	Y7569	79575	022			029
X7672	79575	021			030			033
		029			073			036
		073			084			041
		083	Y93DS1	66289	025			077
X7720	79575	022			033			083
		030			037			088
		074			041			093
		085			078			098
X7724	79575	021			089	07770	78480	020
		029			093			025
		073			098			028
		084	ZV2563C	72987	094			033
X7867	79575	021	ZV2563C	82796	078			036
		029			089			040
		073			099			072
		084	ZW5139	87373	035			077
X7872	79575	022			038			083
		030			042			088
		073			091			093
		084			096			098
X7892	79575	021	ZW5155	87373	101	08227	78480	021
		029			035			029
		073			038			072
		084			042			083
X7895	79575	021			091	17852	71176	014
		029			096			064
		073			101	1XA256	79575	022
		084	Z2474	82796	078			030
X7910	79575	021			089			074
					098			085

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
10-4009-409	01510	014			082	11705	01510	065
		064			087	11707	01510	066
10A2235	22375	012			092	11739	01510	065
		062			097	11772R	01510	065
10M06	00736	023	102483	73370	020	11778	01510	066
		026			024	12X1014	19728	008
		031			028			057
		075			032	12X195	19728	055
		080			036	12X196	19728	055
		086			040	12X199	19728	055
10S10D	82796	025			071			055
		037			076	12X864	19728	056
		041			082	1215-12	85274	013
		079			087			062
		095			092	1215-12WM1	85274	013
		100			097			062
10076	73370	020	10407	66289	022	1215-12WM2	85274	013
		024			030			063
		028			074	1215-12WM3	85274	013
		032			085			063
		036	10611	73370	020	1215-12WM5	85274	013
		040			028			063
		071			072	1215-12WM6	85274	013
		076			083			062
		082	10757	73370	020	1216-13WM4	85274	013
		087			028			062
		092			072	12398	73370	020
		097			083			024
101A710	22375	013	10776	73370	020			028
		062			024			032
101A714	22375	013			028			036
		062			032			040
101A923	22375	013			036			072
		062			040			077
101A926	22375	013			071			083
		062			076			088
10124	73370	020			082			093
		024			087			098
		028			092	13200E5436	97403	002
		032			097			049
		036	10991	01510	066	13446	73370	020
		040	1118	30327	016			024
		072			068			028
		077	1110X4	79470	004			032
		083			020			036
		088			028			040
		093			051			072
		098			072			077
1015-298-8702		007			083			082
		056	11140	01510	065			087
102032	73370	020	11150	01510	055			093
		024	1120	01510	011			098
		028			014	137	95875	010
		032			062			059
		036			065	15-186	79575	021
		040	11248	01510	064			029
		071	11249	01510	064			073
		076	11255	01510	065			084
		082	11322	01510	065	1650-663-4816		002
		087	11429R	01510	065			043
		092	11443	01510	065			047
		097			066	17688		

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		029	2805-374-9746		047	2910-282-7557		021
		073	2805-388-6660		046			029
		084	2805-388-6661		046			072
213-1-179	09058	063	2805-517-9809		046			083
213-1-187	09058	063	2805-517-9810		046	2910-305-5749		020
213-1-401-99	09058	063	2805-526-8753		076			025
213-1-782	09058	063	2805-527-7732		043			028
213-1-783	09058	014			052			033
		064	2805-528-5799		046			036
213-1-786	09058	014	2805-528-6097		048			040
		064	2805-528-6396		048			072
213-1-903-99	09058	063	2805-529-8379		046			077
213-10-202	09058	063	2805-536-8753		092			083
213-10-204	09058	064			097			088
213-10-205-1	09058	063	2805-536-8776		049			093
213-10-206-1	09058	064	2805-536-8835		005			098
213-10-213-1	09058	064			052	2910-347-5613		001
213-10-214-1	09058	064	2805-536-9753		087			044
213-10-215	09058	064	2805-554-1005		046	2910-354-3834		025
213-10-216	09058	064			046			033
213-10-280	09058	064			046			036
227	95875	010	2805-554-9029		047			040
		059	2805-560-9300		002			077
228	95875	010			048			088
		059	2805-571-1100		046			093
2288	79575	021	2805-608-4998		046			098
		029	2805-627-3467		047	2910-358-4317		020
		073	2805-641-7404		019			028
		084			063			072
23A9S	23838	039			070			083
		096	2805-652-9757		047	2910-358-4787		003
2300X6	04255	026	2805-685-6019		023			043
		080			030			050
2510-039-7699		022			074	2910-358-5327		021
		030			085			028
		073	2805-695-2179		045			072
		084	2805-695-2180		045			083
26822A	60038	045	2805-695-2181		044	2910-368-6657		021
26881	60038	045	2805-695-2183		048			025
269P	30327	004	2805-695-2186		048			029
		005	2805-708-9194		002			033
		016			048			036
		016	2805-708-9195		002			041
		016			047			072
		051	2805-715-0424		046			077
		052	2805-715-5326		045			083
		067	2805-715-5327		045			088
		068	2805-718-6972		001			093
		068			044			098
2805-309-8040		047	2805-720-4773		001	2910-382-8768		025
		071			043			033
		076	2805-730-6327		048			036
		082	2805-739-9927		047			040
		087	2805-741-0242		049			077
		092	2805-741-0243		049			088
		097	2805-741-0380		048			093
2805-339-5589		048	2805-767-9386		046			098
2805-339-5595		046	2805-776-8016		043	2910-580-0607		004
2805-339-5598		071			047			051
		082	2805-776-8017		043	2910-715-5328		003
2805-353-5889		003			047			050
		049	2805-776-8078		044	2910-776-7900		003
2805-360-8332		043	2805-776-8111		003			043
		043			049			044
2805-360-8334		002	2805-776-8114		048			050
		047	2805-776-8115		043	2910-776-7902		003
2805-360-8345		045			049			050
2805-366-6218		043	2805-839-5275		046	2910-776-7903		005
		043	2805-839-5276		046			044
2805-366-6231		045	2805-919-3602		002			053
2805-366-6238		045			043	2910-807-7153		003
2805-366-6240		045			048			050
2805-366-6248		048	2910-142-2738		025	2910-816-4057		004
2805-366-6249		048			033			051
2805-366-6270		002			036	2920-035-8025		008
		003			040			057
		043			077	2920-142-1888		025
		049			088			033
2805-366-9740		043			093			037
		045	2910-217-3489		098			041
2805-374-9710		047			037			079
					095			090

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		094	2920-367-7985		021			074
		099			029			085
2920-143-5298		008			073	2920-740-2845		021
		057			084			029
2920-182-8527		008	2920-367-7999		021			073
		057			029			084
2920-217-3489		025			073	2920-740-2846		021
		033			084			029
		041	2920-368-6715		021			073
		079			029			084
		090			073	2920-740-2852		022
		100			084			030
2920-286-2712		078	2920-374-3481		021			074
		089			029			085
		094			073	2920-740-2873		022
		099			083			030
2920-293-5212		022	2920-428-3830		022			073
		030			030			084
		074			074	2920-740-2882		022
		085			085			030
2920-294-4115		008	2920-428-7572		078			074
		057			089			085
2920-335-4178		021			094	2920-778-6315		056
		029			099	2920-785-6393		007
		073	2920-428-7583		078			056
		084			089	2920-787-0480		021
2920-353-6610		022			094			029
		030			099			073
		074	2920-444-8605		009			084
		085			058	2920-800-8156		021
2920-353-6611		021	2920-447-9295		012			029
		029			062			072
		073	2920-505-5108		007			083
		084			056	2920-831-1171		078
2920-353-6614		022	2920-537-1330		079			089
		030			089			094
		074			094			099
		085			099	2920-841-1890		026
2920-353-6618		022	2920-547-4335		008			034
		030			057			037
		074	2920-555-6315		007			041
		085			056			079
2920-353-7422		007	2920-566-7806		021			090
		057			029			095
2920-353-7425		008			072			100
		057			083	2920-843-6741		056
2920-354-0750		079	2920-598-9432		021	2920-844-2035		025
		090			029			033
		094			073			037
		099			084			041
2920-354-0766		079	2920-602-4258		078			079
		089			089			090
		094			094			094
		099			099			099
2920-356-1221		026	2920-604-7773		008	2920-861-1320		007
		033			057			054
		037	2920-604-7774		008	2920-876-8346		009
		041			057			058
		079	2920-604-7776		008	2920-887-1289		026
		090			057			034
		095	2920-607-1324		021			037
		100			029			041
2920-360-8381		022			073			079
		025			084			090
		029	2920-626-8302		009			095
		037			058			100
		041	2920-627-0946		010	2920-962-4598		010
		043			059			059
		073	2920-654-3703		010	2920-971-1451		009
		079			059			058
		084	2920-662-9133		022	2920-979-3504		025
		090			030			033
		094			074			037
		099			085			041
2920-366-6269		029	2920-662-9135		021			078
		084			029			089
2920-366-6296		021			073			093
		073			084			098
2920-366-6306		021	2920-710-6107		008	2920-986-9691		010
		029			057			010
		073	2920-712-1267		022			010
		084			030			059

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		059	2990-603-4773		025			034
		059			033			038
2930-353-6609		021			037			042
		029			041			080
		072			079			091
		083			090			095
2940-141-9025		024			094			100
		032	2990-603-4775		099	3440-977-8672		023
		036			047			031
		040			053			075
		076	2990-657-4467		053			086
		087	2990-677-1771		052	3629	95875	010
		092	2990-732-1179		005			059
		097			052	3640064	22375	012
2940-358-2436		040	2990-739-9930		005			062
		097			053	3740-542-3716		023
2940-358-2536		024	2990-776-8106		006			026
		032			054			031
		036	2995-197-5863		005			075
		040			052			080
		076	3K1	82796	089			086
		087			094	3740-542-3717		014
		092			099			065
		097	3K1	92697	078	3740-971-1418		012
2940-366-9747		004	3T860	71176	014			061
		050			032	3740-971-1419		013
2940-374-3084		004			036			063
		051			040	3750-678-6664		005
2940-393-5988		024			066			052
		032			087	376C032	22375	013
		036			092			062
		040			097	39SYZ20	00736	023
		076	3010A	95875	010			026
		087			059			031
		092	3020-877-1194		014			075
		097			066			080
2940-529-2738		020	3030-246-0152		014	3910	82247	086
		028			064			017
		071	3030-528-4261		007			068
		082			054	4L250	71956	007
2940-542-3807		002	3030-542-3702		014			054
		024			064	40325	01510	065
		032	304A193	22375	013	40357	01510	066
		036			062	414	60038	044
		040	315S128	82796	078	420	60038	044
		049			089	4710	79575	022
		077			094			030
		088			099			074
		093	3110-100-0802		044			085
		098	3110-100-3552		045	4263	93146	017
2940-593-2293		049	3110-100-3904		044			068
2940-606-6816		020	3110-100-6180		048	429-66	09058	064
		028			048	4296	93146	017
		072	3110-144-8505		054			068
		083	3110-144-8882		021	4320-167-8216		014
2940-695-8797		003			029			064
		050			073	4320-918-9988		063
2940-732-4214		024			084	4320-972-8724		064
		032	3110-144-8988		094	4510-919-3101		002
		036	3110-144-8998		078			048
		040			089	4537A3-44TW	82247	017
		077			099			068
		088	3110-293-8819		045	454	95875	010
		093	3110-554-3559		044			059
		098	3120-774-4607		056	4649	93146	017
2940-774-4747		004	3150X2	70470	004			068
		043			051	4652-2	82247	017
297	95875	010	3200X6	04255	034			068
		059			038	466-3989	09058	014
2990-085-9035		005			042			063
		018			091			064
		052			095	4710-162-0991		006
		070	3219	79575	100			018
2990-141-9229		006			022			054
		054			030			070
2990-294-6749		005			074	4710-277-5525		004
		053	322A035	22375	085			005
		052			012			018
2990-366-6277		005			062			020
2990-374-3163		052	3400X2	04255	002			028
		052			048			051
2990-464-3619		052	3400X6	04255	026			052

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		070	4730-277-5575		004			051
		072			051	4730-692-8775		048
		083	4730-277-7051		016			052
4710-277-5526		017			067	4730-814-4132		004
		018	4730-277-7899		016			005
		069			016			016
		070			067			016
4710-809-8149		013			067			016
		013	4730-278-2538		016			051
		018			067			052
		018	4730-278-3358		006			067
		063			054			068
		063	4730-278-3395		002			068
		069			047	4820-845-1096		016
		070	4730-278-4034		017			067
4710-872-1781		004			068	49X4	79470	002
		051	4730-278-4323		004			048
4720-218-5644		004			020	4920-428-3751		021
		018			024			029
		051			028			073
		070			032			084
4720-289-4869		018			036	4971	23838	039
		070			040			096
4730-011-6452		004			043	49712	23838	031
		020			051			086
		028			071	5241	73370	024
		051			076			032
		072			082			036
		083			087			040
4730-011-8831		004			092			076
		051			097			087
4730-014-4574		016	4730-278-6337		002			092
		016			049			097
		016	4730-278-8365		017	5250	79575	022
		068			069			023
		068	4730-278-8829		017			026
		068			069			030
4730-014-4575		017	4730-287-1614		016			031
		068			067			034
4730-044-4688		014	4730-287-3281		003			038
		063			050			042
		065	4730-289-0147		016			074
4730-044-4693		017			067			074
		068	4730-289-0587		016			080
4730-044-4698		014			067			085
		065	4730-289-4869		016			085
4730-044-4704		013			068			091
		062	4730-293-3593		017			095
4730-044-5686		014			068			100
		065	4730-390-0138		016	5305-010-0749		078
4730-068-9388		002			068			089
		048	4730-585-2359		001			093
4730-084-0469		013			005			099
		063			044	5305-010-0959		031
4730-187-4200		003			053			062
		050	4730-603-4470		020			086
4730-188-1854		017			024	5305-011-3975		017
		068			028			068
4730-194-0219		015			032	5305-012-0687		010
		067			036			059
4730-196-1974		017			040	5305-012-0697		011
		068			072			061
4730-200-0273		017			077	5305-012-1832		078
		069			083			089
4730-202-6694		015			088			094
		067			093			099
4730-202-7760		004			096	5305-012-2159		005
		051	4730-639-9638		020			052
4730-221-3928		006			025			055
		054			028	5305-012-2181		013
4730-230-1924		034			033			063
		042			036	5305-013-1238		026
		091			040			030
4730-230-1996		100			072			034
		017			077			037
		017			083			041
		068			088			079
		068			093			085
4730-249-3882		016			098			090
		067	4730-640-5832		002			095
4730-277-5553		016			004			100
		067			048	5305-013-1899		010

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		059			099	5305-627-4028		015
5305-013-2768		014	5305-206-6244		056			067
		064	5305-269-2804		008	5305-637-4028		015
5305-013-3080		028			057			025
		083	5305-269-3217		022			033
5305-013-3083		020			074			066
		024	5305-272-4103		055			077
		032	5305-276-7951		009			088
		036			017	5305-637-4034		014
		040			021			066
		072			029	5305-638-6834		022
		077			058			030
		086			068			074
		093			073			085
		098			084	5305-638-9082		015
5305-013-3098		065	5305-276-7956		008			066
5305-013-3648		013			057	5305-639-6026		022
		063	5305-276-8264		008			030
5305-017-9117		046			057			074
5305-018-1629		065	5305-281-6387		025			085
5305-022-5561		022			033	5305-639-8115		011
		030			037			015
		074			041			061
		085			079			066
5305-042-0450		078			090	5305-639-8118		015
		089			095			015
		093			100			066
		098	5305-281-8308		022			066
5305-042-0699		065			030	5305-958-5252		045
5305-043-6667		013			073	5305-959-4159		009
		063			084			058
5305-044-3507		007	5305-335-4180		022	5305-988-1170		004
		010			023			051
		056			026	5305-988-1721		007
		059			030			054
5305-049-9608		001			031	5305-988-1723		006
		043			034			054
		047			038	5305-988-1725		007
5305-055-6313		064			042			007
5305-055-6314		063			074			010
5305-068-0500		006			074			054
		048			080			056
		053			085			059
		060			085	5305-988-1726		007
5305-068-0502		003			091			054
		004			095	5306-012-6078		006
		005			100			053
		006	5305-353-7448		008	5306-018-0078		003
		008			057			050
		009	5305-407-9163		005	5306-019-3988		072
		011			052			077
		044	5305-424-2999		022			083
		050			030			088
		051			074			093
		053			085			098
		054	5305-428-4750		008	5306-021-5377		001
		057			057			043
		058	5305-514-9662		025	5306-021-7004		064
		060			030	5306-038-4416		071
5305-068-0510		012			033			082
		049			037	5306-206-9166		002
		061			041			047
5305-071-2237		005			079	5306-207-9166		001
		053			085			043
5305-206-0169		078			090	5306-207-9782		014
		089			094			014
		094			099			064
		099	5305-527-4195		071			064
5305-206-1071		001			076	5306-270-9734		049
		001			082	5306-286-1491		008
		007			087			057
		044			092	5306-514-8458		047
		046	5305-543-2218		097	5306-531-1798		004
		047	5305-543-2271		094			051
		054	5305-543-2281		065	5306-543-4308		020
5305-206-8263		008			078			024
		018			089			028
		057			099			032
		069	5305-550-1310		015			036
		078			066			040
		089	5305-584-8736		022			047
		094			074			071

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		076			030			073
		082			073			084
		087			084	5310-188-4185		022
		092	5310-012-0622		009			030
		097			058			074
5306-576-0537		064	5310-012-1744		022			085
5306-639-8060		064			030	5310-205-7981		026
5306-680-6004		007			074			026
		054			085			034
5307-011-2572		003	5310-012-1949		044			034
		050	5310-012-6189		003			037
		071			049			037
		076	5310-013-4556		044			041
		082	5310-013-5830		021			041
		087			029			079
		092			073			079
		097			084			090
5307-025-7993		004	5310-013-8526		010			090
		051			060			095
5307-207-7376		045	5310-013-8530		014			095
5307-207-7377		044			055			100
5310	73370	024			065			100
		032	5310-013-8542		015	5310-208-6994		008
		036			015			057
		040			023	5310-209-4975		055
		076			024	5310-221-3129		002
		087			026			048
		092			026	5310-227-6566		034
		097			028			038
5310-010-3129		023			030			042
		026			031			091
		031			032			095
		075			034			101
		080			036	5310-261-7340		045
		086			037			049
5310-010-7823		006			040	5310-261-7341		003
		053			041			007
5310-011-3102		013			055			044
		063			055			048
5310-011-5544		025			060			049
		033			066			050
		077			066			054
		088			075	5310-265-9214		047
5310-011-5547		015			077	5310-275-1353		022
		066			079			030
5310-011-5551		071			080			074
		076			083			085
		082			085	5310-276-2821		053
		087			086	5310-282-0483		008
		092			088			057
		097			090	5310-285-1591		026
5310-012-0214		001			093			034
		046			095			037
		048			098			041
5310-012-0279		065			100			079
5310-012-0361		013	5310-017-8620		028			090
		018			082			095
		063			056			100
		069	5310-030-2007		008	5310-316-8887		062
		009	5310-043-2226		056	5310-333-6117		010
		013			057			059
		015	5310-045-1005		006	5310-336-7158		089
		015			053			094
		022			056			099
		025	5310-176-8160		020	5310-351-0698		022
		030			024			030
		033			028			074
		037			032			085
		041			036	5310-353-5895		005
		059			040			052
		063			072	5310-353-6620		021
		066			077			029
		066			083			073
		074			088			084
		079			093	5310-358-7423		056
		085			098	5310-366-6163		004
		090	5310-186-7410		079			051
		094			090	5310-366-6294		005
		099			094			023
5310-012-0611		008			099			026
		057	5310-187-3458		021			031
5310-012-0614		022			029			052

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
		075			025			056
		080			033			058
		086			051			059
5310-366-7158		078			053	5310-692-8335		001
5310-368-1908		020			058			045
		024			060	5310-701-6068		008
		028			061			057
		032			066	5310-776-8112		002
		036			066			049
		040			077	5310-794-8554		078
		072			088			089
		077	5310-584-8731		045			094
		082	5310-595-5599		006			099
		087			054	5310-794-8555		026
		093	5310-595-7235		013			033
		098			024			037
5310-368-1911		020			027			041
		072			032			079
5310-417-8620		020			035			090
		024			063			095
		032			077			100
		036			081	5310-800-5282		007
		040			088			010
		071			091			056
		076	5310-595-7237		009			059
		087			013	5310-826-3773		009
		092			015			058
		097			025	5315-011-2726		025
5310-428-2137		009			030			033
		058			033			037
5310-514-7091		047			037			041
5310-514-8416		008			041			079
		057			059			090
5310-527-3288		010			063			094
		013			066			099
		060			079	5315-012-1224		005
		063			085			052
5310-527-3289		005			090	5315-012-4546		008
		006			094			057
		007			099	5315-014-1242		065
		010	5310-596-4908		045	5315-014-1244		065
		011	5310-596-4911		003	5315-050-5654		064
		012			004	5315-050-5753		065
		015			020	5315-141-1651		052
		052			024	5315-221-6005		053
		054			028	5315-248-0003		055
		056			032			055
		060			036	5315-251-9984		047
		060			040	5315-271-3012		001
		061			050			045
		067			051	5315-272-6827		005
5310-530-9636		049			072			052
5310-543-2705		004			072	5315-276-5762		001
		005			077			045
		007			078	5315-366-6242		047
		022			083	5315-366-6291		005
		051			083			052
		053			088	5315-367-7994		022
		054			088			030
		074			093			074
5310-582-6520		056			093			085
5310-582-9926		044			098	5315-615-1699		099
		048			098	5315-616-5523		045
5310-582-9930		022	5310-596-6696		044	5315-616-5526		056
		025	5310-616-6949		031	5315-619-7342		045
		030			061	5315-663-1215		052
		033			086	5315-715-1699		078
		037	5310-627-6128		022			089
		041			074			094
		074	5310-637-2400		001	5315-753-3893		001
		079			044			044
		085	5310-637-9541		003	5315-828-8190		006
		090			050			053
		094			066	5315-839-2325		005
		099			066			052
5310-584-5005		004	5310-639-8061		007	5315-952-3107		001
		006			056			045
		009	5310-641-9308		001	5319-596-4745		008
		011			045			057
		012	5310-655-6314		007	5320-117-7106		012
		014			009			015
		015			010			062

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
5320-118-1759		067	5330-362-1562		017	5340-598-3180		025
		011			069			033
		012	5330-505-6611		011			037
		060			012			041
		060			018			079
5325-281-3993		061			061			090
		011			061			094
		060			070			100
5325-539-7143		061	5330-508-1111		008	5340-664-9187		008
		009			057			057
5330-056-9588		358	5330-542-1420		005	5340-675-5253		025
		020			044			033
		024			053			037
		028	5330-559-6862		008			041
		032			057			079
		036	5330-582-4084		004			090
		040			051			094
		071	5330-599-1285		024			100
		076			032	5340-740-2871		021
		082			036			029
		087			040			073
		092			076			084
		097			087	5340-741-0246		048
5330-143-5192		056			092	5340-776-9921		056
5330-187-2962		025			097	540-16	00736	023
		033	5330-599-5356		022			023
		036			026			026
		041			030			031
		077			034			075
		088			037			075
		093			041			080
		098			074			086
5330-187-3635		053			079	5411	79575	022
5330-191-1096		023			085			030
		023			090			073
		026			095			084
		027			100			022
		031	5330-640-9612		052	5516	79575	030
		031	5330-641-2087		045			074
		075			047			085
		075	5330-684-7734		049			021
		080	5330-729-5106		050	5518	79575	029
		081	5330-793-1057		014			072
		086			064			083
		086	5330-793-1058		064			021
5330-262-3306		022	5330-806-7624		013	5519	79575	029
		030			062			073
		074	5330-925-0455		038			084
		085			042	5520	79575	022
5330-270-8469		002			096			030
		018			101			074
		049	5330-956-4306		042			085
		070			101	5567	79575	021
5330-291-3405		020	5330-956-4307		038			029
		028			096			073
		072	5335-830-9983		079			084
		083			090			022
5330-291-5921		008			094	5610	79575	030
		057			099			074
5330-291-9873		050	5340-050-1591		047			085
5330-292-0320		004	5340-147-3745		049	5622	79575	022
		050	5340-232-5723		044			030
5330-292-1503		043	5340-276-5843		044			074
		045			053			085
5330-297-4578		021	5340-281-6688		022	5633	79575	021
		029			030			029
		073			074			073
		084			085			084
5330-298-0776		020	5340-282-5560		056	5687028	01510	014
		024	5340-353-5960		052			065
		028	5340-353-6606		021	569021	01510	014
		032			029			064
		036			073	5717	79575	022
		040			084			030
		071	5340-374-9707		046			074
		076	5340-447-9222		021			085
		082			029	5850	82247	068
		087			072	5851	82247	017
		092			083			068
		097	5340-550-5635		048	5852	82247	017
330-358-5683		050	5340-582-3078		001			068
330-362-1447		050			044	5871	01510	065

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE	NUMBER	CODE	PAGE	NUMBER	CODE	PAGE
5872	01510	066	6204	79575	022			089
5900	79575	022			030			094
		030			074			099
		074			085	854U	82796	078
5910-127-7252		085	6424	79575	021			089
		010			029			093
		059			073			099
5910-677-6348		010			084	855U	82696	078
		059	6425	79575	021			093
5910-740-2855		022			029	855U	82796	089
		030			073			094
		074			064	856G	82796	078
		085	6459	01510	012			089
5926	79575	022			014			094
		030			062			099
		074			065	856N	82697	094
		085	6465	79575	022	856N	82796	078
5930-797-9462		008			030			089
		058			074			099
5940-314-0255		021			085	857K	82796	078
		029	6560	82796	078			089
		073			089			093
		084			094			099
5940-321-9299		010	6585	79575	021	8112	73310	036
		059			029			092
5940-323-1459		009			073	8112	73370	020
		009			084			024
		058	6625-252-5545		009			026
		058			058			032
5970-353-7172		055	6680-718-7016		002			040
5970-656-7524		009			048			071
		058	6685-855-7226		013			076
5977-391-4031		008			062			082
		057	6690-704-1862		012			087
5977-627-3579		008			062			097
		057	6732	79575	021	8113	73370	020
5977-695-7139		008			029			028
		057			073			071
5977-696-0221		008			084			082
		057	6810-249-9354		009	8134	73370	020
5977-710-2044		056			059			028
654U	82796	078	6946	73370	020			071
		089			028			082
		094			071	820-6-305	09058	013
		099			082			063
6560	82796	099	6957	79575	022	8288	01510	066
656U	82796	078			030	8305-740-2859		021
		089			073			029
		093			084			073
		098	6984	79575	022			084
60-40r	80124	015			030	8739	79575	021
		067			074			029
60169	01510	065			085			073
6036	01510	065	713-9001-107	09058	063			084
6038	01510	065	713-9010-205	09058	064	8792	79575	022
6105-925-4976		056	7420	70655	012			023
6140-057-2553		009			061			030
		058	7491	70903	009			031
		009			058			073
6145-164-7023		019	7617	79575	021			074
		058			029			084
		070			073			085
6145-164-7033		010	7644	79575	021	90102	01510	014
		010			029			065
		018			073	90209	01510	014
		059			073			065
		059	7871	79575	084	90247	01510	014
		070			022			064
6145-295-0804		010			030	90259	01510	065
		018			074	90265	01510	014
		059			085			065
		070	7908	79575	021	92-1000-1240-18	09058	014
615A1	61976	004			029			064
		050			073	92-5660-1348	09058	013
616	95875	010			084			063
		060	7932	01510	014	92-900-820	09058	063
617	95875	010			065	9320-771-1512		011
		060	79575-4	81336	022			061
		022			030	9320-771-1513		012
6199	79575	030			074			061
		074			085	9515-529-0429		012
		085	8LW6	82796	078			018

FEDERAL STOCK NUMBER AND PART NUMBER INDEX

NUMBER	CODE	PAGE
9515-554-0893		062 070 012 018 061 070 062
9905-807-3712		

By Order of the Secretary of the Army:

Official:

KENNETH G. WICKHAM,
Major General, United States Army,
The Adjutant General.

HAROLD K. JOHNSON,
General, United States Army,
Chief of Staff.

Distribution:

Active Army:

USASA (2)
ACSI (1)
DCSLOG (1)
CNGB (1)
TSG (1)
CofEngrs (3)
CC-E (1)
Dir of Trans (1)
CofSptS (1)
USAMB (1)
USARTYBD (2)
USAARMBD (2)
USAIB (2)
USAADB (2)
USAAESWBD (2)
USAAVNBD (2)
USCONARC (3)
OS Maj Comd (5) except
 USASETAF (2)
 USARJ (1)
MDW (1)
Armies (2)
Corps (2)
Div (2)
Engr Bde (1)
Svc Colleges (2)
Br Svc Sch (2)
USACDCEC (10)
USMA (2)
Gen Dep (10)
Engr Dep (10)
A Dep (2) except
 TOAD (3)

USA Tml Comd (2)
Army Tml (1)
Div Engr (2)
Dist Engr (2)
USAERDL (3)
USAMEC (46)
Engr Cen (5)
USAREUR Engr Proc Cen (2)
USAREUR Engr Sup Con Agcy (10)
Engr FLDMS (2)
Ft Knox FLDMS (10)
Fld Comd, DASA (8)
AMS (3)
USAREURCOMZ (2)
USAC (1)
MAAG (1)
JBUSMC (1)
Units org under fol TOE:
(2 copies each UNOINDC)
8-7
3-147
3-217
5-48
5-287 (5)
5-282 (5)
5-267
5-278 (5)
5-279
8-204
8-500 (LA)
29-215
29-216

NG: None.

USAR: Same as Active Army except allowance is one copy to each unit.

For explanation of abbreviations used, see AR 320-50.